awei Y370

Awei Y370 Portable Bluetooth Speaker User Manual

Model: Y370

1. Introduction

Thank you for choosing the Awei Y370 Portable Bluetooth Speaker. This manual provides detailed instructions for setting up, operating, and maintaining your speaker. Please read this manual carefully before using the product to ensure proper function and longevity. Keep this manual for future reference.

2. Product Overview

The Awei Y370 is a versatile and robust portable Bluetooth speaker designed for both indoor and outdoor use. It features powerful stereo sound, an integrated FM radio, and a durable waterproof design. Its compact form factor and multiple playback options make it an ideal audio companion.

Key Features:

- **Waterproof Design:** IPX6 rated, offering protection against strong jets of water, suitable for outdoor environments.
- **Stereo Surround Sound:** Equipped with dual 10W speakers for rich, immersive audio.
- **Multiple Playback Modes:** Supports Bluetooth, USB disk, Micro-SD card, and AUX input.
- **FM Radio:** Built-in FM tuner for listening to your favorite radio stations.
- **Portable Design:** Compact and lightweight with a convenient carrying strap.
- **Dynamic LED Lighting:** Features colorful lighting effects that sync with music.
- **TWS Function:** Allows two Y370 speakers to be paired for true wireless stereo sound.

Product Components:



Image: The Awei Y370 speaker available in red, camouflage, and black, showcasing its portable design.





Image: The Awei Y370 speaker displaying its dynamic and colorful LED light show, which changes with the music.





4 Play Modes
Plug and Play
It is widely compatible with multiple playback modes, meeting the needs of more people
Bluetooth
U Disk
Micro-SD Card
AUX

Image: The Awei Y370 speaker highlighting its versatile connectivity options, including Bluetooth, USB drive, Micro-SD card, and AUX input.





Image: An internal view of the Awei Y370 speaker, illustrating its dual 10W horns and double diaphragms for enhanced sound quality.





Image: The Awei Y370 speaker positioned outdoors near water, emphasizing its IPX6 waterproof capability, making it suitable for various environments.





Image: Detailed views of the Awei Y370 speaker, highlighting its portable design, accessible control buttons, and anti-slip silicone base.





Image: Two Awei Y370 speakers set up to demonstrate True Wireless Stereo (TWS) connection, providing a wider soundstage.

3. Setup

3.1 Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB charging cable to the speaker's charging port and the other end to a compatible USB power adapter (5V). The charging indicator light will illuminate. A full charge takes approximately 5-6 hours.

- Battery Capacity: 3600mAh
- Charging Time: Approximately 5-6 hours

3.2 Powering On/Off

Press and hold the Power button ( ) for 2-3 seconds to turn the speaker on or off. A power-on/off tone will indicate the status.

3.3 Bluetooth Pairing

1. Turn on the Awei Y370 speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED light.
2. On your mobile device (smartphone, tablet, computer), enable Bluetooth.
3. Search for available Bluetooth devices. Select "Awei Y370" from the list.
4. Once connected, the speaker will emit a confirmation tone, and the LED light will become solid.
5. The speaker will automatically reconnect to the last paired device when powered on, if the device is within range and Bluetooth is enabled.

Bluetooth Version: V5.0

3.4 Other Playback Modes

The Awei Y370 supports multiple audio input methods:

- **USB Disk:** Insert a USB flash drive into the USB port. The speaker will automatically switch to USB mode and begin playing audio files.
- **Micro-SD Card:** Insert a Micro-SD card (TF card) into the designated slot. The speaker will switch to TF card mode and play audio.
- **AUX Input:** Connect an audio device using a 3.5mm AUX cable to the AUX port. The speaker will switch to AUX mode.

4. Operating Instructions

4.1 Button Functions

Familiarize yourself with the control buttons on the speaker:

- **Power Button ( ):** Press and hold to power on/off. Short press to switch playback modes (Bluetooth, FM, AUX, USB, TF).
- **Play/Pause Button (▶‖):** Short press to play or pause music. In FM mode, short press to auto-scan and save stations.
- **Volume Down / Previous Track (-):** Short press to decrease volume. Long press to go to the previous track (in Bluetooth/USB/TF mode) or previous FM station.
- **Volume Up / Next Track (+):** Short press to increase volume. Long press to go to the next track (in Bluetooth/USB/TF mode) or next FM station.
- **Light Mode Button ( ):** Short press to cycle through different LED light modes. Long press to turn lights on/off.

4.2 FM Radio Operation

1. Press the Power button ( ) to switch to FM Radio mode.
2. Short press the Play/Pause button (▶‖) to initiate an automatic scan for available FM stations. The speaker will save found stations.
3. Use the Volume Up (+) and Volume Down (-) buttons (long press) to navigate between saved stations.

4.3 True Wireless Stereo (TWS) Pairing

To achieve a true stereo sound experience, you can pair two Awei Y370 speakers together:

1. Ensure both Awei Y370 speakers are powered on and not connected to any Bluetooth device.
2. On one of the speakers (this will be the primary speaker), long press the Play/Pause button (▶‖) until you hear a TWS pairing prompt.
3. The two speakers will automatically search and connect to each other. Once connected, you will hear a confirmation tone.
4. Now, connect your mobile device to the primary speaker via Bluetooth as described in section 3.3. Audio will play through both speakers, creating a stereo effect.

Note: TWS mode only works with two identical Awei Y370 speakers.

5. Maintenance and Care

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Water Resistance:** While the speaker is IPX6 waterproof, avoid submerging it in water for extended periods. Ensure the charging port cover is securely closed when near water.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, charge the speaker regularly, even if not in frequent use. Avoid fully discharging the battery for long periods.
- **Avoid Impacts:** Do not drop or subject the speaker to strong impacts, as this may damage internal components.

6. Troubleshooting

Problem	Possible Cause	Solution
Speaker does not turn on.	Low battery.	Charge the speaker fully.
No sound.	Volume too low; incorrect input mode; device not connected.	Increase volume; ensure correct mode (Bluetooth, AUX, USB, TF); re-pair Bluetooth device.
Cannot pair via Bluetooth.	Speaker not in pairing mode; device Bluetooth off; too far from device.	Ensure speaker is in pairing mode; turn on device Bluetooth; move device closer (within 10M).
FM radio signal is poor.	Weak signal in current location.	Move the speaker to a location with better reception.
TWS pairing fails.	Speakers already connected to other devices; not both Y370 models.	Disconnect speakers from other devices; ensure both are Awei Y370 models.

7. Specifications

Detailed technical specifications for the Awei Y370 speaker:




Image: Technical drawing illustrating the dimensions of the Awei Y370 speaker, with a height of 23cm and a diameter of 15cm.

Basic Information

Item No.: Y370

Net Weight: About 1,100g

Name: Outdoor Bluetooth Speaker

Size: ϕ150*230mm

Bluetooth

Version: 5.0

Transmission Distance: 8~12m

Supported Protocols: A2DP/HFP/HSP/AVRCP

Horns

Diameter: 40mm

Rated Power: 10W*2

Frequency Response Range: 80Hz~15KHz

Battery

Capacity: 3,600mAh

Charging Time: About 6h

Play Time: 7~8h

Image: A table summarizing key specifications including basic information, Bluetooth version, horn details, and battery capacity and play time.

Feature	Specification
Model	Y370
Bluetooth Version	V5.0 (Jerry 6966B solution)
Battery Capacity	3600mAh
Charging Time	Approx. 5-6 hours
Playing Time	Approx. 5-6 hours
Output Power	10W * 2
Effective Distance	10M
Frequency Response	80Hz-15KHz
External Magnetic Speaker	4 ohm 10W * 2
Input Sensitivity	400mV
Separation	≥90dB
Signal to Noise Ratio	≥80dB
Waterproof Rating	IPX6
Product Dimensions	15cm (diameter) x 23cm (height)
Net Weight	Approx. 1100g (1.1 kg)

8. Warranty and Support

The Awei Y370 Portable Bluetooth Speaker comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage details.
For technical support, troubleshooting assistance, or warranty claims, please contact the retailer where you purchased the product or visit the official Awei website for customer service contact information. Ensure you have your proof of purchase ready when seeking support.
Manufacturer: Awei

© 2024 Awei. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question