

Majority Homerton

Majority Homerton 2 User Manual

Model: Homerton

INTRODUCTION

Welcome to the user manual for your Majority Homerton 2 Internet Radio, DAB, FM, and CD Player. This comprehensive guide will assist you in setting up, operating, and maintaining your device to ensure optimal performance and enjoyment of its wide range of features, including Internet Radio, DAB/DAB+, FM, CD playback, Bluetooth connectivity, Spotify Connect, and Podcast streaming.



Image: The Majority Homerton 2 unit in oak finish, showing the front panel with display, controls, CD slot, and a remote control in the foreground.

SETUP

1. Unpacking and Placement

Carefully remove the Homerton 2 from its packaging. Place the unit on a stable, flat surface away from direct sunlight, heat sources, and excessive moisture. Ensure adequate ventilation around the unit.

2. Connecting Power

Connect the provided power adapter to the DC IN port on the back of the unit, then plug the adapter into a wall outlet. The unit will power on or enter standby mode.

3. Antenna Connection

Extend the telescopic antenna fully for optimal DAB/DAB+ and FM radio reception. For Internet Radio and Wi-Fi features, ensure the unit is within range of your wireless router.

4. Initial Setup Wizard

Upon first power-on, the Homerton 2 will guide you through an initial setup wizard. This includes:

- **Language Selection:** Choose your preferred language for the display menu.
- **Network Connection:** Select your Wi-Fi network and enter the password. This is crucial for Internet Radio, Spotify Connect, and Podcast features.
- **Time and Date:** Set the current time and date, or allow the unit to synchronize automatically via network or DAB signal.

High-performance Internet radio featuring DAB+ and CD player.




Image: The Homerton 2 unit showcasing its display and control knobs, indicating its readiness for use.

OPERATING INSTRUCTIONS

1. Power On/Off and Standby

Press the **Power** button on the unit or remote control to switch the unit on or off. In standby mode, the display may show the clock.

2. Mode Selection

Use the **Mode** button on the unit or remote to cycle through available modes: Internet Radio, DAB/DAB+, FM, CD, Bluetooth, USB (MP3), and Auxiliary Input.

3. Internet Radio

Connect to thousands of global radio stations via your Wi-Fi network. Navigate through stations by genre, location, or search. Save your favorite stations as presets for quick access.



Image: The Homerton 2 unit with its display showing the Internet Radio interface, indicating connectivity and available options.

4. DAB/DAB+ and FM Radio

Tune into digital (DAB/DAB+) or analog (FM) radio broadcasts. Perform an auto-scan to find available stations in your area. Use the tuning knob or remote control to select stations. You can store up to 40 presets for your favorite stations.

5. CD Player

Insert an audio CD or MP3 CD into the front-loading CD slot. The unit will automatically detect and begin playback. Use the playback controls (Play/Pause, Skip, Stop) on the unit or remote control. The integrated CD player allows you to enjoy your physical music collection with ease.



THE QUEEN'S AWARDS
2021



Explore your **complete**
music collection through
crystal clear sound.



Image: The Homerton 2 unit with a CD being inserted into its front-loading slot, demonstrating the CD playback capability.

6. Bluetooth Connectivity

Pair your smartphone, tablet, or other Bluetooth-enabled device with the Homerton 2 to stream audio wirelessly. Select Bluetooth mode on the unit, then search for "Homerton 2" on your device's Bluetooth settings and connect. Enjoy high-quality audio streaming from your personal library or streaming apps.

7. Spotify Connect & Podcasts

If you have a Spotify Premium account, use Spotify Connect to control music playback directly from the Spotify app on your phone or tablet, streaming audio through the Homerton 2. Access a wide selection of podcasts directly from the unit's menu.




Image: The Homerton 2 unit next to a smartphone showing the Spotify app, illustrating its Spotify Connect and Bluetooth streaming features.

8. USB Playback (MP3)

Insert a USB flash drive containing MP3 audio files into the USB port. The unit will automatically switch to USB mode and begin playing the files. This allows you to enjoy your own media in HD sound.

9. Dual Alarm Clock

Set up to two independent alarms. You can choose to wake up to a buzzer, FM radio, DAB radio, or Internet radio station. Configure alarm times, sources, and recurrence (daily, weekdays, weekends).



Image: The Homerton 2 unit with a graphic overlay of an alarm clock, emphasizing its dual alarm functionality.

10. Equalizer Settings

Adjust the audio output using the built-in equalizer. Select from preset equalization modes (Normal, Jazz, Rock, Classical, Pop) or customize your own 'My EQ' settings for personalized bass and treble levels.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the unit's exterior. Do not use abrasive cleaners or solvents.
- **CD Player Care:** Keep the CD slot free of dust and debris. Use a CD lens cleaner if playback issues occur due to a dirty lens.
- **Ventilation:** Ensure the ventilation openings are not blocked to prevent overheating.
- **Storage:** If storing the unit for an extended period, disconnect it from power and store in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
No Power	Power adapter not connected; Power outlet faulty.	Check power connections; Try a different outlet.
No Sound	Volume too low; Mute activated; Incorrect source selected.	Increase volume; Deactivate mute; Select correct input mode.
Poor Radio Reception	Antenna not extended; Weak signal; Interference.	Fully extend antenna; Reposition unit; Scan for stations again.
Wi-Fi Connection Issues	Incorrect password; Out of range; Router issues.	Re-enter password; Move unit closer to router; Restart router.
CD Playback Errors	Dirty or scratched CD; Incorrect disc type.	Clean CD; Try a different CD; Ensure it's an audio or MP3 CD.

SPECIFICATIONS

Brand: Majority
Model Number: Homerton
Color: Oak
Connectivity Technology: Bluetooth, USB, WLAN (Wi-Fi)
Special Features: Integrated Clock, Portable, Dual Alarm
Compatible Devices: MP3 Player
Product Dimensions: 23L x 20.2W x 12.8H cm
Tuning Technology: Internet Radio, DAB/DAB+, FM
Supported Radio Bands: 3 band
Power Source: Corded Electric
Components Included: Homerton CD Player, Owner's Manual, Remote Control

WARRANTY AND SUPPORT

The Majority Homerton 2 comes with a **3-year extended warranty**, providing peace of mind for your audio product. For detailed warranty terms and conditions, please refer to the official Majority website or the warranty card included with your product.

For technical support, troubleshooting assistance, or to inquire about spare parts availability, please visit the official Majority support website or contact their customer service. Keep your purchase receipt handy as proof of purchase.




Image: An icon representing the 3-year warranty provided with Majority audio products.



