



[Manuals.plus](#) /

› [Outsunny](#) /

› Outsunny Outdoor Dining Table User Manual

Outsunny 30.75" x 30.75" x 29.25" (Model 196393161920)

Outsunny Outdoor Dining Table User Manual

Model: 30.75" x 30.75" x 29.25" (196393161920)

INTRODUCTION

Thank you for choosing the Outsunny Outdoor Dining Table. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new dining table. Please read all instructions carefully before use and retain this manual for future reference.



Front view of the Outsunny Outdoor Dining Table, showcasing its square design and black woodgrain finish.

SAFETY INFORMATION

To ensure safe use and prevent damage, please observe the following safety precautions:

- Always assemble the table on a flat, stable surface.
- Ensure all bolts and fasteners are securely tightened before use. Periodically check and re-tighten as needed.
- Do not exceed the maximum weight capacity of 110 lbs (50 kg).
- Keep small parts and packaging materials away from children during assembly to prevent choking hazards.
- Avoid placing hot items directly on the tabletop without protective mats.
- Do not stand or sit on the table.
- Use caution when moving the table to prevent injury or damage.

PARTS LIST

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

No.	Part Description	Quantity
1	Tabletop	1
2	Table Legs	4
3	Hardware Pack (Bolts, Washers, Hex Wrench)	1 set
4	Adjustable Non-slip Foot Pads (pre-attached or separate)	4

ASSEMBLY INSTRUCTIONS

Assembly of the Outsunny Outdoor Dining Table is straightforward. It is recommended to have two people for easier assembly.

- Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface (e.g., a blanket or cardboard) to prevent scratches.
- Attach Legs to Tabletop:** Align each table leg (Part 2) with the corresponding corner bracket on the underside of the tabletop (Part 1). Ensure the tabs on the legs align with the backing plates for correct orientation.
- Secure Legs:** Insert the provided bolts from the Hardware Pack (Part 3) through the pre-drilled holes in the leg brackets and into the tabletop. Hand-tighten all bolts initially.
- Final Tightening:** Once all legs are in place, use the hex wrench (from Part 3) to fully tighten all bolts. Do not overtighten.
- Check Stability:** Carefully turn the table upright. Ensure all legs are stable and the table does not wobble. Adjust the non-slip foot pads (Part 4) if necessary to achieve balance on uneven surfaces.

ALUMINIUM STRUCTURE



Sturdy



Durable



Lightweight

Designed for long term outdoor use

Adjustable & Anti-slip Foot Pads

Illustration of the table's aluminum structure and adjustable anti-slip foot pads, highlighting stability features.

Note: No official seller-provided assembly video is available for this product. Please refer to the written instructions and diagrams provided with your product packaging for detailed visual guidance.

USAGE GUIDELINES

The Outsunny Outdoor Dining Table is designed for versatile outdoor use, accommodating up to four people. Its durable construction makes it suitable for various activities.

- **Dining:** Ideal for outdoor meals, picnics, and gatherings.
- **Recreation:** Suitable for board games, card games, or as a surface for crafts.
- **Versatility:** Can be used on patios, lawns, gardens, or for camping.



The dining table set up in an outdoor patio area, demonstrating its practical use for dining.

MULTIPLE USE

Great addition for garden activities



A collage illustrating various applications of the table, including dining, social gatherings, and leisure activities.

CARE AND MAINTENANCE

Proper care will extend the life and appearance of your Outsunny Outdoor Dining Table.

- **Cleaning:** Wipe clean with a damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly. Avoid harsh chemicals or abrasive cleaners.
- **Protection:** While the table is designed for outdoor use and is resistant to weather, covering it during prolonged periods of non-use or extreme weather conditions (heavy rain, snow, intense sun) is recommended to preserve its finish.
- **Storage:** If storing indoors, ensure the table is clean and dry to prevent mold or mildew.
- **Inspection:** Periodically inspect all connections and components for wear or damage. Tighten any loose fasteners.

WOOD-LIKE TABLETOP

Brings a natural feeling to your garden



Rustic



Solid



Easy to clean



Detail of the wood-like tabletop, emphasizing its easy-to-clean surface.

TROUBLESHOOTING

If you encounter issues with your dining table, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Table wobbles after assembly.	Uneven floor or loose fasteners.	Adjust the non-slip foot pads on the bottom of the legs. Ensure all assembly bolts are securely tightened.
Difficulty inserting bolts during assembly.	Misalignment or paint/coating on threads.	Ensure parts are correctly aligned. Some bolts may have paint/powder coating; apply slight pressure and turn slowly. Do not force.
Surface scratches or marks.	Sharp objects or abrasive cleaning.	Use soft cloths for cleaning. Avoid dragging objects across the surface. For minor scratches, touch-up paint may be available from the manufacturer.

PRODUCT SPECIFICATIONS

Detailed specifications for your Outsunny Outdoor Dining Table:

Brand: Outsunny

Model Name: Garden Dining Table

Model Number: 196393161920

Overall Dimensions: 30.75" L x 30.75" W x 29.25" H (78.1 cm L x 78.1 cm W x 74.3 cm H)

Material: Aluminum (frame), Plastic (tabletop with woodgrain finish)

Color: Woodgrain Black

Weight Capacity: 110 lbs (50 kg)

Item Weight: 16.5 lbs (7.5 kg)

Seating Capacity: 4 persons

Indoor/Outdoor Usage: Outdoor

Finish Type: Powder Coated (frame)

Shape: Square

Umbrella Hole Diameter: 1 inch (2.54 cm)



Diagram showing the precise dimensions of the Outsunny Outdoor Dining Table.

WARRANTY AND SUPPORT

Outsunny products typically come with a limited warranty. For specific warranty terms, conditions, and duration, please refer to the warranty card included with your product packaging or visit the official Outsunny website. For customer support, replacement parts, or further assistance, please contact Outsunny customer service through their official channels.

Visit the [Outsunny Store on Amazon](#) for more information and products.

© 2024 Outsunny. All rights reserved.