



[Manuals.plus](#) /

› [farexon](#) /

› farexon Electric Standing Desk (Model: 1) - User Manual

## farexon 1

# farexon Electric Standing Desk (Model: 1) - User Manual

Adjustable Height Sit-Stand Desk with Wheels, 4 Memory Heights, 48 x 24 inch

[Introduction](#) [Safety Information](#) [Package](#)

[Contents](#) [Assembly](#) [Operation](#) [Features](#) [Specifications](#) [Troubleshooting](#) [Maintenance](#) [Warranty & Support](#)

## 1. INTRODUCTION

Thank you for choosing the farexon Electric Standing Desk. This adjustable height sit-stand desk is designed to enhance your workspace with ergonomic flexibility and convenience. Featuring a 48 x 24 inch desktop, 4 memory height presets, and a lifting range of 27.9 to 46.8 inches, it offers a versatile solution for your home or office.



*The farexon Electric Standing Desk in Oak Grey, showcasing its spacious desktop and modern design.*

## 2. SAFETY INFORMATION

**WARNING: Ensure the desk is not overloaded with more than 178 pounds to prevent instability or damage. Improper use may result in injury.**

- Keep children and pets away from the desk during operation.
- Ensure no obstacles are in the path of the desk's movement (up or down).
- Do not sit or stand on the desk.
- Only use the provided power adapter and cables.
- If the desk encounters obstacles during movement, its anti-collision technology will cause it to move 2cm in the opposite direction to prevent damage.

## 3. PACKAGE CONTENTS

Please check that all the following components are included in your package before beginning assembly:

- Desktop (48 x 24 inches, Oak Grey)

- Desk Frame (White)
- 4 Lockable Casters
- 4 Foot Pads
- 2 Metal Hooks
- 3 Cable Clips
- 2 Cable Take-ups
- 1 Enclosed Shelf
- 1 Cabinet
- 1 Built-in Wireless Charger (Note: 48-inch desk does not provide a mouse pad)
- Assembly Tools (Screwdriver, Allen wrench)
- Instruction Manual

*Video: Unboxing and overview of all components included with the farexon Electric Standing Desk.*

## 4. ASSEMBLY INSTRUCTIONS

The farexon Electric Standing Desk is designed for easy assembly with fewer steps. A detailed installation video is available to guide you through the process.

### 4.1. Assembly Video Guide

Your browser does not support the video tag.


*Video: A comprehensive guide demonstrating the step-by-step assembly process for the farexon Electric Standing Desk.*

### 4.2. Key Assembly Steps

1. **Desktop Assembly:** The 48-inch desktop is made of two boards. Connect them securely using the provided hardware.
2. **Frame Assembly:** Assemble the metal frame components, including the legs and crossbeam.
3. **Attach Desktop to Frame:** Carefully align the desktop with the assembled frame and secure it with screws.
4. **Install Accessories:** Attach the casters or foot pads, cable clips, and metal hooks as desired.
5. **Connect Cables:** Connect all motor and control panel cables. Use the cable take-ups and clips for organized cable management.



*Image: Exploded view of the desk frame components, illustrating how they fit together during assembly.*



## Durable high quality motor

The motor tested 50,000 times and still going strong



Noise< 50dB



Anti-Collision  
Technology



Child lock



Overheating  
protection

*Image: Visual guide for connecting the two desktop panels to form the complete work surface.*

## 5. OPERATING INSTRUCTIONS

The farexon Electric Standing Desk offers intuitive controls for seamless height adjustment and personalized settings.

### 5.1. Height Adjustment

- The desk can be adjusted electrically between 27.9 inches and 46.8 inches.
- Use the ^ (up) and v (down) buttons on the control panel to raise or lower the desk to your desired height.

### 5.2. Memory Presets

The control panel features four memory buttons (1, 2, 3, 4) to store your preferred heights.

1. Adjust the desk to your desired height using the up/down buttons.
2. Press and hold one of the memory buttons (1, 2, 3, or 4) for 2 seconds until the display flashes. This saves the current height to that button.
3. To recall a saved height, simply press the corresponding memory button. The desk will automatically move to the stored position.

# Multifunctional Smart LED Controller



## Memory Button

4 memory height in 1/2/3/4



## Up/down

Press the button to adjust the height



## Re-memory height

Long press to re-memory your height



## LED

LED screen displays current height

*Image: The multifunctional smart LED controller, showing the up/down arrows, memory buttons, and current height display.*

## 6. KEY FEATURES

- **Electric Height Adjustment:** Smooth and quiet lifting motor with a range of 27.9"-46.8".
- **4 Memory Presets:** Easily save and recall your preferred sitting and standing heights.
- **Anti-Collision Technology:** Automatically reverses 2cm if an obstacle is detected during movement, ensuring safety.
- **Spacious Desktop:** Large 48" x 24" surface provides ample space for multiple monitors and accessories. The tabletop is water and wear-resistant.
- **Cable Management:** Includes a wire collection hole, cable clips, and cable take-ups to keep your workspace tidy.
- **Mobility & Stability:** Comes with 4 lockable casters for easy movement and 4 foot pads for stationary stability.
- **Convenient Hooks:** Two additional metal hooks are provided for hanging headphones, bags, or other items.

# 25Mins Quick Installation



Image: Close-up of various desk features, including the protective edge, 360° rotation wheels, cable management clips, and waterproof desktop material.



Image: Visual explanation of the anti-collision feature, showing the desk reversing upon encountering an obstacle.

## 7. SPECIFICATIONS

Feature	Detail
Brand	farexon

Model Number	1
Desk Design	Computer Desk
Product Dimensions	24"D x 48"W x 46"H
Color	Oak Grey (Desktop), White (Base)
Minimum Height	27.9 Inches
Maximum Height	46.8 Inches
Lifting Mechanism	Electric
Material Type	Alloy Steel, Wood
Maximum Weight Recommendation	178 Pounds
Special Features	Adjustable Height, Electric, Ergonomic, 4 Memory Presets, Anti-Collision, Wheels
Required Assembly	Yes
Included Components	4 Lockable casters, 4 Foot pads, 2 Metal hooks, 3 cable clips, 2 Cable take-ups, 1 Enclosed shelf, 1 Cabinet, 1 Built-in wireless charger



*Image: Dimensional drawing of the farexon Electric Standing Desk, indicating its height, width, and depth.*

## 8. TROUBLESHOOTING

Here are some common issues and their solutions:

- **Controller Displays "RST", "E07", or "E08" / Desk is Not Working:** To reset the desk, press and hold the v (down) button twice. The desk will move to its lowest position and then reset.
- **Desk Not Moving Smoothly:** Ensure all connections are secure and there are no obstructions.

- **Desk Not Reaching Desired Height:** Check the power connection and ensure the desk is not overloaded.

## 8.1. How to Reset the Standing Desk (Video Guide)

Your browser does not support the video tag.

*Video: A short instructional video demonstrating the process of resetting the farexon Electric Standing Desk.*

## 9. MAINTENANCE

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid harsh chemicals.
- **Cable Management:** Periodically check cable connections and ensure they are neatly organized to prevent snagging or damage.
- **Motor Care:** The motor is designed for durability. Avoid excessive or continuous operation without breaks.

## 10. WARRANTY & SUPPORT

### 10.1. Warranty Information

This farexon Electric Standing Desk comes with a **Limited Warranty**. Please refer to the warranty card included in your package for specific terms and conditions.

### 10.2. Customer Support

For any product problems, questions, or assistance, please contact farexon customer support. We are committed to helping you resolve any issues.

Visit the [farexon Store on Amazon](#) for more information and contact options.