

Sanus SOA-SBM2

SANUS Universal Soundbar TV Mount Kit

Model: SOA-SBM2

INTRODUCTION

The SANUS Universal Soundbar TV Mount Kit (Model SOA-SBM2) is designed to securely attach your soundbar directly to your TV wall mount, positioning it right under your television. Crafted from premium steel, this mount supports soundbars weighing up to 15 lbs. It is compatible with a wide range of soundbar brands, including Samsung, Roku, Bose, Vizio, and LG, and is designed to accommodate both rear and bottom-mounted soundbars. Its adjustable design ensures optimal sound projection, even with Dolby Atmos compatible soundbars.

SAFETY INFORMATION

- Read all instructions before installation and assembly. If you have any questions regarding the instructions or warnings, please contact customer support.
- Do not exceed the weight capacity of 15 lbs (6.8 kg). Serious injury or property damage may occur.
- Ensure the TV wall mount to which this soundbar mount is attached is securely installed and rated for the combined weight of the TV and soundbar.
- Use caution when handling and installing. Always use appropriate lifting techniques.
- This product is intended for indoor use only.

PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning installation. If any parts are missing or damaged, do not attempt to install. Contact SANUS customer service for assistance.

ALL ASSEMBLY HARDWARE INCLUDED



Image: All assembly hardware included, neatly organized for easy identification.

Included Components:

- Soundbar Mount Arms (2)
- Soundbar Brackets (2)
- Mounting Hardware Kit (various screws, washers, spacers, hex key)
- Instruction Manual

SETUP AND INSTALLATION

The SANUS Universal Soundbar TV Mount is designed for easy installation, typically in less than 15 minutes. No drilling is required for the soundbar mount itself, as it attaches directly to your existing TV wall mount.



Image: Easy installation process, attaching the soundbar mount to the TV and existing wall mount.

Installation Steps:

1. **Prepare Your Soundbar:** Identify the mounting points on your soundbar. The mount supports both rear and bottom-mounted soundbars. Attach the soundbar brackets to your soundbar using the appropriate screws from the hardware kit.
2. **Attach Mount Arms to TV:** If your TV is already mounted, you may need to temporarily remove it from the wall mount. Attach the soundbar mount arms to the VESA mounting holes on the back of your TV, alongside your existing TV wall mount brackets. Ensure they are securely fastened.
3. **Connect Soundbar to Mount Arms:** Slide the soundbar (with attached brackets) onto the soundbar mount arms. Secure it in place using the provided hardware.
4. **Re-mount TV (if removed):** If you removed your TV, carefully re-mount it to your wall mount.
5. **Adjust Height and Depth:** Loosen the knobs on the mount arms to adjust the height and depth of the soundbar. This allows you to position the soundbar optimally and prevent blockage of ceiling-deflected sound for Dolby Atmos setups. Tighten the knobs with the included hex key to secure the position.

**ATTACHES
EASILY**
TO TV WALL
MOUNT



Image: The soundbar mount seamlessly integrates with your existing TV wall mount.



HEIGHT & DEPTH ADJUSTABLE

TO ACCOMMODATE DOLBY ATMOS
& UP-FIRING SOUNDBARS

Image: Adjustable height and depth for optimal sound and compatibility with various soundbar types.



TOOL-FREE TENSION ADJUSTMENT KNOBS

PREVENT SOUNDBAR SAGGING

Image: Tool-free tension adjustment knobs ensure the soundbar remains level and secure.

OPERATING INSTRUCTIONS

Once installed, the SANUS Universal Soundbar TV Mount allows your soundbar to move in perfect synchronicity with your TV, especially when attached to a full-motion TV mount. This ensures that the sound is always directed towards your viewing position, providing an optimal audio experience from any seat in the room.



Image: The soundbar moves with your TV, ensuring consistent audio direction.

Adjusting Soundbar Position:

- **Height Adjustment:** To adjust the vertical position of your soundbar, loosen the height adjustment knobs on the mount arms. Slide the soundbar up or down to the desired height, then re-tighten the knobs securely.
- **Depth Adjustment:** To adjust how far the soundbar protrudes from the TV, loosen the depth adjustment screws. Slide the soundbar forward or backward to achieve the optimal depth, especially important for preventing obstruction of up-firing speakers on Dolby Atmos soundbars. Re-tighten the screws firmly.

MAINTENANCE

The SANUS Universal Soundbar TV Mount requires minimal maintenance to ensure its longevity and continued performance.

- **Cleaning:** Dust the mount periodically with a soft, dry cloth. For more stubborn dirt, a slightly damp cloth can be used, followed by a dry cloth. Avoid abrasive cleaners or solvents.
- **Fastener Check:** Periodically check all screws and fasteners to ensure they remain tight and secure. Over time, vibrations or adjustments may cause them to loosen slightly. Re-tighten as necessary.
- **Movement Check:** If your soundbar mount is attached to a full-motion TV mount, occasionally check the movement mechanisms to ensure they operate smoothly.

TROUBLESHOOTING

If you encounter any issues with your SANUS Universal Soundbar TV Mount, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Soundbar sags or is not level.	Tension knobs are not tightened sufficiently.	Ensure the tool-free tension adjustment knobs are fully tightened with the included hex key.
Soundbar does not attach to mount.	Incorrect screws or mounting method for soundbar.	Refer to your soundbar's manual for its specific mounting requirements (rear or bottom). Use the correct screws and spacers from the SANUS hardware kit.
Soundbar blocks TV screen or sound.	Incorrect height or depth adjustment.	Adjust the height and depth of the soundbar using the adjustment knobs/screws until it clears the TV screen and does not obstruct sound, especially for up-firing speakers.
Mount feels unstable.	Mounting screws to TV or soundbar not tight; TV wall mount itself is unstable.	Verify all screws connecting the soundbar mount to the TV and soundbar are securely tightened. Also, ensure your primary TV wall mount is properly installed and stable. Do not exceed the 15 lbs weight capacity.

If the problem persists, please contact SANUS customer support.

SPECIFICATIONS

Model Number	SOA-SBM2
Brand	Sanus
Material	Alloy Steel
Color	Black
Maximum Weight Capacity	15 lbs (6.8 kg)
Mounting Type	Attaches to TV Wall Mount
Special Features	Adjustable Height & Depth, Tool-Free Tension Adjustment
Item Weight	3.52 pounds (1.6 kg)
Package Dimensions	12.24 x 5.31 x 1.85 inches (31.1 x 13.5 x 4.7 cm)
UPC	793795537072

WARRANTY AND SUPPORT

SANUS products are designed and engineered in the U.S. and are backed by a commitment to quality and customer satisfaction.

#1 BEST-SELLING TV MOUNT BRAND IN THE U.S.*

OUR PROMISE TO YOU

*NPD annual dollar sales period ending 12/31/2021



#1 BEST-SELLING MOUNT BRAND



U.S.-BASED CUSTOMER CARE



WE BACK OUR PRODUCTS



EASY 3-STEP INSTALLATION



UL-LISTED FOR QUALITY

Image: SANUS commitment to quality and customer support.

Warranty Information:

This SANUS Universal Soundbar TV Mount comes with a warranty. Please refer to the product packaging or the official SANUS website for specific warranty terms and conditions. SANUS has over 30 years of experience in designing premium products.

Customer Support:

For any questions, assistance with installation, or troubleshooting, SANUS offers U.S.-based expert customer care available 7 days a week. Visit the official SANUS website or refer to the contact information provided in your product packaging for support details.

© 2024 SANUS. All rights reserved.

Related Documents

	SANUS SOA-SBM1 Soundbar Mount Installation Guide Comprehensive installation guide for the SANUS SOA-SBM1 soundbar mount. Includes safety warnings, parts list, weight limits, and step-by-step instructions for mounting your soundbar securely below your TV.
	SANUS BMF320 Elite Advanced Full-Motion TV Mount Installation Manual Step-by-step instructions for installing the SANUS BMF320 Elite Advanced Full-Motion TV Mount. Includes safety guidelines, hardware lists, and mounting procedures for wood studs and concrete.
	SANUS TV Mount Size Chart and Compatibility Guide A comprehensive guide to SANUS TV mounts, detailing specifications for full-motion, low-profile, tilting, and specialty mounts, along with TV hole pattern compatibility (VESA and Random) to help users select the right mount for their television.



[SANUS WSSATM1-B2 Extendable Soundbar TV Mount for Sonos Arc](#)

The SANUS WSSATM1-B2 is an extendable TV mount designed to perfectly complement your Sonos Arc or Sonos Arc Ultra soundbar. It attaches directly to your TV mount, allowing the sound to move with your TV and ensuring optimal performance for Dolby Atmos speakers and microphones.