

[manuals.plus](#) /› [SelfieShow](#) /› [SelfieShow Portable 41 Inch Selfie Stick Phone Tripod with Wireless Remote and Fill Light \(Model Q02S\) - Instruction Manual](#)

SelfieShow Q02S

SelfieShow Portable 41 Inch Selfie Stick Phone Tripod with Wireless Remote and Fill Light (Model Q02S) - Instruction Manual

Model: Q02S | Brand: SelfieShow

1. INTRODUCTION

This manual provides detailed instructions for the proper setup, operation, and maintenance of your SelfieShow Portable 41 Inch Selfie Stick Phone Tripod with Wireless Remote and Fill Light, Model Q02S. Please read this manual thoroughly before using the product to ensure safe and efficient operation.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- SelfieShow Selfie Stick Tripod with integrated phone holder
- Detachable Wireless Remote Control
- Detachable LED Fill Light
- USB Charging Cable (for fill light)
- Lithium Metal Battery (for remote, often pre-installed or spare)
- User Manual (this document)




Image 2.1: Contents of the SelfieShow Q02S package. This includes the selfie stick tripod, a detachable wireless remote, a detachable LED fill light, a USB charging cable, and the user manual.

3. PRODUCT OVERVIEW

Familiarize yourself with the main components of your SelfieShow Q02S device:

- **Phone Holder:** Securely grips your smartphone. Features 360° rotation and 225° neck adjustment.
- **Extendable Rod:** Multi-section stainless steel rod for adjustable length.
- **Tripod Base:** Foldable legs for stable freestanding use.
- **Handle:** Ergonomic grip for handheld use.
- **Wireless Remote Control:** Detachable Bluetooth remote for capturing photos/videos.
- **LED Fill Light:** Detachable light with multiple color modes and brightness levels.



Image 3.1: Key components of the SelfieShow Q02S. This diagram highlights the detachable fill light, the silicone-padded phone clip, the multi-section stainless steel extension rod, the stable tripod base with anti-skid pads, and the detachable wireless remote control.

4. SETUP INSTRUCTIONS

4.1 Unfolding the Selfie Stick Tripod

1. Hold the handle firmly.
2. Gently pull the phone holder upwards to extend the rod.
3. To use as a tripod, spread the three legs at the bottom of the handle until they are fully extended and stable.
4. Adjust the extendable rod to your desired height.



Image 4.1: The SelfieShow Q02S in its compact, folded state and fully extended as a tripod. The image also shows the detachable remote control and the LED fill light.

4.2 Attaching Your Smartphone

1. Open the phone holder clamps. The holder supports phones with widths between 2.5 and 3.6 inches (6.5-9.2 cm).
2. Carefully place your smartphone into the holder, ensuring it is securely gripped by the silicone pads.
3. Adjust the phone holder's angle and rotation (360° rotation, 225° neck adjustment) to achieve the desired viewing or shooting position. Tighten any locking mechanisms if present to secure the angle.



Image 4.2: The phone holder's adjustable angle and 360-degree rotation capabilities. A locking mechanism ensures the phone remains in the chosen position.

4.3 Pairing the Wireless Remote Control

1. Ensure the remote control has a working battery. If not, replace the Lithium Metal battery.
2. Turn on the remote control by pressing and holding the button until an indicator light flashes (usually blue).
3. On your smartphone, go to Bluetooth settings and enable Bluetooth.
4. Search for available devices. The remote will typically appear as "SelfieShow" or a similar name.
5. Select the device to pair. The indicator light on the remote will stop flashing or turn solid once paired.
6. The remote is now ready to use for capturing photos or starting/stopping videos.

Adjustable Angle & 360° Rotation Phone Holder




Image 4.3: The detachable remote control being used to connect to a smartphone via Bluetooth. The phone screen confirms a successful connection to "SelfieShow".

4.4 Using the Detachable LED Fill Light

1. Attach the fill light to the designated slot on the phone holder.
2. Press the power button on the fill light to turn it on.
3. Press the button repeatedly to cycle through the 3 color modes (White, Natural, Warm) and 2 brightness levels for each mode.
4. To charge the fill light, connect it to a USB power source using the provided USB charging cable.

3 Lighting Mode & 6 Brightness Levels




Image 4.4: Demonstration of the three lighting modes (White, Natural, Warm) and their respective brightness levels provided by the detachable LED fill light.

5. OPERATING INSTRUCTIONS

5.1 Using as a Selfie Stick

For handheld use, ensure the tripod legs are folded securely into the handle. Extend the rod to your desired length and hold the handle firmly. Use the wireless remote to capture photos or videos.

5.2 Using as a Tripod

Extend the tripod legs fully on a flat, stable surface. Adjust the rod height and phone holder angle as needed. For optimal stability, ensure the legs are spread wide and the center of gravity is balanced, especially with heavier phones or when fully extended.

5.3 Adjusting Angles and Orientation

The phone holder allows for 360° rotation and 225° neck adjustment. Loosen the locking knob (if applicable), adjust your phone to horizontal or vertical orientation, and tilt it to the desired angle. Tighten the knob to secure the position.

5.4 Capturing Photos and Videos

Once your phone is securely mounted and the remote is paired, open your phone's camera application. Press the button on the wireless remote control to take a photo or start/stop video recording.

6. MAINTENANCE

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the selfie stick tripod in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery:** Replace the remote control battery when its performance diminishes. Recharge the fill light regularly.
- **Avoid Water:** This product is not waterproof. Avoid exposure to water or high humidity.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote control not pairing.	Remote battery low or dead; Bluetooth not enabled on phone; remote not in pairing mode.	Replace remote battery. Ensure phone Bluetooth is on. Press and hold remote button to enter pairing mode.
Remote control not taking photos.	Not paired; camera app not open; phone settings issue.	Verify pairing. Open camera app. Check phone camera settings for volume button shutter function.
Tripod is unstable.	Legs not fully extended; uneven surface; phone too heavy or off-center.	Ensure legs are fully spread. Place on a flat, stable surface. Center the phone in the holder. Avoid extending to maximum height with heavy phones.
Fill light not turning on/charging.	Battery depleted; charging cable faulty; light switch off.	Charge the fill light using the provided USB cable. Ensure the light's power switch is on.

8. SPECIFICATIONS

- **Model:** Q02S
- **Material:** Stainless Steel
- **Folded Length:** 7.6 inches (19.4 cm)
- **Extended Length:** Up to 41.7 inches (106 cm)
- **Item Weight:** 5.8 ounces (164 grams)
- **Phone Holder Width:** 2.5 - 3.6 inches (6.5 - 9.2 cm)
- **Rotation:** 360° (phone holder), 225° (neck)
- **Fill Light:** 3 Color Modes (White, Natural, Warm), 2 Brightness Levels
- **Remote Control:** Bluetooth compatible (iOS 5.1+ / Android 4.4+)
- **Battery (Remote):** 1 Lithium Metal battery (included)
- **Battery (Fill Light):** Rechargeable (USB charging)

9. SAFETY INFORMATION

- Do not disassemble or modify the product.
- Keep out of reach of children.
- Avoid exposing the device to extreme temperatures, direct sunlight, or fire.
- Do not use in wet conditions or immerse in water.
- Ensure your phone is securely mounted before use to prevent drops.
- When using as a tripod, place on a stable, level surface to prevent tipping.

10. WARRANTY AND SUPPORT

SelfieShow products are designed for reliability and performance. For warranty information, technical support, or customer service inquiries, please refer to the contact information provided on the product packaging or visit the official SelfieShow website.

Manufacturer: LDP

© 2023 SelfieShow. All rights reserved.

Related Documents - Q02S

	<p><u>SelfieShow Extendable Selfie Stick Tripod with Wireless Remote - User Guide</u></p> <p>Comprehensive guide to the SelfieShow extendable selfie stick tripod, featuring a wireless remote, portable monopod design, and wide smartphone compatibility for iPhone, Samsung, and Huawei devices.</p>
---	---