

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [COVERT SCOUTING CAMERAS](#) /
- › [COVERT SCOUTING CAMERAS WC20-V \(Verizon Wireless\) 4G LTE Cellular Game & Trail Camera for Hunting Deer and Wildlife – 20mp High-Res Images & 1080p Videos Transmitted to Mobile App, CC0012](#)

COVERT SCOUTING CAMERAS CC0012

COVERT SCOUTING CAMERAS WC20-V User Manual

Model: CC0012 | Brand: COVERT SCOUTING CAMERAS

INTRODUCTION

This manual provides comprehensive instructions for setting up, operating, and maintaining your COVERT SCOUTING CAMERAS WC20-V. Designed for hunting, wildlife monitoring, and property surveillance, this 4G LTE cellular game and trail camera captures high-resolution images and 1080p videos, transmitting previews directly to your mobile app. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.

PRODUCT OVERVIEW



Front view of the Covert WC20-V cellular game camera, showing the lens, sensors, and attached antenna.



Back view of the Covert WC20-V cellular game camera, highlighting the mounting strap loops.



Inside view of the Covert WC20-V cellular game camera, revealing the battery compartments and control panel with screen and buttons.

The Covert WC20-V is a compact and robust cellular game camera. It features a durable casing, an external antenna for reliable cellular connectivity, and an intuitive internal control panel. The camera is designed for outdoor use, capable of capturing high-quality images and videos in various environmental conditions.

SETUP GUIDE

- Battery Installation:** The WC20-V requires 12 AA batteries (not included). Open the camera casing and insert the batteries into the designated slots, ensuring correct polarity.



A user inserting AA batteries into the camera's internal battery compartment.

- SD Card Insertion:** Insert an SD card (up to 32GB, not included) into the SD card slot. This is where high-resolution images and 1080p videos will be stored locally.
- Antenna Attachment:** Screw the provided antenna securely into the antenna port on top of the camera.
- Power On:** Turn the camera on using the power switch located on the control panel.
- Mobile App Integration & QR Code Setup:**
Download the Covert Web Portal mobile app. The camera features a QR code setup for easy installation. Scan the QR code displayed on the camera's internal screen or provided in the packaging using the app to link your device and configure cellular settings. This allows for remote monitoring and setting adjustments.
- Mounting the Camera:** Use the included tree strap to securely mount the camera to a tree or other stable surface. Ensure the camera is positioned to capture the desired area.



The camera securely mounted to a tree using the provided strap, ready for operation.



A person making final adjustments to the camera's position after mounting it on a tree.

OPERATING INSTRUCTIONS

- Trigger Speed:** The camera features an ultra-sensitive 0.3-second trigger speed, ensuring quick capture of moving subjects.
- Detection and Flash Range:** It boasts an 80-foot detection range and a 100-foot flash range. The "No Glow" flash technology ensures that game or subjects are not spooked by visible light during night captures.
- Image and Video Capture:** The camera captures 20MP high-resolution images and 1080p videos. Previews of these captures are transmitted to the Covert Web Portal and mobile app.
- Silent Image Capture:** Utilize the "Maximum Silence" image capture feature for discreet operation, minimizing disturbance to wildlife.
- Turbo Shot Burst Mode:** The camera supports a 1 to 3 turbo shot burst mode, allowing for multiple rapid captures when motion is detected.
- Data Overlay:** Photos are automatically stamped with time, date, temperature, and moon phase information.
- Remote Access:** Once set up with the mobile app, you can remotely check the camera's status, view transmitted previews, and adjust settings from your smartphone.

MAINTENANCE

- Battery Replacement:** Regularly check battery levels via the mobile app or the camera's 1.5" setting screen. Replace all 12 AA batteries when low to ensure continuous operation.
- SD Card Management:** Periodically check the SD card capacity. Format or replace the SD card as needed to prevent storage issues. Always power off the camera before removing or inserting the SD card.
- Cleaning:** Gently wipe the camera lens and sensors with a soft, lint-free cloth to remove dirt or debris. Ensure the

casing is free from obstructions.

- **Environmental Protection:** While designed for outdoor use, avoid prolonged exposure to extreme weather conditions if possible. Ensure all latches are securely closed to maintain water resistance.

TROUBLESHOOTING

- **No Power:** Ensure batteries are correctly inserted with proper polarity and are fully charged. Check if the power switch is in the "ON" position.
- **No Images/Videos Captured:** Verify that the SD card is properly inserted and has sufficient free space. Check motion sensor settings and ensure the camera is positioned correctly within the detection range.
- **No Cellular Transmission:** Confirm that the camera has cellular data service (Verizon or AT&T) and that the antenna is securely attached. Check signal strength in the camera's location. Ensure the camera is correctly linked to your mobile app via QR code setup.
- **Poor Image/Video Quality:** Clean the camera lens and sensors. Ensure there are no obstructions in front of the camera. Check lighting conditions and adjust camera settings if necessary.
- **App Connectivity Issues:** Ensure your mobile device has a stable internet connection. Restart the app and the camera. Verify that the camera's cellular service is active.

SPECIFICATIONS

Feature	Detail
Model Name	CC0012
Brand	COVERT SCOUTING CAMERAS
Effective Still Resolution	20 MP
Video Capture Resolution	1080p
Trigger Speed	0.3 seconds
Detection Range	80 feet
Flash Range	100 feet (No Glow)
Power Source	12 AA Batteries (not included)
SD Card Compatibility	Up to 32GB (not included)
Connectivity Technology	Wireless (4G LTE, Wi-Fi for app control)
Compatible Devices	Smartphone (Android controller type mentioned, implies iOS too)
Dimensions (L x W x H)	8.5 x 4 x 6 inches
Item Weight	1.34 pounds
Mounting Type	Tree Mount
Special Feature	Motion Sensor
International Protection Rating	IP54

OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.


This video provides a comprehensive overview of the Covert Scouting Cameras WC20-V, demonstrating its features, setup, and key functionalities for effective game and trail monitoring.


WARRANTY AND SUPPORT

Please note that this product comes with **No Warranty** as per manufacturer specifications. For any technical support or inquiries, please refer to the contact information provided with your product packaging or visit the official COVERT SCOUTING CAMERAS website.

© 2023 COVERT SCOUTING CAMERAS. All rights reserved.

Related Documents - CC0012

	<p>Covert WC20-A/WC20-V Scouting Camera Instruction Manual Comprehensive instruction manual for the Covert WC20-A and WC20-V scouting cameras, covering setup, features, settings, tips, warranty, and FCC compliance.</p>
	<p>iZEEKER iG200 Trail Camera User Manual User manual for the iZEEKER iG200 Trail Camera, covering setup, operation, menu settings, and mounting instructions.</p>
	<p>Cabela's Cellular Trail Camera User Guide: Setup, Operation, and Troubleshooting Comprehensive user guide for the Cabela's Cellular Trail Camera, covering setup, app usage, best practices for placement and battery performance, troubleshooting common issues, and technical specifications. Learn how to install, activate, and maintain your trail camera for optimal wildlife monitoring.</p>
	<p>SPYPOINT LINK-MICRO-LTE User Manual: Setup, Features, and Operation Comprehensive user manual for the SPYPOINT LINK-MICRO-LTE cellular trail camera. Learn about its features, installation, configuration, troubleshooting, and warranty information to enhance your outdoor photography and wildlife monitoring.</p>



[Browning Defender Pro Scout Max 4G LTE Cell Camera Instruction Manual](#)

Detailed instruction manual for the Browning Defender Pro Scout Max 4G LTE cellular trail camera. Covers camera setup, installation of batteries and SD cards, account creation for the Strike Force Wireless app, quick cellular testing, basic operation, advanced settings, warranty information, and FCC compliance. Includes a comprehensive overview of mobile app features for managing and viewing captured media.



[Stealth Cam STC-GXATW Instruction Manual: Setup, Features, and Operation](#)

This comprehensive instruction manual provides detailed guidance for the Stealth Cam STC-GXATW digital scouting camera. Learn about camera setup, operational modes (PIR Photo, Time Lapse, PIR Video), advanced settings, cellular connectivity, app integration, memory card and battery management, troubleshooting FAQs, and warranty information.