

[Manuals.plus](#) /

> [LEYF](#) /

> LEYF PA-2211 DVB-T2 Full HD 1080p Digital Terrestrial Receiver User Manual

LEYF PA-2211

LEYF PA-2211 DVB-T2 Digital Terrestrial Receiver User Manual

Model: PA-2211 | Brand: LEYF

INTRODUCTION

The LEYF PA-2211 is a Full HD 1080p DVB-T2 Digital Terrestrial Receiver designed to provide an enhanced viewing experience. This manual provides essential information for setting up, operating, and maintaining your device. Please read these instructions carefully before use.



Image: Front view of the LEYF PA-2211 Digital Terrestrial Receiver, showing the display and front panel buttons.

PACKAGE CONTENTS

Ensure all items are present in the package:

- 1x LEYF PA-2211 Digital Terrestrial Receiver
- 1x Remote Control
- 1x User Manual (this document)
- 1x Power Adapter
- (Optional: HDMI Cable, depending on variant)

Stadium quality match enjoyment at home



Image: The LEYF PA-2211 receiver, remote control, and product packaging.

SETUP INSTRUCTIONS

- Unpacking and Placement:** Carefully remove the receiver from its packaging. Place the receiver on a stable, flat surface near your television. Ensure adequate ventilation around the device.
- Remove Protective Film:** Before use, gently peel off any protective film from the device's display or casing.



Image: Close-up of the LEYF PA-2211 receiver with a protective film being removed from the front panel.

3. **Connect Antenna:** Connect your DVB-T2 compatible antenna cable to the "ANT IN" port on the back of the receiver.
4. **Connect to TV:**
 - For High Definition (HD) connection: Use an HDMI cable to connect the receiver's "HDMI" port to an available HDMI input on your TV.
 - For Standard Definition (SD) connection: Use a SCART cable to connect the receiver's "SCART" port to the SCART input on your TV.
5. **Connect Power:** Plug the power adapter into the "DC-IN" port on the receiver, then plug the adapter into a wall outlet.
6. **Initial Power On:** Turn on your TV and select the correct HDMI or SCART input source. The receiver should power on automatically or can be turned on using the remote control.
7. **First Time Installation:** Follow the on-screen prompts for the first-time installation wizard. This typically includes language selection, country, and automatic channel scanning. The signal level indicator can assist with antenna positioning for optimal reception.



Image: Rear view of the LEYF PA-2211 receiver, showing ANT IN, LOOP OUT, COAXIAL, HDMI, SCART, and DC-IN ports.

OPERATING INSTRUCTIONS

Remote Control Functions

The remote control provides full functionality for your LEYF PA-2211 receiver.

Leyf PA-2211

HDMI™
HIGH-DEFINITION MULTIMEDIA INTERFACE



1080P
FULL HD

1000 Channel



Image: The LEYF PA-2211 remote control shown next to the receiver, highlighting its buttons and layout.

- **POWER:** Turns the receiver on or off.
- **MENU:** Accesses the main menu for settings and features.
- **OK:** Confirms selections or displays channel list.
- **CH+/CH-:** Changes channels.
- **VOL+/VOL-:** Adjusts volume.
- **EPG:** Displays the Electronic Program Guide.
- **TTX:** Activates Teletext.
- **FAV:** Accesses favorite channel lists.
- **USB:** Switches to USB media playback mode.
- **INFO:** Displays current channel information.

Channel Management

- **Automatic Channel Scan:** During initial setup, the receiver will automatically scan for available channels.
- **Manual Channel Scan:** If some channels are missing, you can perform a manual scan through the menu settings.
- **Editing Channel List:** You can reorder, delete, or skip channels from the channel list menu.
- **Favorite Channels:** Create and manage multiple favorite channel lists for quick access to your preferred programs.

Media Playback (USB)

The LEYF PA-2211 supports playback of various media files from a USB storage device.

1. Insert a USB flash drive into the USB port on the front of the receiver.
2. Press the "USB" button on the remote control or navigate to the media player section in the main menu.
3. Select the type of media you wish to play (JPEG for images, MP3 for music, MKV for videos).
4. Browse your files and select the desired content for playback.

Supported formats include 1080i, 1080p, 720p for video resolutions, JPEG for images, MP3 for music, and MKV for movies.

Parental Control

The receiver includes advanced locking systems for system settings, configuration, parental control, and channels to create a secure viewing environment. Access these settings via the main menu to set up passwords and restrictions.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the receiver. Do not use liquid cleaners or abrasive materials.
- **Ventilation:** Ensure the ventilation slots on the top and sides of the receiver are not blocked to prevent overheating.
- **Software Updates:** While information on guaranteed software updates is not available, check the manufacturer's website periodically for any potential firmware updates that may improve performance or add features. The flash memory is designed to protect against faulty software installations.
- **Power Outage Protection:** The device is designed to store and protect up to 1000 channels in case of a power outage.

TROUBLESHOOTING

If you encounter issues with your LEYF PA-2211 receiver, refer to the following common solutions:

Problem	Possible Cause	Solution
No power / Device not turning on	Power cable disconnected; Power outlet faulty; Remote control batteries low.	Check power cable connection; Try a different power outlet; Replace remote control batteries.
No signal / "No Signal" message on TV	Antenna not connected or misaligned; Incorrect TV input selected; Channel scan not performed.	Ensure antenna is securely connected to "ANT IN"; Adjust antenna position using signal indicator; Select correct HDMI/SCART input on TV; Perform an automatic or manual channel scan.

Problem	Possible Cause	Solution
Missing channels after automatic scan	Some channels may not be found by automatic scan; Weak signal for certain frequencies.	Perform a manual channel scan for specific frequencies; Adjust antenna direction; Consider a stronger antenna or signal amplifier.
No audio or poor audio quality	Volume too low; Audio cables loose; Incorrect audio settings.	Increase volume on receiver and TV; Check HDMI/SCART cable connections; Verify audio output settings in the receiver's menu.
Remote control not working	Batteries depleted or incorrectly inserted; Obstruction between remote and receiver; Remote sensor blocked.	Replace batteries, ensuring correct polarity; Remove any objects blocking the line of sight; Clean the remote control sensor on the receiver.

SPECIFICATIONS

Feature	Detail
Model Number	PA-2211
Brand	LEYF
Connectivity Technology	Wi-Fi (Note: Requires compatible Wi-Fi adapter, not included)
Video Encoding	MKV (for media playback)
Audio Output Mode	Surround
Surround Sound Channel Configuration	5.1
Special Feature	Motion Detector (Functionality details not specified, refer to device menu)
Compatible Devices	YouTube (Requires Wi-Fi connectivity)
Total HDMI Ports	1
Connector Type	USB
Controller Type	Remote Control
Display Resolutions	1080i, 1080p, 720p
Channel Storage	Up to 1000 channels
Menu Languages	10 languages
Manufacturer	LEYF
Country of Origin	Turkey

WARRANTY AND SUPPORT

For warranty information, please refer to the terms and conditions provided at the point of purchase. Typically, products purchased from Amazon.com.be may be eligible for a 30-day return/replacement policy.

Information regarding the availability of spare parts and guaranteed software updates is not available. For technical support or further assistance, please contact your retailer or refer to the official LEYF support channels if available.



This manual is for informational purposes only. LEYF reserves the right to make changes to the product without prior notice.