Probrico DLS07

Probrico DLS07 Brushed Nickel Privacy Door Knob Instruction Manual

Model: DLS07

1. Product Overview

The Probrico DLS07 Privacy Door Knob is designed for interior doors where privacy is required, such as bedrooms and bathrooms. Featuring a modern brushed nickel finish and durable stainless steel construction, this round handle knob meets ANSI Grade 3 standards, exceeding 200,000 cycles for reliable performance. It includes an emergency release function for unlocking from the outside.



Image: Probrico DLS07 Brushed Nickel Privacy Door Knob, ideal for interior doors requiring privacy.

2. Package Contents

Verify that all components are present before beginning installation:

- Door Knob Assembly (Interior and Exterior Knobs)
- Adjustable Latch
- Strike Plate
- Mounting Screws
- Emergency Release Tool (or instructions for using a coin/flathead screwdriver)
- Installation Instructions



Image: All components of the Probrico DLS07 door knob set.

3. Specifications

Feature	Specification
Material	Stainless Steel
Finish	Brushed Nickel
Lock Type	Privacy (Thumb Turn Button)
Emergency Release	Yes (via coin or flathead screwdriver)
Door Thickness Compatibility	1-1/4 inch to 1-3/4 inch (35mm to 45mm)
Adjustable Latch	2-3/8 inch (60mm) or 2-3/4 inch (70mm)
Knob Diameter	2.09 inch (53mm)
Rosette Diameter	2.56 inch (65mm)
Hand Orientation	Universal (fits both right and left-handed doors)
ANSI Grade	Grade 3




Image: Detailed dimensions of the Probrico DLS07 door knob components.

4. Installation Instructions

The Probrico DLS07 door knob is designed for easy installation with basic tools. Follow these steps for a successful setup:

1. **Prepare the Door:** Ensure your door has standard bore holes and is between 1-1/4 inch and 1-3/4 inch thick.
2. **Adjust the Latch:** The steel adjustable latch can be set to either 2-3/8 inch (60mm) or 2-3/4 inch (70mm) backset. Adjust as needed for your door.
3. **Install the Latch:** Insert the latch into the door edge hole and secure it with the provided screws. Ensure the latch bolt faces the door frame.
4. **Install the Exterior Knob:** Place the exterior knob assembly through the door, aligning the spindle with the latch mechanism.
5. **Install the Interior Knob:** Remove the two preinstalled machine screws from the interior knob handle. Place the interior knob assembly over the exterior knob's spindle and secure it using the removed screws. Ensure the knobs are flush against the door surface.

6. **Install the Strike Plate:** Attach the strike plate to the door frame, aligning it with the latch bolt. Secure with screws.
7. **Test Operation:** Close the door and test the locking and unlocking mechanism from both sides to ensure smooth operation.



Image: Easy installation of the Probrico DLS07 door knob with a screwdriver.




Image: Adjustable latch mechanism for different door backsets.



Image: Door thickness compatibility for the Probrico DLS07 door knob.

5. Operation

The Probrico DLS07 door knob provides privacy with a simple locking mechanism.

- **Locking:** From the inside, press or turn the thumb turn button on the interior knob to engage the lock.
- **Unlocking:** From the inside, turn the thumb turn button to disengage the lock. From the outside, use an emergency release tool (or a coin/flathead screwdriver) inserted into the slot on the exterior knob to unlock the door.



Image: Privacy function details, showing internal locking and external emergency release.

6. Maintenance

To ensure the longevity and smooth operation of your Probrico DLS07 door knob, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the knobs regularly with a soft, damp cloth to remove dust and fingerprints. Avoid abrasive cleaners or harsh chemicals, as these can damage the brushed nickel finish.
- **Lubrication:** Periodically apply a small amount of silicone-based lubricant to the latch mechanism

and the interior moving parts to maintain smooth operation. Do not use oil-based lubricants, as they can attract dust and debris.

- **Tightening:** Check the mounting screws periodically and tighten them if necessary to prevent wobbling or looseness.

7. Troubleshooting

If you encounter any issues with your Probrico DLS07 door knob, refer to the following troubleshooting tips:

- **Knob is Loose:** Tighten the mounting screws located on the interior rosette. If the screws are stripped, they may need to be replaced.
- **Latch Does Not Retract Smoothly:** Ensure the latch is properly aligned with the strike plate. Lubricate the latch mechanism with a silicone-based lubricant. Check for any obstructions in the door frame or latch bore.
- **Door Does Not Latch Properly:** Verify that the strike plate is correctly aligned with the latch bolt. Adjust the strike plate position if needed. Ensure the door frame is not warped.
- **Lock Mechanism Jams:** If the lock mechanism becomes difficult to operate, apply a small amount of silicone lubricant to the thumb turn and the emergency release slot. Ensure no debris is obstructing the mechanism. If the issue persists, the internal mechanism may be damaged and require replacement.
- **Emergency Release Not Working:** Ensure you are using an appropriate tool (coin or flathead screwdriver) and applying sufficient, steady pressure to turn the mechanism in the emergency release slot.

8. Warranty and Support

Probrico products are manufactured to high-quality standards. For warranty information, technical support, or replacement parts, please contact Probrico customer service through their official website or the retailer where the product was purchased. Please have your model number (DLS07) and purchase date available when contacting support.

© 2026 Probrico. All rights reserved.