

[Manuals.plus](#) /

› [Hape](#) /

› Hape 1635 Human Body Puzzle Instruction Manual

Hape E1635

Hape 1635 Human Body Puzzle Instruction Manual

INTRODUCTION

The Hape 1635 Human Body Puzzle is an educational toy designed to introduce children to human anatomy. This 60-piece jigsaw puzzle, accompanied by 10 wooden parts representing organs, muscles, and bones, helps children learn about the human body through interactive play. It also includes a double-sided poster with anatomical facts. This product is recommended for ages 4 years and up, fostering fine motor skills, hand-eye coordination, and problem-solving abilities.

SETUP

Follow these steps to set up your Hape Human Body Puzzle:

1. Unpack all 60 puzzle pieces and the 10 wooden anatomical parts from the packaging.
2. Begin by assembling the 60 jigsaw pieces on a flat, stable surface to form the full human body outline. Refer to the product image for guidance on the overall shape.






Image: The fully assembled 60-piece human body puzzle, ready for the anatomical parts.



Image: The product packaging, illustrating the puzzle and its components.

OPERATING

Once the main puzzle is assembled, you can begin exploring human anatomy:

1. Identify the 10 wooden parts, which include representations of the brain, heart, lungs, kidneys, stomach, intestines, and bones.
2. Place each wooden part onto its corresponding location on the puzzle. The puzzle's design provides visual cues for correct placement.
3. Utilize the included double-sided poster to learn facts about each body part. The poster provides detailed information on how different organs function and their importance.



Image: Children engaging with the puzzle, placing the wooden anatomical pieces.



Image: A close-up view of a hand placing a wooden bone piece onto the puzzle.





Image: The 10 wooden anatomical parts, including organs and bones.




Image: The educational poster, detailing various human body facts.

MAINTENANCE

Proper care will ensure the longevity of your puzzle:

- **Cleaning:** To clean the puzzle pieces and wooden parts, wipe them gently with a dry or slightly damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the materials.
- **Storage:** Store the puzzle in its original packaging or a dry, cool place away from direct sunlight and humidity. This helps prevent warping, fading, or damage to the wood and paper components.
- **Inspection:** Regularly inspect all pieces for wear and tear. If any parts become broken or damaged, discontinue use to prevent potential hazards, especially for younger children.

TROUBLESHOOTING

- **Missing Pieces:** In the event of missing puzzle pieces or wooden parts, please contact Hape customer support. Provide your product model number (E1635) and purchase details for assistance.
- **Difficulty Assembling:** Ensure all puzzle pieces are oriented correctly. The unique shapes of jigsaw pieces are designed to fit only in their designated spots. If a piece does not fit easily, do not force it. Refer to the product images or the included poster for visual guidance.

SPECIFICATIONS

Model Number	E1635
Number of Puzzle Pieces	60
Number of Wooden Parts	10
Material Type(s)	Wood, Paper
Recommended Age	4 years and up
Product Dimensions	100 x 50.01 x 2.31 cm
Educational Objective(s)	Motor skills, Hand-eye coordination, Problem-solving skills

WARRANTY AND SUPPORT

For detailed warranty information, product support, or to inquire about replacement parts, please refer to the official Hape website or contact your authorized retailer. It is advisable to retain your proof of purchase and the product model number (E1635) for any future inquiries.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question