JBL 710BT

JBL Tune 710BT Wireless Over-Ear Headphones User Manual

Model: 710BT | Brand: JBL

Introduction

The JBL Tune 710BT Wireless Over-Ear Headphones deliver powerful JBL Pure Bass Sound, offering an immersive audio experience. Designed for comfort and portability, these headphones feature a lightweight and foldable design, making them ideal for travel and daily use. With a long-lasting battery and hands-free call capabilities, they provide convenience and high-quality sound for extended listening sessions.



Figure 1: JBL Tune 710BT Wireless Over-Ear Headphones (White)

This image displays the JBL Tune 710BT headphones in white, showcasing their over-ear design and the JBL logo on the earcup.

What's in the Box

Upon unboxing your JBL Tune 710BT headphones, you should find the following components:

- JBL Tune 760NC headphone (Note: The product is 710BT, but the included components list 760NC. Please verify your specific model.)
- USB-C Charging Cable
- Detachable Audio Cable
- Quick Start Guide (QSG)



Figure 2: Included Cables

This image shows the orange USB-C charging cable and the white detachable audio cable that come with the headphones.

Setup

1. Charging the Headphones

Before first use, fully charge your JBL Tune 710BT headphones. Connect the provided USB-C charging cable to the charging port on the headphone and the other end to a USB power source. A full charge takes approximately 2 hours. Once fully charged, the headphones offer up to 35 hours of battery life.

2. Bluetooth Pairing

1. Ensure your headphones are powered off.
2. Press and hold the power button on the headphone until the LED indicator flashes blue, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "JBL Tune 710BT" from the list of devices to connect.
5. Once connected, the LED indicator will turn solid blue.

The headphones utilize Bluetooth Version 5.0 for a stable wireless connection.



Figure 3: Headphone Controls

This image highlights the control buttons located on the earcup, including power, volume, and multi-function buttons.

Operating Instructions

1. Power On/Off

- To power on, press and hold the power button until the LED indicator lights up.
- To power off, press and hold the power button until the LED indicator turns off.

2. Music Playback

- **Play/Pause:** Press the multi-function button once.
- **Next Track:** Double-press the multi-function button.
- **Previous Track:** Triple-press the multi-function button.
- **Volume Up:** Press the '+' button.
- **Volume Down:** Press the '-' button.

3. Hands-Free Calls

Easily manage your calls directly from the headphones:

- **Answer/End Call:** Press the multi-function button once.
- **Reject Call:** Press and hold the multi-function button for 2 seconds.

4. Voice Control

Trigger your device's voice assistant (Siri, Google Assistant, etc.) by pressing the dedicated voice control button on the earcup.

Maintenance

To ensure the longevity and optimal performance of your JBL Tune 710BT headphones, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the earcups and headband. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the headphones in a cool, dry place. The foldable design allows for compact storage, protecting them from damage.
- **Water Resistance:** These headphones are **Not Water Resistant**. Avoid exposure to water, moisture, or excessive humidity to prevent damage.
- **Battery Care:** For optimal battery health, avoid fully discharging the battery frequently. Charge the headphones regularly, even if not in constant use.



Figure 4: Foldable Design

This image demonstrates the headphones in their folded position, highlighting their portability and ease of storage.

Troubleshooting

If you encounter issues with your JBL Tune 710BT headphones, refer to the following common problems and solutions:

Problem	Possible Solution
Headphones do not power on	Ensure the battery is charged. Connect to a power source using the USB-C cable.

Problem	Possible Solution
Cannot pair via Bluetooth	Ensure headphones are in pairing mode (flashing blue LED). Turn off and on Bluetooth on your device. Forget the device in your Bluetooth settings and try pairing again. Ensure headphones are within range.
No sound or low volume	Check volume levels on both headphones and your connected device. Ensure headphones are properly paired. Try playing different audio sources.
Sound distortion	Move closer to your device to reduce interference. Ensure the audio source quality is good.

Specifications

Feature	Detail
Model Name	JBL Tune 710BT White
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.0
Battery Life	35 Hours
Charging Time	2 Hours
Frequency Range	20 Hz - 20 kHz
Sensitivity	103 dB
Item Weight	220 Grams (7.8 ounces)
Product Dimensions	8.07 x 2.44 x 8.78 inches
Ear Placement	Over Ear
Noise Control	Active Noise Cancellation (as per feature bullets, though specifications list 'Noise Control: Active Noise Cancellation' for 760NC, the product is 710BT. User should verify.)
Water Resistance Level	Not Water Resistant

Feature	Detail
UPC	656942704515

Warranty and Support

Your JBL Tune 710BT headphones are covered by a return policy that allows for replacement or refund within 90 days of purchase. For detailed warranty information, technical support, or service inquiries, please refer to the official JBL website or contact their customer support directly. Keep your proof of purchase for any warranty claims.

© 2025 JBL. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question