realme C35

realme C35 Smartphone User Manual

Model: C35

1. Introduction

Welcome to the user manual for your new realme C35 smartphone. This guide provides detailed instructions on how to set up, operate, maintain, and troubleshoot your device. Please read this manual thoroughly to ensure optimal performance and longevity of your realme C35.
The realme C35 is designed to offer a seamless mobile experience with its advanced features and user-friendly interface. For further assistance, please refer to the support section at the end of this manual.

2. Package Contents

Ensure all items are present in your product package:

- realme C35 Smartphone
- USB Cable
- Power Adapter
- SIM Ejector Tool
- Quick Start Guide
- Safety Information and Warranty Card

Note: Specific contents may vary by region.

3. Device Layout

Familiarize yourself with the physical components of your realme C35.



Figure 3.1: Front view of the realme C35 smartphone, showing the display, front camera, and earpiece.



Figure 3.2: Rear view of the realme C35 smartphone, highlighting the triple camera module and realme branding.

Key Components:

- **Front Camera:** Located at the top of the display for selfies and video calls.
- **Earpiece:** For audio during calls.

- **Display:** The main screen for interaction.
- **Volume Buttons:** On the side, to adjust media and call volume.
- **Power Button:** On the side, to turn the device on/off or lock/unlock the screen. May also integrate a fingerprint sensor.
- **SIM/SD Card Tray:** For inserting SIM cards and a microSD card.
- **USB Port:** For charging and data transfer.
- **3.5mm Audio Jack:** For connecting headphones.
- **Microphone:** For voice input during calls and recordings.
- **Speaker:** For audio output.
- **Rear Camera Module:** Contains multiple lenses and flash for photography and videography.

4. Setup

4.1. Installing SIM and SD Card

1. Locate the SIM card tray on the side of your realme C35.
2. Insert the SIM ejector tool into the small hole next to the tray and press gently until the tray pops out.
3. Place your Nano-SIM card(s) and/or microSD card into the designated slots on the tray, ensuring the gold contacts face downwards.
4. Carefully push the tray back into the phone until it is flush with the device's side.

4.2. Initial Power On and Basic Setup

1. Press and hold the **Power Button** until the realme logo appears on the screen.
2. Follow the on-screen prompts to select your language, region, and connect to a Wi-Fi network.
3. Sign in with your Google account or create a new one to access Google services and the Play Store.
4. Set up a screen lock (PIN, pattern, password, fingerprint, or face unlock) for security.
5. Review and accept the terms and conditions to complete the setup process.

4.3. Charging the Device

Connect the USB cable to the phone's USB port and the other end to the power adapter. Plug the adapter into a power outlet. The battery icon on the screen will indicate charging status. For optimal battery life, use the original charger and cable provided with your device.

5. Operating Your realme C35

5.1. Basic Navigation

- **Tap:** Touch an icon or option to open or select it.
- **Swipe:** Drag your finger across the screen to scroll through pages or content.
- **Pinch:** Use two fingers to zoom in or out on images and web pages.
- **Long Press:** Press and hold an item to reveal additional options or move it.

5.2. Making and Receiving Calls

- **To Make a Call:** Open the **Phone** app, enter the number using the dial pad, and tap the call icon. Alternatively, select a contact from your contacts list.
- **To Receive a Call:** When a call comes in, swipe up to answer or swipe down to decline.

5.3. Sending Messages

Open the **Messages** app, tap the "Start chat" or "+" icon, enter the recipient's number or select from contacts, type your message, and tap the send icon.

5.4. Using the Camera

Open the **Camera** app. Tap the shutter button to take a photo. Swipe left or right to switch between different modes like Video, Portrait, or Night. Tap the camera switch icon to toggle between front and rear cameras.

5.5. Internet Connectivity

- **Wi-Fi:** Go to **Settings > Network & internet > Wi-Fi** Turn Wi-Fi on, select a network, and enter the password if required.
- **Mobile Data:** Go to **Settings > Network & internet > Mobile network** Ensure Mobile data is turned on.

5.6. Applications

Download and install applications from the Google Play Store. To uninstall an app, long-press its icon on the home screen or app drawer, then select "Uninstall" or drag it to the uninstall option.

5.7. Security Features

Your realme C35 supports various security features. Navigate to **Settings > Security** to set up or manage:

- **Fingerprint Unlock:** Register your fingerprints for quick and secure unlocking.
- **Face Unlock:** Use your face to unlock the device.
- **Screen Lock:** PIN, Pattern, or Password.

6. Maintenance

6.1. Cleaning Your Device

Use a soft, lint-free cloth to gently wipe the screen and body of your phone. Avoid using harsh chemicals, abrasive materials, or excessive moisture, as these can damage the device. Disconnect all cables before cleaning.

6.2. Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements. Go to **Settings > About phone > Software update** to check for available updates. Ensure your device is sufficiently charged and connected to Wi-Fi before initiating an update.

6.3. Battery Care

- Avoid exposing the phone to extreme temperatures.
- Do not let the battery completely drain frequently.
- Use the original charger and cable for optimal charging.
- Unplug the charger once the battery is fully charged.

7. Troubleshooting

This section addresses common issues you might encounter with your realme C35.

Issue	Possible Solution

Issue	Possible Solution
Phone does not turn on.	Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again. If unresponsive, try a forced restart by holding the Power button for 10-15 seconds.
Screen is unresponsive.	Restart the device. If the issue persists, try a factory reset (*Note: This will erase all data*).
Cannot connect to Wi-Fi/Mobile Data.	Check if Wi-Fi or Mobile Data is enabled in Settings. Restart your router for Wi-Fi issues. Ensure your SIM card is properly inserted and has an active plan for mobile data.
Battery drains quickly.	Reduce screen brightness, close unused apps running in the background, disable unnecessary notifications, and limit location services. Check battery usage in Settings to identify power-hungry apps.
Apps are crashing or freezing.	Clear the cache and data of the problematic app via**Settings > Apps > [App Name] > Storage** Ensure the app and your phone's software are up to date.

If you encounter issues not listed here or if the suggested solutions do not resolve the problem, please contact realme customer support.

8. Specifications

Key technical specifications for the realme C35 smartphone:

Feature	Detail
Model	realme C35
Operating System	Android 11.0
RAM	4 GB
Internal Storage	64 GB
Battery Capacity	5000 mAh
Dimensions (LxWxH)	16.4 x 7.5 x 0.8 cm
Weight	450 g
Connectivity	Bluetooth, Wi-Fi
Audio Jack	3.5 mm
Manufacturer	Oppo Mobiles India Private Limited
First Available	15 March 2022

9. Safety Information

Please read the following safety information carefully to prevent injury or damage to your device:

- Do not use the device in extremely hot or cold environments.
- Avoid exposing the device to direct sunlight or heat sources.
- Keep the device dry and away from liquids.
- Use only realme-approved chargers and accessories.
- Do not attempt to disassemble, repair, or modify the device yourself.
- Dispose of the device and its battery responsibly according to local regulations.
- Avoid using the phone while driving or engaging in activities that require full attention.

10. Warranty and Support

Your realme C35 is covered by a limited manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including warranty period and coverage details.
For technical support, service, or further inquiries, please visit the official realme support website or contact their customer service hotline. You can find contact information on the realme official website or in the warranty documentation.
Online Support: www.realme.com/support

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question