

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [UrbanX](#) /

› [UrbanX Ultra-Slim Bluetooth Rechargeable Keyboard User Manual](#)

UrbanX UX030

UrbanX Ultra-Slim Bluetooth Rechargeable Keyboard User Manual

Model: UX030



INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your UrbanX Ultra-Slim Bluetooth Rechargeable Keyboard. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

The UrbanX Ultra-Slim Bluetooth Rechargeable Keyboard is designed for seamless connectivity with a wide range of Bluetooth-enabled devices, including iPads, iPhones, Android tablets, smartphones, and Windows PCs. Its compact and lightweight design makes it ideal for portable use.

PRODUCT OVERVIEW



The UrbanX Ultra-Slim Bluetooth Rechargeable Keyboard in Jade Green, showcasing its full QWERTY layout and compact design.

Light · Slim · Portable



Dimensions of the keyboard: 24.7cm (9.72in) length, 15cm (6in) width, and 0.5cm (0.2in) thickness, weighing 6.402 ounces, highlighting its light, slim, and portable nature.

Mini Size

Similar Size As iPad Air



The keyboard's mini size, shown alongside an iPad Air, demonstrating its similar compact footprint for easy portability.

Supports 3 Operating Systems

iOS / Android / Windows



The keyboard supports three major operating systems: iOS, Android, and Windows, indicated by their respective logos, ensuring broad compatibility.



Comfortable Keystrokes

X structure, exert equal pressure and lower keystrokes in comparison with the clickety keyboard.

Detail of the keyboard's comfortable keystrokes, featuring an X-structure design that ensures equal pressure and lower keystroke noise compared to clicky keyboards.

SPECIFICATIONS

Feature	Detail
Model Number	UX030
Bluetooth Edition	Bluetooth 3.0 and support latest Bluetooth 5.2
Dimensions (L x W x H)	285 x 120 x 6 mm (11.2 x 4.7 x 0.2 inches)
Weight	217g (7.65 oz) / 10 ounces (as per product specifications)

Number of Keys	78 keys (including 13 iPad hot keys)
Operating Range	Up to 10 meters (33 feet)
Material	Superior plastic
Battery Type	Rechargeable Li-On battery (included)
Battery Life	Up to 4 months between charges (based on 2 hours' non-stop use per day)
Compatible Operating Systems	iOS, Android, Mac OS, Windows (Hot Keys may not work 100% on Windows)
Color	Jade Green

SETUP AND PAIRING

Charging the Keyboard

Before first use, ensure the keyboard is fully charged. Connect the included charging cable to the keyboard's charging port and to a USB power source. The charging indicator light will illuminate during charging and turn off when fully charged.

Pairing with Your Device

- Power On:** Locate the ON/OFF switch on the keyboard and slide it to the "ON" position. The power indicator light will briefly illuminate.
- Activate Pairing Mode:** Press the "**Connect**" button on the keyboard. The Bluetooth indicator light will start blinking, indicating the keyboard is in pairing mode.
- Enable Bluetooth on Your Device:** On your tablet, smartphone, or computer, go to the Bluetooth settings.
- Search for Devices:** Your device will scan for available Bluetooth devices. Look for "Bluetooth Keyboard" or a similar name in the list of discovered devices.
- Select and Pair:** Select the keyboard from the list. Your device may prompt you to enter a pairing code displayed on your screen. Type this code on the UrbanX keyboard and press **Enter**.
- Confirmation:** Once successfully paired, the Bluetooth indicator light on the keyboard will stop blinking and remain solid or turn off, depending on the model. Your device will also confirm the connection.

Note: The keyboard will automatically attempt to reconnect to the last paired device when powered on. If you wish to pair with a new device, you may need to unpair it from the previous device first or ensure Bluetooth is off on the previously connected device.

OPERATING INSTRUCTIONS

Keyboard Layout and Hot Keys

The keyboard features a US QWERTY layout with 78 keys, including dedicated hot keys for iPad functionality. These hot keys provide quick access to functions such as volume control, media playback, and screen brightness.

- Function Keys (Fn):** To use the special functions printed on the F1-F12 keys, press and hold the **Fn** key simultaneously with the desired function key.
- Operating System Switching:** The keyboard supports iOS, Android, and Windows. To optimize hot key functionality for your specific operating system, use the dedicated OS keys (e.g., **Fn + Q** for iOS, **Fn + W** for Android, **Fn + E** for

Windows).

- **Caps Lock:** The Caps Lock indicator light will illuminate when Caps Lock is active.

Power Saving Mode

To conserve battery life, the keyboard will automatically enter power-saving mode after 10 minutes of inactivity. To wake the keyboard, press any key and wait for 2-3 seconds for it to reconnect to your device.

Typing Experience

The keyboard features whisper-quiet, low-profile keys with an X-structure design, providing a comfortable and responsive typing experience. This design ensures equal pressure distribution and reduced noise compared to traditional clicky keyboards.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the keyboard surface. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- **Storage:** When not in use for extended periods, turn off the keyboard to preserve battery life. Store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Liquids:** Do not expose the keyboard to liquids. In case of accidental spills, immediately turn off the keyboard and allow it to dry completely before attempting to use it again.
- **Handle with Care:** Avoid dropping the keyboard or subjecting it to strong impacts, as this may damage internal components.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Keyboard does not power on.	Battery is depleted.	Charge the keyboard using the provided USB cable.
Keyboard does not pair with device.	Bluetooth is not enabled on device; keyboard not in pairing mode; device already paired with another keyboard; interference.	Ensure Bluetooth is enabled on your device. Press the "Connect" button on the keyboard to enter pairing mode. Turn off Bluetooth on other nearby devices. Try restarting both the keyboard and your device.
Keyboard disconnects frequently.	Low battery; too far from device; interference.	Recharge the keyboard. Ensure the keyboard is within 10 meters (33 feet) of your device. Move away from other wireless devices that may cause interference.
Keys are unresponsive or typing errors occur.	Keyboard in power-saving mode; software glitch; physical obstruction.	Press any key to wake the keyboard. Restart your device. Check for any debris under the keys and clean if necessary.
Hot keys not working correctly on Windows.	Limited compatibility with Windows hot keys.	As noted in specifications, some hot keys may not function 100% on Windows. This is expected behavior.

WARRANTY AND SUPPORT

The UrbanX KB030 Bluetooth Keyboard comes with a **90-day warranty**. For any product-related inquiries, technical support, or warranty claims, please contact UrbanX customer service. Refer to the welcome guide included in your package for specific contact details or visit the official UrbanX website.

Package Contents:

- UrbanX KB030 Bluetooth Keyboard
- Charging Cable
- Welcome Guide



© 2024 UrbanX. All rights reserved.