

T-DAGGER TGS600

T-DAGGER TGS600 X-Ray RGB Gaming Soundbar User Manual

Model: TGS600 | Brand: T-DAGGER

1. INTRODUCTION

Thank you for choosing the T-DAGGER TGS600 X-Ray RGB Gaming Soundbar. This soundbar is designed to enhance your audio experience with high-quality stereo sound and dynamic RGB lighting. This manual provides essential information for setting up, operating, and maintaining your device to ensure optimal performance and longevity.

2. SAFETY INFORMATION

Please read all safety instructions carefully before using the product. Keep this manual for future reference.

- Do not expose the device to water or excessive moisture.
- Avoid placing the device near heat sources or in direct sunlight.
- Do not attempt to disassemble or repair the device yourself. Refer all servicing to qualified personnel.
- Use only the power source specified for this device.
- Keep out of reach of children.
- Ensure proper ventilation around the soundbar during operation.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- T-DAGGER TGS600 X-Ray RGB Gaming Soundbar
- Integrated USB Power Cable
- Integrated 3.5mm Audio Cable
- User Manual (this document)

4. PRODUCT OVERVIEW

Familiarize yourself with the components of your TGS600 Soundbar.



Figure 4.1: Front view of the T-DAGGER TGS600 Soundbar, showcasing the speaker grilles, the central volume knob with green illumination, and the vibrant RGB lighting strips on either side.




Figure 4.2: Top-down view of the T-DAGGER TGS600 Soundbar, highlighting the sleek design and the placement of the volume control in the center.



Figure 4.3: Angled top view of the T-DAGGER TGS600 Soundbar, providing a perspective of its compact form factor and integrated RGB lighting elements.



Figure 4.4: Rear view of the T-DAGGER TGS600 Soundbar, showing the integrated USB power cable and 3.5mm audio cable extending from the back panel.

5. SETUP

Follow these steps to set up your TGS600 Soundbar:

1. **Placement:** Place the soundbar on a stable, flat surface, such as a desk or TV stand, ensuring it is close to your audio source (PC, laptop, TV, etc.).
2. **Connect Audio:** Plug the 3.5mm audio jack from the soundbar into the audio output port (headphone jack) of your device.
3. **Connect Power:** Plug the USB-A connector from the soundbar into an available USB port on your computer, laptop, or a USB wall adapter (5V/1A recommended). The soundbar will power on and the RGB lighting will illuminate.
4. **Adjust Volume:** Turn the volume knob on the front of the soundbar clockwise to increase the volume. Adjust the volume on your connected device as needed.

6. OPERATING INSTRUCTIONS

The TGS600 Soundbar is designed for simple operation.

- **Power On/Off:** The soundbar powers on automatically when the USB cable is connected to a powered USB port. Disconnect the USB cable to power off.
- **Volume Control:** The large knob on the front of the soundbar controls the master volume. Rotate it clockwise to increase volume and counter-clockwise to decrease volume.
- **RGB Lighting:** The soundbar features integrated RGB lighting that activates automatically when powered on, providing an aesthetic enhancement to your setup. The lighting pattern is fixed and not user-adjustable.
- **Audio Source:** Ensure your connected device's audio output is set to the correct port where the soundbar is connected.

7. MAINTENANCE

Proper care will ensure the longevity of your soundbar.

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the soundbar. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use for extended periods, store the soundbar in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid bending or crimping the integrated cables excessively to prevent damage.

8. TROUBLESHOOTING

If you encounter issues with your TGS600 Soundbar, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound	• Audio cable not fully connected. • Volume too low on soundbar or source device. • Incorrect audio output selected on source device. • USB power not connected or insufficient.	• Ensure 3.5mm audio jack is securely plugged in. • Increase volume on both the soundbar and the source device. • Verify the correct audio output is selected in your device's sound settings. • Ensure USB cable is connected to a working USB port providing sufficient power.
No power/RGB lighting off	• USB power cable not connected. • Faulty USB port.	• Connect the USB power cable to a working USB port. • Try a different USB port or a USB wall adapter.
Distorted sound	• Volume too high. • Poor audio source quality.	• Lower the volume on the soundbar and/or source device. • Test with a different audio source or file.

9. SPECIFICATIONS

Feature	Detail
Brand	T-DAGGER
Model Name	TGS600
Speaker Type	Soundbar
Connectivity Technology	Auxiliary (3.5mm), USB (for power)
Audio Output Mode	Stereo
Speaker Maximum Output Power	3 Watts (per speaker, total 6W)
Special Features	RGB lighting
Recommended Uses	For Gaming Consoles, For Televisions, PCs, Laptops
Color	Black
Material	Plastic or Metal
Product Dimensions	12.5 x 47 x 10.5 cm
Item Weight	4.4 Kilograms
Power Source	Corded Electric (USB)

10. WARRANTY AND SUPPORT

T-DAGGER products are manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your purchase or visit the official T-DAGGER website. Please retain your proof of purchase for warranty claims.

For further assistance, you may contact T-DAGGER customer support through their official channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question