

[Manuals.plus](#) /

› [BANGSON](#) /

› BANGSON 3.2 CU.FT Mini Fridge with Freezer User Manual

BANGSON 644ebd09-5680-48a7-a277-5a91a8dd3688

BANGSON 3.2 CU.FT Mini Fridge with Freezer User Manual

Model: 644ebd09-5680-48a7-a277-5a91a8dd3688 | Brand: BANGSON

1. INTRODUCTION

Thank you for choosing the BANGSON 3.2 CU.FT Mini Fridge with Freezer. This compact and efficient appliance is designed to provide convenient refrigeration and freezing capabilities for various settings, including bedrooms, dorms, offices, homes, garages, or RVs. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before use and retain it for future reference.

2. SAFETY INFORMATION

To reduce the risk of fire, electric shock, or injury when using your refrigerator, follow these basic precautions:

- Ensure the refrigerator is properly grounded.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- Unplug the refrigerator before cleaning or performing any maintenance.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- This appliance uses R-600a refrigerant, which is flammable. Handle with care during transportation and installation to avoid damaging the refrigerant tubing.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x BANGSON Mini Fridge with Freezer Unit
- 2 x Removable Shelves
- 2 x Door Handles
- 1 x Crisper Drawer
- 1 x Ice Tray
- 1 x Defrost Tool
- 1 x Bottle Opener (pre-attached or separate)

4. SETUP

4.1 Placement

Place the refrigerator on a firm, level surface away from direct sunlight and heat sources (e.g., stoves, heaters). Ensure there is adequate air circulation around the unit for proper cooling. The dimensions of the unit are approximately 19.68"D x 17.9"W x 34.01"H.

4.2 Leveling the Appliance

The refrigerator is equipped with adjustable legs to ensure stable and balanced placement, even on uneven surfaces. Rotate the adjustable leg clockwise or counter-clockwise to raise or lower the corresponding corner of the appliance until it is level.



Figure 4.2: Adjustable Leg for secure and balanced placement.

4.3 Door Reversal

The BANGSON mini fridge features reversible doors, allowing you to change the door swing direction to suit your space. Refer to the detailed instructions in the separate door reversal guide (if provided) or contact customer support for assistance with this procedure.

5. OPERATING INSTRUCTIONS

5.1 Temperature Control

The refrigerator features a temperature control dial with 5 modes, allowing you to adjust the cooling intensity. Turn the dial to select your desired setting:

- "0": Turns the unit off.
- "1" - "2": Eco Mode, suitable for energy-saving operation.
- "3" - "5": Max Mode, provides maximum cooling for faster chilling or freezing.

Adjust the dial according to your needs and the ambient temperature. Allow several hours for the temperature to stabilize after making adjustments.




Figure 5.1: Temperature Control Dial.

5.2 Storage and Capacity

The BANGSON mini fridge offers a total capacity of 3.2 cubic feet, with a dedicated freezer compartment of 0.95 cubic feet and a refrigerator fresh food capacity of 2.26 cubic feet. It features:

- **Crisper Drawer:** Ideal for keeping fruits and vegetables fresh.
- **Removable Tempered Glass Shelves:** Two full-width shelves for flexible storage and easy cleaning.
- **Can Dispenser:** Convenient storage for canned beverages.
- **Door Racks:** Integrated tall bottle door shelf for larger items.



Figure 5.2: Internal Capacity and Layout.




Figure 5.3: Product Details and Features.

6. FEATURES OVERVIEW

- **Dual Door Design & Large Capacity:** Features separate doors for the freezer and refrigerator compartments, offering a total of 3.2 cubic feet of storage.
- **Reversible Doors with Handles & Bottle Opener:** The doors can be configured to open from either the left or right side. Stylish handles enhance usability, and a convenient bottle opener is integrated on the side.
- **Energy Saving & Super Quiet Operation:** Designed for energy efficiency with an annual energy consumption of 322 Kilowatt Hours. The compressor operates at a low noise level of approximately 38dB, ensuring a quiet environment.



Figure 6.1: Energy Efficiency.



Figure 6.2: Low Noise Operation.

- **Chic Design & Easy to Clean:** Features a large vegetable crisper, an integrated tall bottle door shelf, and two full-width glass refrigerator shelves. All shelves and the crisper are easily removable for cleaning.

7. MAINTENANCE

7.1 Cleaning

Regular cleaning helps maintain the efficiency and appearance of your refrigerator. Always unplug the unit before cleaning.

- Clean the interior and exterior surfaces with a soft cloth and mild detergent.
- The removable shelves and crisper drawer can be washed with warm, soapy water.
- Ensure the removable door seal is clean and free of debris to maintain a tight seal.
- Wipe dry all surfaces thoroughly after cleaning.

7.2 Defrosting

This refrigerator features manual defrost. Frost buildup in the freezer compartment can reduce cooling efficiency. Defrost the unit when frost accumulation reaches approximately 1/4 inch (6 mm) thickness.

- Turn the temperature control to "0" (off) and unplug the unit.
- Remove all food items from the freezer and refrigerator compartments.
- Leave the doors open to allow frost to melt naturally. You can place towels at the bottom to absorb water.
- Use the provided defrost tool to gently scrape away ice, avoiding sharp objects that could damage the lining.
- Once defrosted, clean and dry the interior thoroughly before plugging the unit back in and returning food items.

8. TROUBLESHOOTING

Before contacting customer support, please check the following common issues:

Problem	Possible Cause	Solution
Refrigerator does not operate.	Not plugged in; circuit breaker tripped; temperature control set to "0".	Ensure plug is secure; reset circuit breaker; set temperature control to a higher setting.
Temperature is not cold enough.	Door opened too frequently; warm food placed inside; poor air circulation; temperature setting too low.	Minimize door openings; allow hot food to cool before placing inside; ensure proper spacing around unit; adjust temperature control to a colder setting.
Excessive noise.	Unit is not level; parts are loose; normal operating sounds.	Adjust leveling legs; check for loose components; gurgling or humming sounds are normal for refrigeration systems (noise level is approx. 38dB).
Door does not close properly.	Unit is not level; gasket is dirty or damaged; shelves are out of place.	Level the unit; clean or replace gasket; reposition shelves.

9. SPECIFICATIONS

Specification	Value
Brand Name	BANGSON
Model Info / Item model number	644ebd09-5680-48a7-a277-5a91a8dd3688
Item Weight	50.7 pounds (23 kg)
Product Dimensions (D x W x H)	19.68 x 17.9 x 34.01 inches (50 x 45.5 x 86.4 cm)
Capacity	3.2 Cubic Feet (90.6 Liters)
Annual Energy Consumption	322 Kilowatt Hours
Refrigerator Fresh Food Capacity	2.26 Cubic Feet (64 Liters)
Freezer Capacity	0.95 Cubic Feet (26.9 Liters)
Noise Level	38 dB
Installation Type	Freestanding
Form Factor	Compact
Color	Red
Voltage	115 Volts

Specification	Value
Number of Shelves	2
Crispers/Drawers	1
Defrost System	Manual
Door Hinges	Reversible
Number Of Doors	2
Date First Available	March 15, 2022

10. WARRANTY AND SUPPORT

For warranty information or if you have any questions or require assistance with your BANGSON Mini Fridge, please contact our customer support. We are committed to providing comprehensive pre-sales and after-sales services and will help you solve any issues in a timely manner.

Please refer to your purchase documentation for specific warranty terms and contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B09VNXL17Q>

More documents and user manuals: <https://manuals.plus/>