

Mintu FCM5SUAWW, FCM5SUBWW, FCM5SUCWW, FCM5SUDWW, FCM5SUEWW

Mintu Upper Freezer Basket Replacement Manual

For GE, Haier, and Hotpoint Chest Freezers

INTRODUCTION

This manual provides essential information for the installation, use, and maintenance of your Mintu Upper Freezer Basket Replacement. This basket is designed to fit various GE, Haier, and Hotpoint chest freezer models, enhancing organization and accessibility within your freezer.

Compatible Models:

- **For GE:** FCM5SUAWW, FCM5SUBWW, FCM5SUCWW, FCM5SUDWW, FCM5SUEWW, FCM7DUAWW, FCM7DUBWW, FCM7DUCWW, FCM7DUDWW, FCM7DUFWW, FCM7DUGWW, FCM7SUAWW, FCM7SUBWW, FCM7SUCWW, FCM7SUDWW, FCM7SUFWW, FCM7SUGWW
- **For Haier:** FCM7DUHWW, FCM7SUHWW, HF50CM23NW, HF50CW20W, HF71CL53NW, HFC3501ACW, IF71CM33NW
- **For Hotpoint:** HCM4SMAWW, HCM4SMBWW, HCM5SMAWW, HCM5SMBWW, HCM7SMAWW, HCM7SMBWW, HHM5SMAWW, HHM5SMBWW, HHM7SMAWW, HHM7SMBWW, VCM5SMBWW, VCM7SMBWW

Please verify your freezer's model number to ensure compatibility. You can typically find the model number on a label inside the freezer compartment or on the back of the unit.

SETUP AND INSTALLATION

The Mintu Upper Freezer Basket is designed for simple, tool-free installation.

1. **Unpack the Basket:** Carefully remove the replacement basket from its packaging. Inspect it for any signs of damage during transit.
2. **Prepare the Freezer:** Ensure your chest freezer is clean and free of ice buildup in the area where the basket will be placed.
3. **Position the Basket:** Locate the designated rails or ledges inside your chest freezer designed to support an upper basket. Gently lower the Mintu basket into the freezer, aligning its wire handles or edges with these supports.
4. **Secure Placement:** Ensure the basket sits securely and level on the freezer's internal supports. It should slide smoothly if designed to do so.



Figure 1: The Mintu Upper Freezer Basket, a white wire basket designed for chest freezers.

OPERATING INSTRUCTIONS

The upper freezer basket provides convenient storage for frequently accessed items or smaller packages, preventing them from getting lost at the bottom of the freezer.

- **Loading:** Place items into the basket, ensuring not to overload it beyond its capacity or the freezer's recommended weight limits for accessories. Distribute weight evenly.
- **Access:** The basket can be easily lifted or slid (if applicable to your freezer model) to access items stored underneath.
- **Organization:** Use the basket to categorize items, such as frozen vegetables, ice cream, or smaller meat packages, for better organization and quicker retrieval.

MAINTENANCE AND CARE

Regular cleaning will help maintain the hygiene and longevity of your freezer basket.

- **Cleaning:** Periodically remove the basket from the freezer. Wash it with warm water and a mild dish soap. Rinse thoroughly with clean water.

- **Drying:** Allow the basket to air dry completely before returning it to the freezer to prevent ice buildup or rust.
- **Inspection:** Occasionally inspect the basket for any signs of wear, bending, or damage to the wire coating.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Basket does not fit or sit level.	Incorrect model compatibility or improper placement.	1. Double-check your freezer's model number against the compatibility list in the Introduction section. 2. Ensure the basket is correctly aligned with the internal support rails or ledges.
Basket is difficult to slide.	Ice buildup or uneven loading.	1. Defrost your freezer if there is significant ice buildup on the rails. 2. Redistribute items within the basket to ensure even weight distribution.

SPECIFICATIONS

- **Product Type:** Upper Freezer Basket Replacement
- **Brand:** Mintu
- **Material:** Durable coated wire
- **Compatibility:** Designed for specific GE, Haier, and Hotpoint chest freezer models (refer to Introduction for full list).
- **ASIN:** B09VPDPGYK
- **Date First Available:** March 16, 2022

CUSTOMER SUPPORT

For further assistance or inquiries regarding your Mintu Upper Freezer Basket Replacement, please contact your retailer or refer to the Mintu brand store on Amazon:

[Visit the Mintu Store on Amazon](#)

© 2024 Mintu. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question