

[Manuals.plus](#) /

› [Mintu](#) /

› Mintu Upper Freezer Basket Replacement User Manual

Mintu Upper Freezer Basket Replacement

Mintu Upper Freezer Basket Replacement User Manual

Model: Upper Freezer Basket Replacement

Brand: Mintu

INTRODUCTION

This manual provides instructions for the installation, use, and maintenance of your Mintu Upper Freezer Basket Replacement. This product is designed to replace original freezer baskets in various chest freezer models, helping to organize freezer contents efficiently.

COMPATIBILITY

This replacement basket is compatible with a range of chest freezer models from GE, Haier, and Hotpoint. Please verify your freezer's model number against the list below to ensure compatibility.

Compatible Hotpoint Models:

- HCM4SMAWW
- HCM4SMBWW
- HCM5SMAWW
- HCM5SMBWW
- HCM7SMAWW
- HCM7SMBWW
- HHM5SMAWW
- HHM5SMBWW
- HHM7SMAWW
- HHM7SMBWW
- VCM5SMBWW
- VCM7SMBWW

Compatible GE Models:

- FCM5SUAWW

- FCM5SUBWW
- FCM5SUCWW
- FCM5SUDWW
- FCM5SUEWW
- FCM7DUAWW
- FCM7DUBWW
- FCM7DUCWW
- FCM7DUDWW
- FCM7DUFWW
- FCM7DUGWW
- FCM7SUAWW
- FCM7SUBWW
- FCM7SUCWW
- FCM7SUDWW
- FCM7SUFWW
- FCM7SUGWW

Compatible Haier Models:

- FCM7DUHWW
- FCM7SUHWW
- HF50CM23NW
- HF50CW20W
- HF71CL53NW
- HFC3501ACW
- IF71CM33NW

SETUP AND INSTALLATION

The Mintu Upper Freezer Basket Replacement is designed for easy installation.

1. **Unpack the Basket:** Carefully remove the new freezer basket from its packaging. Inspect it for any signs of damage during transit.
2. **Prepare the Freezer:** Ensure your freezer is clean and free of ice buildup where the basket will be placed. If replacing an old basket, remove the old one first.
3. **Position the Basket:** Gently lower the basket into the freezer, aligning the top edges of the basket with the support rails. Ensure it sits securely and level.
4. **Test Stability:** Once in place, gently push down on the basket to confirm it is stable and will not easily dislodge when loaded with items.



Image Description: A white wire basket designed as an upper replacement part for chest freezers. It features a rectangular shape with a grid pattern at the bottom and sides, and a handle-like extension on one end for suspension within the freezer. This image illustrates the general appearance of the replacement basket.

OPERATING INSTRUCTIONS

The freezer basket is intended for organizing smaller, frequently accessed items within your chest freezer. This helps prevent items from getting lost at the bottom of the freezer and improves air circulation.

- **Loading:** Place items evenly within the basket. Avoid overloading to ensure the basket remains stable and does not impede the freezer lid from closing properly.
- **Access:** The basket can be easily slid along the rails or lifted out entirely for access to items stored below.
- **Organization:** Use the basket to separate different types of food or to keep frequently used items readily available.

MAINTENANCE

Regular cleaning will help maintain the hygiene and longevity of your freezer basket.

- **Cleaning:** Periodically remove the basket from the freezer. Wash it with warm water and a mild dish soap. Rinse thoroughly.
- **Drying:** Ensure the basket is completely dry before returning it to the freezer to prevent ice buildup or rust.
- **Inspection:** Occasionally inspect the basket for any signs of wear, bending, or rust. While durable, extreme impacts can cause damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Basket does not fit.	Incorrect model compatibility.	Verify your freezer model number against the compatibility list in this manual.
Basket is unstable or wobbly.	Not properly seated on freezer rails; uneven loading.	Ensure the basket is fully seated on all support rails. Distribute contents evenly.
Basket shows signs of rust.	Improper drying after cleaning; prolonged exposure to moisture.	Always ensure the basket is completely dry before returning it to the freezer.

SPECIFICATIONS

- **Product Type:** Upper Freezer Basket Replacement
- **Material:** Coated Wire (typically steel with a protective coating)
- **Color:** White (as per product image)
- **Compatibility:** Designed for specific GE, Haier, and Hotpoint chest freezer models (refer to Compatibility section)
- **ASIN:** B09VPDTLJP
- **Date First Available:** March 16, 2022

WARRANTY AND SUPPORT

For information regarding warranty coverage or technical support, please refer to the seller's information on the product's purchase page or contact Mintu customer service directly through their official channels. Keep your purchase receipt as proof of purchase.

For additional assistance, you may visit the [Mintu Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09VPDTLJP>

More documents and user manuals: <https://manuals.plus/>