

[manuals.plus](#) /

› [Pagani Design](#) /

› [Pagani Design PD1718 Chronograph Watch User Manual](#)

**Pagani Design PD1718**

## **Pagani Design PD1718 Chronograph Watch User Manual**

Model: PD1718

### **1. INTRODUCTION**

Thank you for choosing the Pagani Design PD1718 Chronograph Watch. This manual provides essential information for the proper setup, operation, and maintenance of your timepiece. Please read it carefully to ensure optimal performance and longevity of your watch.




Figure 1.1: Front view of the Pagani Design PD1718 Chronograph Watch.

## 2. PRODUCT OVERVIEW

### 2.1 Package Contents

- Pagani Design PD1718 Watch (1)
- Original Packaging Box (1)
- Instruction Manual (1)
- Cleaning Cloth (1)
- Bracelet Adjuster Tool (1)

## 2.2 Watch Components



100% Original  
& Brand New



PAGANI DESIGN



2 Years  
Local Warranty

Model: PD1718



Thickness: 13MM



Bezel Diameter: 39.5MM



Movement: VK64



Case Material:  
316L Stainless Steel



Band Length: 240MM



Band Width: 20MM



Strap: 316L Stainless Steel



Water Resistant: 10Bar=100Meters



Luminous: C3 Green Light



Watch Case, User Manual,  
Original Warranty Card, Brand tag



Figure 2.1: Diagram illustrating key components and dimensions of the PD1718 watch.

- **Crown:** Used for setting time and winding (if applicable). This model features a screw-down crown for enhanced water resistance.
- **Pushers:** Buttons located on the side of the case, used to operate the chronograph functions.
- **Main Dial:** Displays hours and minutes. The large central seconds hand functions as the chronograph stopwatch hand.
- **Sub-dials:**
  - **9 o'clock sub-dial:** Minute counter for the chronograph.
  - **3 o'clock sub-dial:** 24-hour indicator.
- **Bezel:** Fixed bezel with a tachymeter scale for measuring speed.
- **Luminous Markers:** Dial markers and hands feature C3 Green Luminous material for visibility in low light conditions.

## 3. SETUP

### 3.1 Setting the Time

1. **Unscrew the Crown:** Gently turn the crown downwards (counter-clockwise) until it disengages from the case.

2. **Pull to Position 2:** Carefully pull the crown out to the second click position.
3. **Set Time:** Rotate the crown to set the hour and minute hands to the desired time.
4. **Push and Screw Down:** Push the crown back into the first position, then gently push it inwards while turning it upwards (clockwise) to screw it back into the case. Ensure it is securely tightened to maintain water resistance.

### 3.2 Adjusting the Bracelet

Your watch comes with a bracelet adjuster tool. To adjust the length of the stainless steel bracelet, use the provided tool to remove or add links as necessary. It is recommended to have this procedure performed by a qualified watch technician to prevent damage.



Figure 3.1: The watch's stainless steel bracelet and push-button hidden clasp.

## 4. OPERATING INSTRUCTIONS

### 4.1 Chronograph Function

The Pagani Design PD1718 features a Japan VK64 quartz chronograph movement. Note that the large central seconds hand is dedicated to the chronograph stopwatch function and does not display continuous seconds for timekeeping.

- The large central hand: Stopwatch seconds.

- The sub-dial at 9 o'clock: Stopwatch minutes counter.
- The sub-dial at 3 o'clock: 24-hour time display.

## 4.2 Using the Chronograph

1. **Start:** Press the upper pusher to start the chronograph. The large central hand will begin to count seconds, and the 9 o'clock sub-dial will count minutes.
2. **Stop:** Press the upper pusher again to stop the chronograph. The elapsed time will be displayed.
3. **Reset:** After stopping the chronograph, press the lower pusher to reset all chronograph hands to their zero positions.



Figure 4.1: Side view of the watch, highlighting the crown and chronograph pushers.

## 5. MAINTENANCE

### 5.1 Water Resistance

Your Pagani Design PD1718 watch is water-resistant up to 100 meters (10 ATM / 330 feet). This rating allows for activities such as hand washing, rain exposure, and swimming. However, please observe the following precautions:

- **Tighten Crown:** Always ensure the screw-down crown is securely tightened before any water

exposure.

- **Do Not Operate Underwater:** Never press any buttons or adjust the crown while the watch is submerged in water.
- **Avoid Extreme Temperatures:** Do not expose the watch to extreme hot or cold temperatures, such as hot showers or saunas. Water vapor can corrode the waterproof seals.
- **Not for Diving:** This watch is not suitable for diving activities.

## 5.2 Cleaning and Care

- **Regular Cleaning:** Clean the watch case and stainless steel band regularly with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying.
- **Avoid Chemicals:** Do not use harsh chemicals, solvents, or abrasive cleaners, as these can damage the watch's finish and seals.
- **Impact Protection:** Avoid strong impacts or dropping the watch, which can damage the internal movement or external components.
- **Magnetic Fields:** Keep the watch away from strong magnetic fields, as these can affect the accuracy of the quartz movement.

## 6. SPECIFICATIONS

| Feature              | Specification                 |
|----------------------|-------------------------------|
| Model Number         | PD1718                        |
| Movement             | Japan VK64 Quartz Chronograph |
| Case Material        | Stainless Steel               |
| Band Material        | Stainless Steel               |
| Dial Window Material | Synthetic Sapphire            |
| Bezel Material       | Ceramic                       |
| Case Diameter        | 39.5 mm                       |
| Case Thickness       | 13 mm                         |
| Band Width           | 20 mm                         |
| Band Length          | 240 mm                        |
| Clasp Type           | Push Button Hidden Clasp      |
| Water Resistance     | 100M (10 ATM / 330 ft)        |
| Luminous             | C3 Green Light                |

## 7. TROUBLESHOOTING

### 7.1 Common Issues and Solutions

- **Watch Not Running:**
  - Ensure the crown is fully pushed in and screwed down.

- If the watch still does not run, the battery may need replacement. Consult a professional watch repair service.
- **Chronograph Hands Not Resetting to Zero:**
  - This may indicate a need for chronograph hand alignment. Refer to a watch technician for adjustment.
- **Water Inside the Watch:**
  - Immediately take the watch to a professional watch repair service to prevent further damage.

## 8. WARRANTY AND SUPPORT

### 8.1 Warranty Information

Your Pagani Design PD1718 watch is guaranteed for 2 years from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from improper handling, accidents, unauthorized repairs, or normal wear and tear.

Additionally, a 30-day return policy is offered for any reason, allowing for returns within 30 days of purchase.

### 8.2 Customer Support

For warranty claims, service, or any inquiries regarding your Pagani Design watch, please refer to the contact information provided with your purchase documentation or contact the retailer where the watch was acquired.


## Related Documents - PD1718

|   |   |
|---|---|
|  | <p><a href="#">Pagani Design VK63 Chronograph Watch Instruction Manual</a></p> <p>Comprehensive instruction manual for the Pagani Design VK63, VK67, and VK73 chronograph watches, covering time setting, chronograph operation, tachymeter use, battery care, and water resistance.</p>                      |
|  | <p><a href="#">Pagani Design PD1662 Green Watch - Product Details</a></p> <p>Informational details for the Pagani Design PD1662 Green watch, including product code, category, manufacturer, price, and seller contact information from Moment.</p>   |
|  | <p><a href="#">Pagani Design PD1701 Srebrno Plavi Sat - Detalji Proizvoda</a></p> <p>Detaljne informacije o satu Pagani Design PD1701 srebrno plavi, sa kućištem od nerđajućeg čelika, Seiko mehanizmom, safirnim stakлом, vodootpornošću do 10ATM i prečnikom kućišta od 42mm. Informacije od Moment 23.</p> |



#### [BENYAR Watch User Manual and International Guarantee Certificate](#)

Comprehensive user manual and international guarantee details for BENYAR watches, covering operation, maintenance, materials, and technical specifications.



#### [Filippo Loreti Multifunction Moonphase Watch Instructions](#)

Detailed instructions for operating and caring for your Filippo Loreti Multifunction Moonphase watch, including setting the time, date, day, month, and moon phase.



#### [Pagani Design VK63 Chronograph Watch Instruction Manual](#)

Comprehensive instruction manual for the Pagani Design VK63, VK67, and VK73 chronograph watches, covering time setting, chronograph operation, tachymeter use, battery care, and water resistance.