Beurer BR10 (60318)

Beurer BR10 Insect Bite Healer User Manual

Model: BR10 (60318)

Introduction Safety Information Setup Operating Instructions Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

The Beurer BR10 Insect Bite Healer is a compact, portable device designed to provide relief from itching and swelling caused by insect bites and stings. It utilizes targeted heat application to accelerate the body's natural healing process, offering a chemical-free solution for common insect irritations.



The Beurer BR10 Insect Bite Healer, shown with its product packaging, highlighting its compact design and purpose.



The Beurer BR10 provides quick relief for stings and bites by reducing itching and swelling through heat, without chemicals. It offers up to 300 uses per pair of batteries.

2. Safety Information

Please read this instruction manual in full before first use as it contains all safety and warning information.

- For ages 12 and above for self-application.
- For children aged 3+ with adult supervision.
- Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.
- Do not use on open wounds, irritated skin, or if you have known skin sensitivities to heat.
- Consult a medical professional if symptoms persist or worsen.



The Beurer BR10 is suitable for kids 3+ with adult supervision, and ages 12+ for self-application. It is also safe for adults and during pregnancy.



The device is recommended for users aged 12 and above for independent use.

3. Setup

3.1 Battery Installation

The Beurer BR10 requires 2 AAA batteries (included). To install or replace batteries:

1. Locate the battery compartment cover on the back of the device.
2. Slide the cover off to open the compartment.
3. Insert 2 AAA batteries, ensuring the correct polarity (+/-) as indicated inside the compartment.
4. Slide the battery compartment cover back on until it clicks securely into place.



A detailed view of the Beurer BR10 device, showing its compact form factor.

4. Operating Instructions


The Beurer BR10 is designed for simple and effective use. Follow these steps for optimal results:

1. **Turn On:** Simply flip the switch on the front of the BR10 to the "on" position. A green light will illuminate.
2. **Positioning:** Place the ceramic heat plate directly onto the insect bite or sting on your skin.
3. **Activate Treatment:** Press the button on the device to start the treatment. The BR10 will deliver heat for 3 seconds.
4. **Completion:** An acoustic signal (beep) will indicate the end of the treatment.
5. **Turn Off:** Flip the switch back to the "off" position to turn off the device.

For best results, apply the device immediately after noticing a bug bite.




The image illustrates the recommended immediate application of the BR10 after a bug bite for optimal relief, showing the heat application process.



Step-by-step guide on how to use the Beurer BR10: turn on, place on bite, press for 3-second treatment, wait for beep, and turn off.

4.1 Temperature Information

The BR10's ceramic plate heats up to 122°F (50°C), which is the ideal temperature to reduce itching and swelling while remaining safe for the skin. This temperature is carefully calibrated for effectiveness without causing harm.



A visual comparison demonstrating that the BR10's operating temperature of 122°F is effective for relief while being safe for skin, unlike higher temperatures found in other common items.

5. Maintenance

To ensure the longevity and hygienic use of your Beurer BR10, follow these simple maintenance guidelines:

- **Cleaning:** After each use, gently wipe the ceramic heat plate with a clean, dry cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** Store the device in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** If the device will not be used for an extended period, remove the batteries to prevent leakage and damage.

6. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Device does not turn on.	Batteries are dead or incorrectly inserted.	Check battery polarity and replace batteries if necessary.
Device does not heat up.	Low battery power or device malfunction.	Replace batteries. If problem persists, contact customer support.
Itching/swelling persists after use.	Severe reaction or improper application.	Ensure immediate application after bite. Reapply if needed. Consult a medical professional if symptoms are severe or do not improve.

7. Specifications

Product Dimensions: 3.39 x 1.38 x 0.98 inches

Weight: 0.01 ounces (excluding batteries)

Item Model Number: 60318

Batteries: 2 AAA batteries (included)

Manufacturer: Beurer

Color: White

Special Feature: Clinically Proven, Targeted, Non-Drowsy, Fast-Acting

Number of Pieces: 10

Age Range (Description): Adult (Suitable for kids 3+ with adult supervision, 12+ for self-application)

8. Warranty & Support

For warranty information and customer support, please refer to the documentation included with your product or visit the official Beurer website. Keep your purchase receipt as proof of purchase for any warranty claims.
Manufacturer: Beurer
Website: www.beurer.com (Example link, actual link may vary)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question