

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [REVAMP](#) /

› [Revamp Progloss Wide Ultra X Shine 1.5-Inch Flat Iron Hair Straightener Instruction Manual](#)

REVAMP ST-2250

Revamp Progloss Wide Ultra X Shine 1.5-Inch Flat Iron Hair Straightener Instruction Manual

Model: ST-2250

INTRODUCTION

This manual provides essential information for the safe and effective use of your Revamp Progloss Wide Ultra X Shine 1.5-Inch Flat Iron Hair Straightener. This ceramic hair straightener features plates infused with keratin, argan, and coconut oils, along with ionic technology, designed for efficient hair styling.

IMPORTANT SAFETY INFORMATION

Please read all safety instructions carefully before use.

- Keep away from children.
- Do not immerse in water.
- Ensure hands are dry before plugging in or unplugging the appliance.
- Do not use near water, such as bathtubs, showers, basins, or other vessels containing water.
- Always unplug the appliance immediately after use.
- Allow the appliance to cool completely before storing.
- Do not use if the cord is damaged. Contact customer support for repair.

WHAT'S IN THE Box

- 1 Revamp Progloss Wide Ultra X Shine Ceramic Hair Straightener
- 1 Silicone Heat-Resistant Mat



Image: The Revamp Progloss Wide Ultra X Shine Ceramic Hair Straightener shown with its accompanying silicone heat-resistant mat.

SETUP

1. Unpack the hair straightener and all accessories.
2. Place the silicone heat-resistant mat on a flat, stable surface.
3. Ensure the hair is clean, dry, and tangle-free before use.
4. For extra protection, consider applying a heat protection spray to your hair.

450°F-
170°F

TOUCH OPTIMAL HAIR TYPE SETTINGS

for fine, medium & thick hair



Image: A close-up view of the Revamp Progloss Wide Ultra X Shine Ceramic Hair Straightener, highlighting its wide ceramic plates infused with Progloss oils.

ADVANCED INTELLIGENT HEAT CONTROL

OPERATING INSTRUCTIONS

1. Plug the product into a 120V AC electrical outlet.
2. Press the on/off button to turn on the straightener.
3. Use the touch temperature control '+' and '-' buttons to select your desired temperature manually.
4. Alternatively, use the Hair Mode button to automatically select the recommended temperature for your hair type:
 - **Fine Hair:** 280°F
 - **Medium Hair:** 360°F
 - **Coarse Hair:** 450°F
5. The temperature lock will activate automatically after a few seconds; a lock symbol will appear on the temperature display.

6. To switch off the temperature lock to adjust the heat, press the on/off button once.
7. We recommend using a lower temperature to start.
8. Section the hair prior to styling. Style the lower layers first.
9. Working on one section at a time, run the straightener through the entire length of the hair from roots to ends, without stopping.
10. Use a comb while straightening for even straighter results.
11. Repeat this process all over the head, allowing hair to cool before combing through.
12. After using the straightener, turn off, unplug, and allow to cool before storing away.



Image: The digital temperature display on the Revamp Progloss Wide Ultra X Shine Ceramic Hair Straightener, showing temperature controls and hair type settings.

Your browser does not support the video tag.

Video: Official product video demonstrating the Revamp Progloss Wide Ultra X Shine Ceramic Hair Straightener in use, highlighting its features and styling capabilities.

MAINTENANCE

- Ensure the appliance is unplugged and completely cool before cleaning.
- Wipe the plates and exterior with a soft, damp cloth.
- Do not use abrasive cleaners or solvents.
- Store the straightener in a safe, dry place, preferably on its heat-resistant mat.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Straightener not heating up.	Not plugged in correctly, power button not pressed, or power outlet issue.	Ensure the straightener is securely plugged into a working 120V AC outlet. Press the on/off button. Check the circuit breaker.
Temperature not changing.	Temperature lock is active.	Press the on/off button once to deactivate the temperature lock, then adjust using '+' and '-' buttons.
Hair feels dry or damaged.	Temperature setting too high for hair type, or no heat protectant used.	Reduce the temperature setting. Always use a heat protectant spray. Ensure hair is completely dry before styling.

SPECIFICATIONS

Feature	Detail
Product Dimensions	12.2 x 1.38 x 1.65 inches
Weight	2.81 Pounds
Model Number	ST-2250
Brand	REVAMP
Material	Ceramic
Color	Black
Plate Size	1.5 Inch Wide
Temperature Range	170°F - 450°F (80°C - 235°C)
Heat Technology	SwiftHeat MCH for ultra-fast heat up and recovery
Cord Length	9' Swivel Cable
Auto Shut-off	60 minutes
Infused Oils	Keratin, Argan, Coconut

WARRANTY INFORMATION

The Revamp Progloss Wide Ultra X Shine Ceramic Hair Straightener comes with a 2-year limited warranty. Please retain

your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For further assistance, product registration, or to view additional products, please visit the official REVAMP Store:
[REVAMP Store on Amazon](#).

© 2026 REVAMP. All rights reserved. Information subject to change without notice.