

Dynamix

Sujata Dynamix Mixer Grinder Instruction Manual

Model: Dynamix

1. PRODUCT OVERVIEW

The Sujata Dynamix Mixer Grinder is designed for efficient and versatile kitchen tasks. It features a powerful 900-watt motor with double ball bearings, ensuring durability and consistent performance. This appliance includes three stainless steel jars tailored for various applications: a dome jar for wet grinding, a dry grinding jar, and a chutney grinding jar.



Image 1.1: The Sujata Dynamix Mixer Grinder unit with its three accompanying stainless steel jars. The main motor unit is white, and the jars are silver with clear lids and handles. The largest jar is positioned on the motor unit, while the two smaller jars are placed beside it.

Key features include:

- Powerful 900 Watts motor with double ball bearings for efficiency and low maintenance.
- Designed for continuous running for up to 90 minutes, suitable for longer usage.
- Includes a dome jar for wet grinding, a separate jar for dry grinding, and a chutney grinding jar.
- High-strength stainless steel blades for finer and faster grinding.
- Vibration-free operation for stability during use.
- Totally shock-proof design for enhanced safety.

2. SAFETY INSTRUCTIONS

Read all instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Electrical Safety:** Ensure the voltage indicated on the appliance matches your local power supply before connecting. Do not immerse the motor unit in water or any other liquid. Always unplug the

appliance from the power outlet when not in use, before cleaning, or before assembling/disassembling parts.

- **Blade Safety:** Blades are sharp. Handle with extreme care. Never touch the blades with your hands, especially when the appliance is plugged in.
- **Usage:** Do not operate the mixer grinder with an empty jar. Do not overload the appliance; refer to the maximum capacity markings on the jars. Ensure the jar lid is securely fastened before operating.
- **Supervision:** This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Keep out of reach of children.
- **Maintenance:** Do not attempt to repair the appliance yourself. Contact authorized service personnel for any repairs.
- **Placement:** Place the appliance on a stable, flat, and dry surface. Keep away from heat sources and direct sunlight.

3. PACKAGE CONTENTS

Upon unpacking, please verify that all components are present and undamaged:

- 1 x Motor Unit
- 1 x Wet Grinder Jar (Dome Jar)
- 1 x Dry Grinder Jar
- 1 x Chutney Grinder Jar

4. SETUP AND FIRST USE

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Cleaning:** Before first use, wash all jars and lids with warm soapy water, rinse thoroughly, and dry completely. Wipe the motor unit with a damp cloth. Do not immerse the motor unit in water.
3. **Placement:** Place the motor unit on a clean, dry, and stable surface, ensuring adequate ventilation around the unit.
4. **Jar Assembly:** Select the appropriate jar for your task. Ensure the blade assembly is securely fitted inside the jar. Place the ingredients into the jar, observing the maximum fill line. Securely place the lid on the jar.
5. **Mounting Jar:** Place the assembled jar onto the motor unit, aligning the grooves on the jar with the locking mechanism on the motor unit. Twist gently until the jar is securely locked in place.
6. **Power Connection:** Plug the power cord into a suitable electrical outlet (230 Volts).

5. OPERATING INSTRUCTIONS

The Sujata Dynamix Mixer Grinder features an adjustable speed control for optimal results.

1. **Preparation:** Ensure the mixer grinder is properly set up as described in Section 4. Add ingredients to the chosen jar and secure the lid.
2. **Starting:** Turn the speed control knob to the desired setting. Start with a lower speed and gradually increase if needed. The appliance is designed for continuous running for up to 90 minutes.

3. **Pulsing (if applicable):** For short bursts of power, use the pulse function (if available on your model) by briefly turning the knob to the pulse setting and releasing.
4. **Stopping:** Once grinding is complete, turn the speed control knob to the "OFF" position. Wait for the blades to come to a complete stop before removing the jar.
5. **Removing Jar:** Unlock the jar from the motor unit by twisting it in the opposite direction of locking. Carefully remove the lid and pour out the contents.

Note on Jars:

- **Dome Jar:** Ideal for wet grinding tasks such as making idli or dosa batter.
- **Dry Grinding Jar:** Suitable for grinding spices, coffee beans, or dry ingredients.
- **Chutney Grinding Jar:** Designed for smaller quantities and making chutneys or pastes.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your mixer grinder.

1. **Unplug:** Always unplug the appliance from the power outlet before cleaning.
2. **Motor Unit:** Wipe the motor unit with a soft, damp cloth. Do not use abrasive cleaners or immerse the motor unit in water.
3. **Jars and Lids:** Wash jars and lids immediately after use to prevent food from drying and sticking. Use warm soapy water and a soft brush or sponge. Rinse thoroughly under running water.
4. **Blades:** Exercise extreme caution when cleaning blades due to their sharpness. Use a brush to clean around the blades.
5. **Dishwasher Safety:** The jars and lids are **NOT dishwasher safe**. Hand wash only.
6. **Drying and Storage:** Ensure all parts are completely dry before reassembling or storing. Store the mixer grinder and its accessories in a clean, dry place.

7. TROUBLESHOOTING

If you encounter any issues with your Sujata Dynamix Mixer Grinder, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not start	Not plugged in; Jar not properly locked; Power outage; Overload protector activated.	Check power connection; Ensure jar is securely locked onto the motor unit; Check household circuit breaker; Reduce ingredients and wait 2-3 minutes before restarting.
Motor makes unusual noise or smells burnt	Overloading; Motor overheating.	Switch off immediately and unplug. Reduce the quantity of ingredients. Allow the motor to cool down for at least 15-20 minutes. If the problem persists, contact customer support.
Leakage from jar	Lid not properly secured; Gasket/seal damaged or missing; Overfilling.	Ensure lid is tightly closed; Check if the gasket/seal is correctly placed and undamaged; Do not exceed the maximum fill line.

Problem	Possible Cause	Solution
Ineffective grinding	Insufficient liquid (for wet grinding); Blades are dull or damaged; Incorrect jar used.	Add more liquid if necessary; Inspect blades for damage (contact support if damaged); Ensure the correct jar is used for the task (e.g., wet grinding jar for wet ingredients).

If the problem persists after attempting these solutions, please contact customer support.

8. SPECIFICATIONS

Model Number	Dynamix
Brand	Generic (Sujata)
Wattage	900 Watts
Voltage	230 Volts
Capacity	3 Liters (total across jars)
Number of Jars	3 (Wet Grinder, Dry Grinder, Chutney Grinder)
Material	Plastic (Motor Unit), Stainless Steel (Jars)
Color	White
Item Weight	13.55 pounds
Package Dimensions	19.61 x 14.17 x 9.13 inches
Special Feature	Adjustable Speed Control
Dishwasher Safe	No

9. WARRANTY AND SUPPORT

Your Sujata Dynamix Mixer Grinder comes with a **2-year warranty** provided by the manufacturer from the date of purchase.

For warranty claims, technical support, or service inquiries, please refer to the contact information provided with your purchase documentation or visit the manufacturer's official website. Please retain your purchase receipt as proof of purchase for warranty validation.