

iMice AN-300

iMice AN-300 Wired Gaming Keyboard and Mouse User Manual

Model: AN-300

1. INTRODUCTION

Thank you for choosing the iMice AN-300 Wired Gaming Keyboard and Mouse. This product is designed to enhance your gaming and computing experience with its responsive keys, comfortable design, and vibrant backlight. This manual provides essential information for setting up, operating, and maintaining your new device.

Please read this manual thoroughly before using the product to ensure proper function and longevity.

2. PRODUCT FEATURES

- **104-Key Keyboard Layout:** Full-size keyboard with all standard keys for comprehensive functionality.
- **Water-Resistant Design:** Engineered to withstand accidental spills, providing enhanced durability.
- **Colorful Backlight:** Integrated vibrant backlighting for improved visibility in low-light conditions and an aesthetic appeal.
- **One-Key Backlight Control:** Easily toggle the backlight on or off with a dedicated key.
- **Comfortable Keycap Design:** Ergonomically designed keycaps to reduce fatigue during extended use.
- **Narrow Bezel Design:** Space-saving design for a compact footprint on your desk.
- **Gaming Mouse:** Responsive optical mouse with dedicated gaming features.
- **Mouse Special Features:** Includes a double-click fire enhancement button and convenient forward/backward side keys for improved control.

3. PACKAGE CONTENTS

Ensure all items are present in the package:

- 1 x iMice AN-300 Wired Gaming Keyboard

- 1 x iMice Wired Gaming Mouse
- 1 x User Manual (this document)



Image: The iMice AN-300 Wired Gaming Keyboard and Mouse, shown both in its retail packaging and laid out, highlighting the full keyboard and the accompanying gaming mouse.

4. SETUP

1. **Connect the Keyboard:** Locate an available USB port on your computer. Insert the USB connector of the keyboard firmly into the USB port.
2. **Connect the Mouse:** Locate another available USB port on your computer. Insert the USB connector of the mouse firmly into the USB port.
3. **Driver Installation:** The keyboard and mouse are plug-and-play devices. Your operating system should automatically detect and install the necessary drivers. This process may take a few moments.
4. **Verify Connection:** Once drivers are installed, the keyboard backlight should illuminate, and the mouse cursor should be responsive on your screen.

5. OPERATING INSTRUCTIONS

5.1 Keyboard Functions

- **Standard Typing:** Use the keys as you would any standard 104-key keyboard for typing and data entry.
- **Backlight Control:** Locate the dedicated backlight key (often labeled with a light bulb icon or similar) to

toggle the colorful backlight on or off.

- **Multimedia Keys:** Some keyboards may include dedicated multimedia keys (e.g., volume control, play/pause). Refer to the key legends for specific functions.



Image: A close-up view of the iMice AN-300 keyboard, showcasing its vibrant, multi-colored backlighting across different sections of the keys.

5.2 Mouse Functions

- **Standard Navigation:** Use the left and right click buttons, and the scroll wheel for standard computer navigation.
- **Double-Click Fire Enhancement Button:** This button (often located near the left click button) provides a rapid double-click action, useful in gaming scenarios.
- **Forward/Backward Side Keys:** Located on the side of the mouse, these buttons typically function as 'forward' and 'backward' in web browsers and file explorers, and can often be customized in games.

CONVENIENT OPERATION

The mouse has a double-click fire enhancement button, forward/backward side keys



Image: A detailed view of the iMice wired gaming mouse, highlighting its ergonomic shape, blue LED lighting, and the clearly visible "DOUBLE CLICK" and "FORWARD BACK" side buttons.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe down the keyboard and mouse. For stubborn dirt, a slightly damp cloth with mild soap can be used, ensuring no liquid enters the device.
- **Spill Management:** While the keyboard is water-resistant, it is not waterproof. In case of a spill, immediately unplug the keyboard, turn it upside down to drain liquid, and allow it to air dry completely before reconnecting. Do not immerse the device in water.
- **Storage:** Store the keyboard and mouse in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid sharp bends or kinks in the USB cables to prevent internal wire damage.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Keyboard/Mouse not responding	Loose USB connection, faulty USB port, driver issue.	<ol style="list-style-type: none">1. Ensure USB cables are securely plugged into the computer.2. Try connecting to a different USB port.3. Restart your computer.4. Check Device Manager (Windows) or System Information (macOS) to see if the devices are recognized.

Problem	Possible Cause	Solution
Backlight not working	Backlight turned off, power issue.	<ol style="list-style-type: none">1. Press the dedicated backlight control key on the keyboard.2. Ensure the keyboard is properly connected and receiving power.
Mouse cursor erratic or unresponsive	Dirty optical sensor, unsuitable surface.	<ol style="list-style-type: none">1. Clean the optical sensor on the bottom of the mouse with a soft cloth.2. Use the mouse on a clean, non-reflective, opaque surface or a mouse pad.

8. SPECIFICATIONS

Feature	Detail
Brand	iMice (Generic)
Model Number	AN-300
Connectivity Technology	Wired (USB)
Keyboard Key Count	104 Keys
Special Features	Water-Resistant, Backlit
Power Source	Corded Electric
Color	Black
Compatible Devices	Gaming Console, PC (implied)
Movement Detection (Mouse)	Optical

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided at the point of purchase or contact your retailer. Keep your proof of purchase for warranty claims.

For further assistance, you may also visit the manufacturer's official website (if available) or contact their customer service department.