

Jimmyjane JJ10550

JIMMYJANE Dia Anal Plug Vibrator with Remote Control User Manual

Model: JJ10550
Brand: Jimmyjane

1. INTRODUCTION

The JIMMYJANE Dia Anal Plug Vibrator is designed for personal pleasure, featuring a remote control, multiple vibration modes, and intensity levels. Crafted from silky-soft silicone, this device offers a comfortable and customizable experience. This manual provides essential information for the safe and effective use, maintenance, and care of your Dia vibrator.

2. SAFETY INFORMATION

- **Material Safety:** The device is made from body-safe silicone. Clean thoroughly before and after each use.
- **Lubrication:** Always use a water-based lubricant with this device. Oil-based lubricants can damage silicone.
- **Discomfort:** Discontinue use immediately if you experience any pain, irritation, or discomfort.
- **Medical Use:** This product is not intended for medical use or to treat any medical conditions. Consult a healthcare professional if you have concerns.
- **Storage:** Keep out of reach of children and pets.
- **Water Resistance:** The device is waterproof. However, avoid submerging the magnetic charging port for extended periods.

3. PACKAGE CONTENTS

- 1 x JIMMYJANE Dia Anal Plug Vibrator
- 1 x Remote Control
- 1 x Magnetic USB Charging Cable
- 1 x User Manual (this document)

4. PRODUCT OVERVIEW

The JIMMYJANE Dia Anal Plug Vibrator features an ergonomic design with a secure wide base for safe and easy removal. The device is controlled by a separate remote, allowing for convenient operation.



- Ergonomically shaped for precise massage
with a high-performance motor
- Powerful, fulfilling vibrations

Image: JIMMYJANE Dia Anal Plug Vibrator and Remote Control. The image displays the blue silicone vibrator with its metallic charging contacts and the separate, circular remote control.



• Choose between seven high-performing vibration modes and three intensity levels for your every mood

Image: JIMMYJANE Dia Anal Plug Vibrator, side view. This image shows the vibrator from a different angle, highlighting its tapered shape and wide base.

Components:

- **Vibrator:** Main device with internal motor and charging contacts.
- **Remote Control:** Used to power on/off, change vibration modes, and adjust intensity.
- **Magnetic Charging Port:** Located on the vibrator, for connecting the USB charging cable.

5. SETUP

5.1. Charging the Device

1. Locate the magnetic charging contacts on the base of the vibrator.
2. Connect the magnetic end of the USB charging cable to these contacts. Ensure a secure connection.
3. Plug the USB end of the cable into a standard USB power adapter (not included) or a computer USB port.
4. The indicator light on the device will illuminate during charging. Refer to the device for specific light behavior (e.g., solid light for charging, off for fully charged).
5. A full charge typically provides approximately 90 minutes of run time.

5.2. First Use Preparation

Before initial use, clean the device thoroughly according to the "Maintenance" section (Section 7).

6. OPERATING INSTRUCTIONS

The JIMMYJANE Dia Anal Plug Vibrator is operated using its dedicated remote control.




Image: User holding the JIMMYJANE Dia Anal Plug Vibrator. The image shows a person holding the blue vibrator, demonstrating its size and ergonomic shape.

6.1. Power On/Off

- To turn on the device, press and hold the power button on the remote control for 2-3 seconds. The device will vibrate briefly to indicate it is on.
- To turn off the device, press and hold the power button on the remote control for 2-3 seconds. The device will stop vibrating.

6.2. Changing Vibration Modes

- While the device is on, press the mode button (often indicated by a wave or cycle icon) on the remote control to cycle through the 7 available vibration modes.
- Each press will switch to the next mode.

6.3. Adjusting Intensity Levels

- While the device is on, use the '+' and '-' buttons on the remote control to adjust the vibration intensity.
- There are 3 intensity levels to choose from.

7. MAINTENANCE

7.1. Cleaning

1. Always clean your device before and after each use.
2. Wash the device with warm water and a mild, toy-safe soap or a specialized toy cleaner.
3. Rinse thoroughly to remove all soap residue.
4. Pat dry with a lint-free cloth or allow to air dry completely.
5. Do not use harsh chemicals, alcohol, or petroleum-based cleaners, as these can damage the silicone.

7.2. Storage

- Store the device in a clean, dry, and cool place, away from direct sunlight and extreme temperatures.
- Avoid storing with other toys made of different materials, especially those made of PVC or jelly, as this can cause material degradation or discoloration.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not turning on	Low battery; Remote not paired or out of range	Charge the device fully. Ensure the remote is within operating range and has power.
Vibrations are weak	Low battery	Recharge the device.
Device not charging	Improper cable connection; Faulty cable/adaptor	Ensure the magnetic cable is securely connected. Try a different USB port or power adapter.
Remote not responding	Device is off; Remote battery low; Out of range	Ensure the device is powered on. Move the remote closer to the device.

9. SPECIFICATIONS

Feature	Detail
Model Number	JJ10550
Material	Silicone

Feature	Detail
Color	Blue
Vibration Modes	7
Intensity Levels	3
Power Source	Magnetic USB Charging
Run Time	Approximately 90 minutes (on a full charge)
Water Resistance Level	Waterproof
Package Dimensions	6.61 x 3.9 x 1.73 inches
Item Weight	7.37 ounces

10. WARRANTY INFORMATION

For specific warranty details regarding your JIMMYJANE Dia Anal Plug Vibrator, please refer to the original product packaging or visit the official Jimmyjane website. Warranty terms and conditions may vary by region and retailer.

11. CUSTOMER SUPPORT

If you have any questions, require assistance, or need further information about your JIMMYJANE Dia Anal Plug Vibrator, please visit the official Jimmyjane website or contact their customer service department through the contact information provided on their website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question