

[Manuals.plus](#) /

› [Mintu](#) /

› Mintu Dryer Door Handle Replacement Manual for Maytag Models

Mintu Dryer Door Handle

Mintu Dryer Door Handle Replacement Manual

For Maytag Dryer Models

1. INTRODUCTION

This manual provides detailed instructions for the safe and correct installation and maintenance of your new Mintu replacement dryer door handle. Please read all instructions carefully before beginning the installation process.

2. SAFETY INFORMATION

- Always disconnect power to the dryer before attempting any repairs or installations. Failure to do so can result in electric shock or injury.
- Wear appropriate personal protective equipment, such as gloves, to prevent injury during installation.
- If you are unsure about any step, consult a qualified appliance technician.
- Keep small parts away from children.

3. PRODUCT OVERVIEW

The Mintu replacement dryer door handle is designed for durability and ease of installation. It is a direct replacement part for compatible Maytag dryer models.



Figure 1: Front view of the Mintu replacement dryer door handle.



Figure 2: Side view illustrating the mounting clips on the replacement handle.

4. COMPATIBILITY

This replacement door handle is compatible with the following Maytag dryer models. Please verify your dryer's model number before installation to ensure proper fit.

- MGDB755DW2
- MGDB755DW3
- MGDB766FW0
- MGDC215EW1
- MGDC215EW2
- MGDC415EW1
- MGDC415EW2

- MGDC465HW0
- MGDC555DW2
- MGDC555DW3
- MGD655DW1
- MGD655DW2
- MGD6STBW1
- MGD6STBW2

5. INSTALLATION INSTRUCTIONS

Tools Required:

- Flathead screwdriver (optional, for prying)
- Gloves (recommended)

Step-by-Step Guide:

1. **Disconnect Power:** Unplug the dryer from the electrical outlet or turn off the circuit breaker supplying power to the dryer. This is a critical safety step.
2. **Remove Old Handle:** Carefully inspect the existing handle. Most dryer door handles are either screwed in from the inside of the door panel or clip into place. If it's clipped, you may need to gently pry it off using a flathead screwdriver. If it's screwed, remove the screws from the inside of the door.
3. **Clean Mounting Area:** Once the old handle is removed, clean any debris or residue from the door panel where the new handle will be installed.
4. **Install New Handle:** Align the new Mintu replacement handle with the mounting holes or slots on the dryer door. Press firmly until the clips engage and the handle is securely in place. If your original handle was screwed, ensure the new handle also aligns with screw holes and secure it with appropriate screws (not included, reuse original if applicable).
5. **Test Handle:** Gently pull on the new handle to ensure it is firmly attached and does not wobble. Open and close the dryer door a few times to confirm proper operation.
6. **Reconnect Power:** Plug the dryer back into the electrical outlet or restore power at the circuit breaker.

6. MAINTENANCE

To maintain the appearance and functionality of your dryer door handle, simply wipe it clean with a soft, damp cloth as needed. Avoid using abrasive cleaners or solvents, as these can damage the finish.

7. TROUBLESHOOTING

Handle Does Not Fit:

- Double-check your dryer's model number against the compatibility list in Section 4.
- Ensure the handle is oriented correctly.
- If the issue persists, contact customer support for assistance.

Handle Feels Loose:

- Ensure all clips are fully engaged or screws are tightened (if applicable).
- If the handle continues to feel loose, it may indicate improper installation or a damaged mounting point on the dryer door.

8. SPECIFICATIONS

- **Product Type:** Dryer Door Handle Replacement
- **Brand:** Mintu
- **Material:** Durable Plastic
- **Color:** White
- **Dimensions:** Approximately 5.7 inches (length) x 2 inches (width)



Figure 3: Dimensions of the replacement dryer door handle.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact the retailer where the item was purchased. You may also visit the [Mintu Store on Amazon](#) for additional product information.

© 2026 Mintu. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question