Magellan 5045-MU

Magellan Roadmate 5045-MU Vehicle Navigator Instruction Manual

Comprehensive guide for setting up, operating, and maintaining your Magellan Roadmate 5045-MU Vehicle Navigator.

Introduction

This manual provides detailed instructions for the Magellan Roadmate 5045-MU Vehicle Navigator. It covers device setup, operational procedures, maintenance guidelines, and troubleshooting tips to ensure optimal performance and user experience. The Magellan Roadmate 5045-MU is designed to provide reliable navigation with a 5.0-inch color touchscreen display.

Setup

1. Device Mounting

The Magellan Roadmate 5045-MU is designed for dashboard mounting. Ensure the mounting surface is clean and dry before attaching the mount. Securely attach the device to the mount, ensuring it is stable and does not obstruct your view of the road.



Image: The Magellan Roadmate 5045-MU Vehicle Navigator showing a navigation route with an exit instruction for "Hollywood Way" and current distance of 19.3 miles. The screen also displays traffic information and a "OneTouch" shortcut button.

2. Powering On and Charging

Connect the device to a power source using the provided vehicle power adapter. The device requires a product-specific battery. For initial use, ensure the battery is fully charged. The typical battery life is approximately 2.25 hours on a full charge. To power on, press and hold the power button until the screen illuminates.

Operating Instructions

1. Basic Navigation

- **Touchscreen Interface:** Interact with the device using its 5.0-inch color touchscreen.
- **Entering Destinations:** Tap the "Menu" button, then select "Find Address" or "Point of Interest" to enter your destination.
- **OneTouch Favorites Menu:** Utilize the OneTouch Favorites Menu for instant access to personalized bookmarks of frequently visited places or saved searches.

2. Advanced Features

- **Free Lifetime Traffic:** The device provides real-time traffic information to help you avoid traffic jams, detours, and construction zones. This feature is automatically updated.
- **Highway Lane Assist:** Realistic highway signs are displayed to guide you, ensuring you choose the correct lane when approaching interchanges and exits.
- **AAA TourBook Guide:** Access the built-in AAA TourBook Guide for ratings and descriptions of AAA-approved places to stay, play, dine, and save.

3. Map Updates

The Magellan Roadmate 5045-MU includes one free map update during the life of the GPS navigator. Additionally, it offers free lifetime map updates, allowing you to receive up to four map updates per year at no extra cost. Refer to the Magellan website for instructions on how to download and install map updates.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the screen and exterior of the device. Avoid abrasive cleaners or solvents.
- **Temperature:** Do not expose the device to extreme temperatures, either hot or cold, for extended periods.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Store the device in a cool, dry place if not used for an extended period.

Troubleshooting

- **No GPS Signal:** Ensure the device has a clear view of the sky. Move away from tall buildings or dense foliage.
- **Screen Unresponsive:** Try restarting the device. If the issue persists, ensure the screen is clean and free of debris.
- **Device Not Charging:** Verify that the power adapter is securely connected to both the device and the vehicle's power outlet. Check for any damage to the cable or adapter.
- **Incorrect Route Calculation:** Ensure your maps are up to date. Check your navigation settings for preferred routes (e.g., fastest, shortest, avoid highways).

Specifications

Feature	Detail
Brand	Magellan
Model	Roadmate 5045-MU
Display Size	5.0 inches
Resolution	480 x 272
Touch Screen Type	Capacitive
Item Weight	6.4 ounces (0.4 Pounds)
Product Dimensions	3.5 x 5.63 x 0.63 inches
Battery Life	2.25 Hours
Mounting Type	Dashboard Mount
Map Type	North America
Special Features	Lane Assist, Touchscreen
Vehicle Service Type	Car

Warranty Information

The Magellan Roadmate 5045-MU comes with a 90-day limited warranty. For specific terms and conditions, please refer to the warranty documentation included with your purchase or visit the official Magellan support website.

Support

For further assistance, technical support, or to access additional resources such as software updates and FAQs, please visit the official Magellan support website. Contact information for customer service may also be found on the manufacturer's website.

Magellan Roadmate 5045-MU User Manual. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question