

Manuals.plus /

- › TOWILD /
- › TOWILD ALC-01 Wireless Remote Control for Bicycle Light User Manual

## TOWILD ALC-01

# TOWILD ALC-01 Wireless Remote Control for Bicycle Light User Manual

Model: ALC-01 | Brand: TOWILD

## 1. INTRODUCTION

This manual provides detailed instructions for the proper use and maintenance of your TOWILD ALC-01 Wireless Remote Control for Bicycle Light. Please read this manual thoroughly before use to ensure optimal performance and safety.

## 2. PRODUCT OVERVIEW

The TOWILD ALC-01 is a compact wireless remote control designed to enhance the functionality of compatible TOWILD bicycle lights. It allows for convenient mode switching and brightness adjustments without needing to reach the light unit directly.



Top-down view of the TOWILD ALC-01 remote control, showing three distinct buttons with symbols for mode, power, and brightness.



Side view of the TOWILD ALC-01 remote control, highlighting its compact design and integrated mounting hooks.



Angled view of the TOWILD ALC-01 remote control, showing the textured surface and button layout.

### Components:

- ALC-01 Wireless Remote Control Unit
- Mounting Straps (rubber bands)
- User Manual

## 3. SETUP

---

### Pairing the Remote Control with Your Bicycle Light:

1. Ensure your TOWILD bicycle light is powered on.
2. Power on the remote control.
3. Long-press the switch button on the remote control for 3 seconds. The indicator on the remote will turn red (the light may flash once).
4. While the indicator is red, long-press any button on the remote control. The indicator will change from red to blue/green, indicating successful pairing.

Your browser does not support the video tag.

Video: Demonstrates the pairing process between the TOWILD ALC-01 remote control and a compatible bicycle light. Shows how to activate pairing mode on the remote and confirm successful connection.

## 4. OPERATING INSTRUCTIONS

---

Once paired, the remote control allows for easy operation of your TOWILD bicycle light.

**TOWILD**



ワイヤレスリモコン  
と接続使用可能

### 操作説明



クリックすると警告、点灯モードを切り替えます。0.5秒間を長押ししてスマートモードと手動モードを切り替えます。



0.5秒間を長押しで電源オン、0.8秒間を長押しで電源オフ。クリックするのはロー/ミドル/ハイまたはナイトフラッシュ(スロー)→デイフラッシュモードを切り替えます。



極亮スイッチで、長押しすると最高輝度になります。手を離すと前のモードに戻ります。

The remote control mounted on a handlebar, illustrating the button functions.

### Button Functions:

- **Top Left Button (Mode Switch):** Click to switch between warning and flashing modes. Long-press for 0.5 seconds to switch between smart mode and manual mode.
- **Top Right Button (Power/Brightness):** Long-press for 0.5 seconds to power on, long-press for 0.8 seconds to power off. Click to cycle through low/middle/high brightness modes or night flash (slow) to day flash mode.
- **Bottom Button (Instant Max Brightness):** Long-press for instant maximum brightness. Release the button to return to the previous mode.

Your browser does not support the video tag.

Video: Demonstrates the various operating modes and button functions of the TOWILD ALC-01 remote control, including switching between brightness levels and flashing modes.

## 5. MAINTENANCE

### Battery Replacement:

The remote control uses a replaceable button cell battery. To replace the battery:

1. First, remove the rubber mat from the bottom of the remote control.
2. Apply force to the center of the remote control from the front to separate the main body from its case.
3. Remove the soft cap from the main unit.
4. Carefully remove the internal components and replace the battery. Ensure correct polarity.
5. When reassembling, pay close attention to the alignment of the contacts to ensure proper function.

Your browser does not support the video tag.

Video: Step-by-step guide on how to replace the battery in the TOWILD ALC-01 wireless remote control, including disassembly and reassembly instructions.

## 6. TROUBLESHOOTING

- **Remote not responding:** Ensure the remote control and bicycle light are both powered on. Check the remote control's battery and replace if necessary. Re-pair the remote control with the light.
- **Light not changing modes:** Verify that the remote control is properly paired. Ensure there are no obstructions between the remote and the light.
- **Short battery life:** Ensure the remote is turned off when not in use. Replace with a fresh, high-quality battery.

## 7. SPECIFICATIONS

Feature	Specification
Brand	TOWILD
Model	ALC-01
Power Source	Corded Electric (refers to the light, remote is battery-powered)
Water Resistance Level	Waterproof
Item Weight	10 grams
Mounting Type	Handlebar Mount
Number of Settings	1 (remote unit)
UPC	768497183278
GTIN	768497183278

## 8. WARRANTY & SUPPORT

For warranty information and customer support, please refer to the documentation included with your TOWILD bicycle light or visit the official TOWILD website. Keep your purchase receipt for warranty claims.