Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nostalgia Deluxe

Nostalgia Taco Tuesday Deluxe 8-Inch 6-Wedge Electric Quesadilla Maker Instruction Manual

Model: Deluxe | Brand: Nostalgia

Introduction

The Nostalgia Taco Tuesday Deluxe 8-Inch 6-Wedge Electric Quesadilla Maker is designed to simplify the preparation of crispy and delicious quesadillas. This appliance features a unique cooking plate that creates six sectional pieces, sealing in flavorful ingredients. An extra stuffing latch accommodates various filling amounts, and the non-stick surface ensures easy cleanup. Prepare your favorite quesadillas in minutes with this convenient kitchen tool.

- **Unique Cooking Plate:** Creates 6 sectional pieces to neatly seal in ingredients.
- **Extra Stuffing Latch:** A two-position latch adjusts for thin or thick stuffed quesadillas.
- **8-Inch Cooking Surface:** Cooks 6 wedges on an 8-inch surface quickly.
- **Indicator Lights:** Two lights show when the unit has power and is preheated.
- **Easy Cleanup:** Non-stick cooking surface wipes clean effortlessly.



The quesadilla maker open, showcasing a perfectly cooked 6-wedge quesadilla.

Setup

1. **Unpack:** Carefully remove the quesadilla maker from its packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the unit on a stable, heat-resistant surface, ensuring adequate ventilation around the appliance.
3. **Initial Cleaning:** Before first use, wipe the non-stick cooking plates with a damp cloth and dry thoroughly.
4. **Power Connection:** Plug the appliance into a standard 120-volt AC outlet. The red indicator light will illuminate, signaling that the unit is powered on.

5. **Preheating:** Allow the quesadilla maker to preheat. The green indicator light will illuminate when the unit has reached its optimal cooking temperature and is ready for use.



The indicator lights on the quesadilla maker, showing power and preheat status.

Operating Instructions

Follow these steps to prepare your quesadillas:

1. **Preheat:** Ensure the unit is preheated until the green indicator light is on.
2. **Place Tortilla:** Open the lid and carefully place one 8-inch tortilla onto the bottom cooking plate.
3. **Add Fillings:** Distribute your desired fillings (cheese, meat, vegetables) evenly over the tortilla, keeping them within the designated sections to ensure proper sealing. Utilize the two-position latch to accommodate thicker fillings if needed.
4. **Top Tortilla:** Place a second 8-inch tortilla on top of the fillings.
5. **Close and Latch:** Gently close the lid and secure the latch. The unit will begin cooking.

6. **Cook:** Cook for approximately 3-5 minutes, or until the quesadilla is golden brown and the cheese is melted. Cooking time may vary based on filling and desired crispness.
7. **Remove:** Once cooked, carefully open the lid and use a non-metallic utensil to remove the quesadilla. The built-in sections will guide you for easy cutting into wedges.

Watch this video for a demonstration on how to use the quesadilla maker, including adding ingredients and cooking process.



The extra stuffing latch allows for more generous fillings, ensuring a perfectly sealed quesadilla.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your quesadilla maker.

1. **Unplug and Cool:** Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. **Clean Cooking Plates:** The non-stick cooking plates can be easily wiped clean with a damp cloth or sponge. Avoid abrasive cleaners or scouring pads that could damage the non-stick coating.

3. **Clean Drip Tray:** The drip tray, designed to collect excess grease, should be removed and washed with warm, soapy water. Rinse thoroughly and dry before reinserting.
4. **Exterior Cleaning:** Wipe the exterior of the unit with a damp cloth. Do not immerse the appliance in water or any other liquid.
5. **Storage:** Store the quesadilla maker in a cool, dry place. Its compact design allows for vertical storage to save space.

This video demonstrates the ease of cleaning the non-stick surfaces after use.

Troubleshooting

- **Quesadilla is not crispy:** Ensure the unit is fully preheated before adding tortillas. Increase cooking time by 1-2 minutes for a crispier result.
- **Cheese or fillings overflow:** Reduce the amount of filling used. Ensure the tortillas are centered on the cooking plate and the lid is properly latched.
- **Unit not heating:** Check that the power cord is securely plugged into a working 120V AC outlet. Verify that the red power indicator light is illuminated.
- **Quesadilla sticks to plates:** Ensure the non-stick plates are clean and dry. For extra sticky fillings, a light spray of cooking oil can be applied before placing the first tortilla.

Specifications

Feature	Detail
Special Feature	Manual
Color	Red
Material	Quesadilla, Quesadillas
Brand	Nostalgia
Product Dimensions	10"D x 11"W x 5"H
Wattage	1000 watts
Item Weight	2.97 Pounds
Included Components	Quesadilla Maker and Drip Tray
Style	8-Inch Quesadilla Maker
Voltage	120 Volts
Number of settings	1
UPC	810061703143

Warranty

This product comes with a limited warranty. For detailed information regarding warranty coverage, terms, and conditions, please refer to the official Nostalgia Products website or contact their customer support directly.

Support

For additional support, product information, or to explore other Nostalgia products, please visit the official Nostalgia Store.

Official Nostalgia Store: Visit the Nostalgia Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question