

[Manuals.plus](#) /

› [BRITA](#) /

› Brita Metro 6-Cup Water Filter Pitcher with SmartLight Indicator User Manual

BRITA 0B11/OB03

Brita Metro 6-Cup Water Filter Pitcher User Manual

Model: 0B11/OB03

1. PRODUCT OVERVIEW

The Brita Metro 6-Cup Water Filter Pitcher is designed to provide healthier, great-tasting tap water. This BPA-free pitcher reduces the taste and odor of chlorine, as well as copper, cadmium, and mercury impurities. It features an easy-fill locking lid and an electronic SmartLight filter indicator to signal when a filter change is needed.



Figure 1: Brita Metro 6-Cup Water Filter Pitcher.

Key Features:

- BPA-free construction.
- Reduces chlorine taste and odor, copper, cadmium, and mercury.
- Easy-fill locking lid to prevent spills.
- Electronic SmartLight filter indicator for timely filter replacement.
- 6-cup capacity, designed for fridge-friendly fit.

2. SETUP AND FIRST USE

2.1 Unpacking and Initial Cleaning

1. Remove all components from the packaging.
2. Hand-wash the pitcher, lid, and reservoir with mild detergent. Rinse thoroughly.

2.2 Filter Preparation and Installation

1. Remove the new Brita Standard filter from its packaging.
2. Rinse the filter under cold tap water for 15 seconds.
3. Insert the filter firmly into the reservoir until it creates a tight seal. Ensure the longest slot on the filter faces the handle.
4. Place the reservoir with the installed filter into the pitcher.
5. Attach the lid to the pitcher.

Your browser does not support the video tag.

Video 1: Demonstrates the setup and initial use of the Brita Metro Water Filter Pitcher, including filter installation and filling.

2.3 Activating the SmartLight Filter Indicator

1. On the lid, locate the 'Filter Life' indicator button.
2. Press and hold the 'RESET' button for 2 seconds until a green light flashes. This indicates the filter life has been reset for a Standard filter. (For LongLast filters, hold for 6 seconds).

SMARTER FEATURES, SIMPLER LIVING



- 💧 SmartLight indicator
- 💧 Easy to pour and carry
- 💧 Made without BPA

Figure 2: The SmartLight indicator on the pitcher lid helps track filter life.

3. OPERATING INSTRUCTIONS

3.1 Filling the Pitcher

1. Open the easy-fill locking lid.
2. Place the pitcher under a cold water tap.
3. Fill the reservoir with tap water. The water will filter through to the main pitcher compartment. Do not overfill past the maximum fill line.
4. Close the lid securely.

Your browser does not support the video tag.

Video 2: Shows the process of filling the Brita pitcher and the quick filtration speed.

3.2 Pouring Filtered Water

Once the water has filtered through to the main pitcher, it is ready to be poured. The pitcher's design allows for easy pouring without spills.

**GREAT-TASTING HYDRATION AT ABOUT
1¢ PER GLASS***

*Purchase of filter refill

Figure 3: Pouring filtered water from the Brita Metro pitcher.

4. MAINTENANCE

4.1 Filter Replacement

The SmartLight filter indicator will flash red when it is time to replace your filter. For optimal performance, replace your Standard filter after 40 gallons or approximately every two months. If using an Elite filter, replace after 120 gallons or about every six months.

1. Remove the lid and the old filter from the reservoir.
2. Discard the old filter.
3. Prepare and install a new Brita filter as described in Section 2.2.
4. Reset the SmartLight filter indicator as described in Section 2.3.



Brita Original™ Filter Technology

Patented aeration technology

Figure 4: Brita Original filter technology, showing water flow through vents and mesh screens.



Water then flows through
activated carbon (made from
recycle coconut shells!) which
helps to trap chlorine

Figure 5: Activated carbon in the filter traps chlorine for improved taste and odor.



Ion exchange resin traps select heavy metals. And voila! Don't forget to change your filter!

Figure 6: Ion exchange resin within the filter traps select heavy metals.

4.2 Cleaning the Pitcher

The pitcher, lid, and reservoir should be hand-washed regularly with mild detergent and rinsed thoroughly. Do not wash the filter in a dishwasher.

5. TROUBLESHOOTING

5.1 Slow Filtration

If water filters very slowly, ensure the filter is properly seated in the reservoir. If the issue persists, the filter may be clogged and require replacement.

5.2 Unfiltered Water Dispensing

If unfiltered water is dispensing, check that the filter is securely installed and that the reservoir is correctly positioned within the pitcher. A loose filter or improperly seated reservoir can allow water to bypass the filtration system.

5.3 Lid or Handle Issues

Ensure all parts of the pitcher are assembled correctly. If the lid or handle components appear damaged or do not fit securely, contact customer support for assistance.

6. SPECIFICATIONS

Feature	Detail
Brand	BRITA
Model Name	Metro

Model Number	0B11/OB03
Special Feature	Change Filter Indicator
Product Dimensions (L x W x H)	10.12"L x 10.04"W x 4.82"H
Material	Plastic
Capacity	6-Cup (approx. 3 Pounds)
Included Components	1 Standard Filter
Supported Water TDS Level Maximum	500 PPM



The image shows a white Brita Metro 6-Cup Pitcher. The pitcher has a wide, flared top with a white filter housing and a spout. The Brita logo, a blue water drop with the word 'BRITA' in blue capital letters, is visible on the side of the pitcher. The background is a solid blue color.



The seal is a circular gold medal with a scalloped edge. It features the Water Quality Association logo in the center, which consists of a stylized 'W' and 'A' inside a circle. The text 'TESTED AND CERTIFIED' is written in a circle around the logo, and 'UNDER INDUSTRY STANDARDS' is written in a larger circle at the bottom. The words 'Water Quality ASSOCIATION' are written in smaller text below the logo.

THE GOLD STANDARD OF FILTER PERFORMANCE

All Brita filters are put through rigorous testing to meet NSF/ANSI standards.

Based on health contaminant reduction, per WQA certifications.

Figure 7: Dimensions of the Brita Metro 6-Cup Pitcher.

7. WARRANTY AND SUPPORT

Brita offers a 30-day, unconditional, 100% money-back guarantee on all Brita® Pitchers, Faucet Filter Systems, Water Bottles, and Filters.

For customer support or warranty claims, please call 1-800-24-BRITA.

© 2026 BRITA. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question