

[Manuals.plus](#) /

› [WOSTOKE](#) /

› WOSTOKE 10-inch Android Navigation Stereo User Manual for Honda Civic (2004-2011)

WOSTOKE 10-Quad-Core-2G-32G

WOSTOKE 10-inch Android Navigation Stereo User Manual

Model: 10-Quad-Core-2G-32G

For Honda Civic (2004-2011)

1. INTRODUCTION

This manual provides comprehensive instructions for the WOSTOKE 10-inch Android Navigation Stereo, designed specifically for Honda Civic models manufactured between 2004 and 2011. This head unit integrates advanced features such as GPS navigation, Bluetooth connectivity, Wi-Fi, and reverse camera support, enhancing your driving experience. Please read this manual thoroughly before installation and operation to ensure proper use and to maximize the product's functionality.



Figure 1: WOSTOKE 10-inch Android Navigation Stereo main unit.

2. PRODUCT FEATURES

- **10-inch IPS Touchscreen:** High-definition (1024x600 resolution), scratch-resistant, and wear-resistant display for clear visuals.
- **Android Operating System:** Provides a versatile platform for various applications and functions.
- **GPS Navigation:** Real-time satellite GPS navigation, functional with or without internet connection (with pre-downloaded maps). Supports various navigation applications.
- **Wi-Fi Connectivity:** Browse the internet, access online navigation, stream videos, and download applications.
- **Bluetooth (BT 4.0):** Enjoy wireless music streaming, hands-free calling, and navigation audio.
- **Mirror Link:** Wireless screen mirroring for iOS devices and wired for Android devices.
- **Steering Wheel Control (SWC):** Quickly switch functions using your vehicle's existing steering wheel controls.
- **Car Reverse Camera Support:** Displays video feed from a rear-view camera when reversing.

- **FM Radio:** Tune into your favorite radio stations.
- **Quad Core Processor with 2GB RAM and 32GB Storage:** Ensures smooth operation and ample space for apps and media.

3. SETUP AND INSTALLATION

3.1 Compatibility Note

This unit is designed for Honda Civic models from 2004 to 2011. It is crucial to verify your vehicle's specific configuration before installation.

3.2 Important Amplifier Information

If your Honda Civic has an original factory amplifier, you must purchase a **CANBUS decoder separately**. Without the CANBUS decoder, the stereo will produce no sound. Vehicles with a large colorful screen or factory navigation typically indicate the presence of an amplifier.




Figure 2: Important note regarding CANBUS requirement for vehicles with original amplifiers.

3.3 Package Contents

Before beginning installation, ensure all components listed below are present in your package:

Package Content




Figure 3: Contents of the product package, including the 10-inch unit, power cable, cable plug, camera input, USB cables, GPS antenna, RCA wire harness, AHD reverse camera, external mic, and crowbar tool.

- 10-inch Head Unit
- Power Cable
- Cable Plug
- Camera Input Cable
- USB Cables (4-pin and 6-pin)
- GPS Antenna
- RCA Wire Harness
- AHD Reverse Camera
- External Microphone
- Crowbar Tool (for trim removal)

3.4 Installation Overview

Installation typically involves removing the factory radio, connecting the new head unit's wiring harness to the vehicle's wiring, installing the GPS antenna and reverse camera (if applicable), and securing the new unit in the dashboard. Professional installation is recommended if you are unfamiliar with car audio wiring.

Installation Effect



Figure 4: Visual comparison of the dashboard before and after the installation of the WOSTOKE Android Navigation Stereo.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off and Basic Controls

Press and hold the power button (usually located on the front panel) to turn the unit on or off. Use the volume controls to adjust audio levels. The touchscreen interface allows for intuitive control of all functions.

4.2 GPS Navigation

The unit comes with pre-installed navigation capabilities. Connect to Wi-Fi to download map updates or use online navigation services. The GPS antenna ensures accurate real-time positioning.

Ultra Clear & Real Color



10 Inch

2.5D IPS

1280*720

Figure 5: The GPS Navigation interface displaying map data and vehicle information. Supports various navigation apps.

4.3 Bluetooth Connectivity

Pair your smartphone via Bluetooth to make hands-free calls and stream audio. Access the Bluetooth settings menu on the head unit to search for and connect to your device.

BT Function

Built-in BT, Enjoy Wireless Streaming Music, Hands-free Calling & Navigation



Figure 6: Bluetooth 4.0 functionality for hands-free calling and audio streaming. The image shows the Bluetooth calling interface on the stereo and a phone connected.

4.4 Wi-Fi Connection

Enable Wi-Fi in the settings menu to connect to a mobile hotspot or available Wi-Fi networks. This allows for online features, app downloads, and internet browsing.

GPS Navigation

Satellite GPS can locate in real time without network. With wifi connected, you can use navigation in real time




Figure 7: The Wi-Fi interface, enabling access to online content and applications.

4.5 Steering Wheel Control (SWC)

Configure the steering wheel controls through the unit's settings to manage audio, calls, and other functions without taking your hands off the wheel. Refer to the "Steering Learn" option in the settings.

2.5D IPS Screen

2.5D surface effect: scratch-resistant and wear-resistant. high-definition and sensitive. the device gives you better vision especially when watch TV or movies.

10 inch

Multi Touch Screen

IPS

With HD LCD Display

2.5D

Display Screen



Figure 8: The Steering Wheel Control learning interface, allowing customization of button functions.

4.6 Car Reverse Camera Function

When the vehicle is shifted into reverse, the display automatically switches to the rear-view camera feed, providing visual assistance for parking and maneuvering.

FM Radio

You can transfer the music to the car stereo by FM, Long press to save your favorite radio station



Figure 9: Display showing the car reverse camera view with parking guidelines.

4.7 FM Radio

Access the FM Radio application to scan for and save your preferred radio stations. Long-press on a frequency to save it as a preset.




Figure 10: The FM Radio interface, displaying frequency and station presets.

4.8 Mirror Link

Use Mirror Link to display your smartphone's screen on the head unit. This feature works wirelessly for iOS devices and requires a wired connection for Android devices.

5. MAINTENANCE

To ensure the longevity and optimal performance of your WOSTOKE Android Navigation Stereo, follow these maintenance guidelines:

- **Screen Cleaning:** Use a soft, lint-free cloth to gently wipe the touchscreen. For stubborn smudges, slightly dampen the cloth with water or a screen-safe cleaner. Avoid harsh chemicals or abrasive materials.
- **Software Updates:** Periodically check for software updates through the unit's settings menu to ensure you have the latest features and security patches.
- **Environmental Conditions:** Avoid exposing the unit to extreme temperatures, direct sunlight for prolonged periods, or

excessive moisture.

- **Cable Connections:** Ensure all cables are securely connected. Loose connections can lead to intermittent functionality.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound from speakers.	Vehicle has an original factory amplifier without a CANBUS decoder.	Purchase and install a compatible CANBUS decoder. Ensure all audio connections are secure.
GPS signal is weak or inaccurate.	GPS antenna is not properly installed or obstructed.	Ensure the GPS antenna is mounted in a clear location, free from metal obstructions, and securely connected to the unit.
Bluetooth device cannot connect.	Bluetooth is off, device is out of range, or pairing mode is not active.	Ensure Bluetooth is enabled on both the head unit and your device. Place devices close together and activate pairing mode on your phone. Try restarting both devices.
Touchscreen is unresponsive.	Temporary software glitch or screen protector interference.	Restart the head unit. If a screen protector is installed, ensure it is applied correctly and not causing issues.
Unit does not power on.	Power cable loose or fuse blown.	Check all power connections. Inspect vehicle fuses related to the stereo system and replace if necessary.

7. SPECIFICATIONS

Feature	Detail
Brand	WOSTOKE
Model	10-Quad-Core-2G-32G
Screen Size	10 Inches
Screen Resolution	1024 x 600
Operating System	Android
Processor	Quad Core
Memory (RAM)	2 GB
Storage (ROM)	32 GB
Connectivity Technology	USB, Bluetooth, Wi-Fi
Bluetooth Version	BT 4.0
Map Type	North America (pre-installed)
Mounting Type	Panel Mount
Compatible Vehicle Type	Honda Civic (2004-2011)

8. WARRANTY AND SUPPORT

The WOSTOKE Android Navigation Stereo comes with a **1-year warranty** covering non-human damage. For any questions, technical assistance, or warranty claims, please contact the seller directly. Your consultation is always welcomed. For support, please refer to your purchase platform or the contact information provided by the seller at the time of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question