

BoxWave MagnetoSync Mini Adapter

BoxWave MagnetoSync Mini Adapter Instruction Manual

Brand: BoxWave | Model: MagnetoSync Mini Adapter (ASIN: B09W4X5R7W)

INTRODUCTION

Thank you for choosing the BoxWave MagnetoSync Mini Adapter. This versatile magnetic charging and data transmission adapter is designed to provide a convenient and efficient solution for connecting various devices. With its interchangeable magnetic tips, it offers broad compatibility with Micro USB, USB Type-C, and other compatible interfaces. This manual provides detailed instructions on how to set up, operate, and maintain your MagnetoSync Mini Adapter to ensure optimal performance and longevity.

SAFETY INFORMATION

- Keep the adapter and its components away from water or other liquids to prevent electrical shock or damage.
- Do not attempt to disassemble or modify the adapter. This may void the warranty and pose safety risks.
- Avoid exposing the adapter to extreme temperatures, direct sunlight, or high humidity.
- Keep out of reach of children and pets. Small parts can be a choking hazard.
- Ensure the magnetic tips are clean and free of debris before connecting to your device to prevent poor contact or damage.
- Use only with compatible devices and power sources as specified in this manual.

PRODUCT OVERVIEW AND COMPONENTS

The BoxWave MagnetoSync Mini Adapter consists of a main USB-A adapter body and interchangeable magnetic tips. These tips allow the adapter to connect to devices with different port types.



Figure 1: Main components of the MagnetoSync Mini Adapter, including the USB-A base and various magnetic tips.



Figure 2: Detailed view of the magnetic connection mechanism and interchangeable tips.

- **USB-A Adapter Body:** The main part of the adapter that plugs into a USB-A port on a computer or charger. It features a magnetic receptacle for the tips.
- **Magnetic Tips:** Small, interchangeable connectors that plug into your device's charging port. Common types include Micro USB, USB Type-C, and i-product (Lightning compatible).

SETUP AND INSTALLATION

Follow these steps to set up and begin using your MagnetoSync Mini Adapter:

1. **Select the Correct Tip:** Identify the charging port type on your device (e.g., Micro USB, USB Type-C). Choose the corresponding magnetic tip from the adapter set.
2. **Insert the Tip into Your Device:** Carefully insert the selected magnetic tip into your device's charging port. This tip can remain in your device for convenience, protecting the port from dust and wear.
3. **Connect the Adapter Body:** Plug the USB-A end of the MagnetoSync Mini Adapter body into a compatible USB-A port on a power adapter, computer, or power bank.
4. **Attach Magnetically:** Bring the magnetic end of the adapter body close to the magnetic tip inserted in your device. The strong magnets will automatically snap together, establishing the connection.



Figure 3: Illustrating the simple magnetic connection.



Figure 4: Adapter in use, connected to a device.

OPERATING INSTRUCTIONS

Once connected, the MagnetoSync Mini Adapter facilitates both charging and data transmission, depending on the capabilities of your device and the connected USB port.

- **Charging:** When connected to a power source (e.g., wall adapter, power bank), your device will begin charging. The adapter supports various current and voltage outputs as detailed in the specifications.
- **Data Transmission:** When connected to a computer, the adapter allows for data transfer between your device and the computer. Ensure your device is set to the correct USB mode (e.g., File Transfer, MTP) if prompted.
- **540° Rotation Feature:** The magnetic connection point on the adapter body allows for a full 540-degree rotation, providing flexibility and preventing cable strain. This feature enables you to position your device comfortably while charging or transferring data.



Figure 5: Demonstrating the 540-degree rotation for flexible use.

MAINTENANCE

Proper maintenance will extend the life of your MagnetoSync Mini Adapter:

- **Cleaning:** Use a soft, dry cloth to wipe the adapter and magnetic tips. Do not use harsh chemicals or abrasive cleaners. Ensure the magnetic contact points are free of dust and metallic particles.
- **Storage:** Store the adapter and tips in a cool, dry place when not in use. Avoid tangling the adapter body with other cables.
- **Handling:** Always pull from the adapter body when disconnecting, not the cable itself, to prevent damage to the internal wiring.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not charging/connecting.	Magnetic tip not fully inserted. Dirty magnetic contacts. Incompatible power source/USB port. Damaged adapter/tip.	Ensure the magnetic tip is firmly seated in the device's port. Clean the magnetic contacts on both the adapter and tip with a dry cloth. Try a different USB port or power adapter. Inspect for visible damage. If damaged, discontinue use.
Slow charging.	Low power output from USB port. Device drawing high power.	Use a higher-wattage power adapter or a dedicated charging port. Close background apps on your device.

Problem	Possible Cause	Solution
Data transfer issues.	Device USB mode not set correctly.	On your device, select "File Transfer" or "MTP" mode when connected to a computer.
	Computer driver issues.	Ensure your computer has the necessary drivers for your device.

SPECIFICATIONS

The following are the technical specifications for the BoxWave MagnetoSync Mini Adapter:

Product Name	540° Rotate Mini Magnetic Charger
Function	Charging + Data Transmission
Current / Voltage	9V/2A, 5V/3A
Applicable Interface	Micro USB, i-product (Lightning compatible), Type-C
Material	Aluminum Alloy
Color Options	Black, Red, Purple, Green, Blue (Jet Black for this model)
Dimensions (Adapter Body)	Approx. 41.5mm (Length) x 14.2mm (Width) x 9mm (Thickness)

Product Parameters

Product Name: 540° Rotate Mini Magnetic Charger

Function: Charging + Data Transmission

Current /Voltage: 9V/2A;5V/3A

Applicable Interface: Micro / i-product / Type-C

Material: Aluminum Alloy

Color: Black / Red / Purple / Green / Blue




Figure 6: Product parameters and dimensions.

WARRANTY AND SUPPORT

BoxWave products are designed for reliability and performance. For specific warranty information, please refer to the warranty card included with your purchase or visit the official BoxWave website. For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact BoxWave customer service through their official channels. Please have your product model and purchase details ready when contacting support.

Manufacturer: BoxWave

Date First Available: September 25, 2024

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09W4X5R7W>

More documents and user manuals: **<https://manuals.plus/>**