

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [MUSICOZY](#) /

› [MUSICOZY Bluetooth Headband Sleep Headphones GH01 User Manual](#)

MUSICOZY GH01

MUSICOZY Bluetooth Headband Sleep Headphones

MODEL: GH01

Brand: MUSICOZY

INTRODUCTION

This manual provides essential instructions for the safe and effective use of your MUSICOZY Bluetooth Headband Sleep Headphones. Please read this manual thoroughly before operating the device and retain it for future reference.



Image: The MUSICOZY Bluetooth Headband in Lavender Purple, showcasing its integrated control panel.

WHAT'S IN THE BOX

- 1 x MUSICOZY Bluetooth Headband
- 1 x USB to USB-C Cable
- 1 x User Manual (this document)

PRODUCT FEATURES

- **Versatile Design:** Functions as both sleep headphones and a sports headband, suitable for various activities including workouts, running, yoga, meditation, and travel.
- **Bluetooth 5.4 Technology:** Ensures stable and compatible wireless connection with electronic devices.
- **Immersive Stereo Sound:** Equipped with 40mm composite drivers for clear audio, rich bass, and balanced treble.
- **Integrated Microphone:** Allows for hands-free calling.
- **Extended Playtime:** Up to 14 hours of continuous audio playback on a single 1-2 hour charge.
- **Comfortable Material:** Made from highly elastic, breathable, sweat-absorbent, soft, and hypoallergenic fabric.
- **Removable Electronics:** Allows for easy washing of the fabric headband.

SETUP & PAIRING

1. **Charge the Headband:** Before first use, fully charge the headband using the provided USB to USB-C cable. Refer to the Charging section for details.
2. **Power On:** Locate the control panel on the headband. Press and hold the Power button (P) for approximately 1-2 seconds until you hear an audible prompt indicating power on and pairing mode (e.g., "Power On," "Pairing"). The indicator light on the control panel will flash.
3. **Activate Bluetooth:** On your mobile device (e.g., smartphone, tablet), go to the Bluetooth settings and ensure Bluetooth is enabled.
4. **Select Device:** In the list of available Bluetooth devices, locate and select "MUSICOZY" (or a similar name).
5. **Confirm Connection:** Once successfully paired, you will hear an audible confirmation (e.g., "Connected"), and the indicator light on the control panel may change to a solid color or flash less frequently.

Your browser does not support the video tag.

Video: A demonstration of the MUSICOZY Bluetooth Headband's features and comfortable use.

OPERATING INSTRUCTIONS

Control Panel Overview

Hear the Difference



Unmatched sound quality that redefines what you expect from audio.



HIFI

HIFI Sound

ENC

ENC Clear

LDAC

LDAC Scheme



Bluetooth 5.4



Transparency



CLIMATE
PLEDGE
FRIENDLY

Image: Detailed view of the control panel with Power, Volume Up/Next Track, and Volume Down/Previous Track buttons.

- **Power Button ():** Press and hold to Power On/Off. Short press to Play/Pause music or Answer/End calls.
- **Volume Up / Next Track (+):** Short press to increase volume. Long press to skip to the next track.
- **Volume Down / Previous Track (-):** Short press to decrease volume. Long press to go to the previous track.

Music Playback

- **Play/Pause:** Short press the Power button ().
- **Adjust Volume:** Short press the (+) or (-) buttons.
- **Skip Tracks:** Long press the (+) button for the next track, or the (-) button for the previous track.

Call Handling

- **Answer/End Call:** Short press the Power button () when a call comes in or during a call.
- **Reject Call:** Press and hold the Power button () for approximately 2 seconds when a call comes in.
- **Redial Last Number:** Double-press the Power button ().

Your browser does not support the video tag.

Video: A user demonstrating the controls and functionality of the Bluetooth Headband.

CHARGING

To charge your MUSICOZY Bluetooth Headband:

1. Locate the charging port on the control panel.
2. Connect the provided USB to USB-C cable to the charging port.
3. Plug the other end of the USB cable into a compatible USB power source (e.g., computer, wall adapter).
4. The indicator light will typically show red during charging and turn blue or off when fully charged.

A full charge takes approximately 1-2 hours and provides up to 14 hours of playtime.



More Time, More Power

The E5 battery delivers extended usage for all your needs.

Image: The MUSICOZY Bluetooth Headband being charged via its USB-C port.

MAINTENANCE & CARE

Washing Instructions

The fabric headband is machine washable after removing the electronic components.

1. Gently open the small opening on the inside of the headband to access the electronic module.
2. Carefully remove the control panel, speakers, and wiring from the headband.
3. Machine wash the fabric headband in cold water on a gentle cycle. Air dry or tumble dry on low heat.
4. Once the headband is completely dry, reinsert the electronic components into their designated pockets, ensuring the control panel is correctly positioned.

One Touch to Freedom

Effortless control for a seamless musical journey.



Image: The electronic module and speakers being carefully removed from the headband for cleaning.

General Care

- Avoid exposing the electronic components to water or excessive moisture.
- Store the headband in a clean, dry place when not in use.
- Do not attempt to disassemble or repair the electronic components yourself. Contact support if issues arise.

TROUBLESHOOTING

- **Device Not Powering On:** Ensure the headband is fully charged. Connect it to a power source and check the charging indicator light.
- **Unable to Pair:** Make sure the headband is in pairing mode (flashing indicator light). Turn off and on your device's Bluetooth, then try searching again. Ensure the headband is within the Bluetooth range (up to 25

meters).

- **No Sound:** Check the volume levels on both the headband and your connected device. Ensure the headband is successfully paired.
- **Charging Port Difficulty:** If the charging cable is difficult to insert, ensure it is aligned correctly. Avoid forcing the connection to prevent damage.

SPECIFICATIONS

Model Name	Sleep Headphones Bluetooth Headband
Model Number	GH01
Connectivity Technology	Bluetooth 5.4
Bluetooth Range	25 Meters
Audio Driver Size	40 Millimeters
Noise Control	Sound Isolation
Battery Life	Up to 14 Hours
Charging Time	1-2 Hours
Water Resistance Level	Not Water Resistant
Item Weight	2.46 ounces (0.07 Kilograms)
Product Dimensions	7.87 x 3.94 x 0.39 inches

WARRANTY & SUPPORT

MUSICOZY stands behind its products. This product comes with a one-year manufacturer's warranty. For any issues or inquiries, please contact our after-sales team via email. We aim to provide a satisfactory solution within 6 hours.

Additionally, a 30-day refund policy is available if you are not satisfied with your purchase.

SAFETY INFORMATION

Please observe the following safety guidelines:

- Do not expose the device to extreme temperatures or direct sunlight.
- Keep the device away from water and liquids, as it is not water resistant.
- Avoid using the device at excessively high volumes for prolonged periods to prevent hearing damage.
- Ensure the device is clean and dry before charging.
- Keep out of reach of children.

LEGAL DISCLAIMER

At MUSICOZY, we prioritize quality control. Our products are manufactured using high-quality materials and current Bluetooth technology. This product is intended for personal use as described in this manual. Any unauthorized modification or misuse of the product may void the warranty and could result in injury or damage. MUSICOZY is not responsible for any damages or injuries resulting from improper use of this

product.