YOTON YD105

YOTON Portable DVD Player Instruction Manual

Model: YD105

Introduction

This manual provides essential information for the safe and efficient operation of your YOTON Portable DVD Player. Please read it thoroughly before use and retain it for future reference.

Key Features

- **Immersive Movie Experience:** 14.1-inch HD Swivel Screen (1280x800 resolution) with dual stereo speakers for stunning visuals and immersive sound.
- **Large Capacity Built-in Battery:** Provides 4-6 hours of playback on a full charge, sufficient for 2-3 movies. Includes a certified car charger for on-the-go use.
- **Flexible Rotating Screen:** The 14.1-inch screen rotates 270° and flips 180°, offering versatile viewing angles.
- **Multi-Device Connectivity:** Sync screen to TV, projector, or other compatible portable DVD players using the AV cable for a larger viewing experience.
- **Wide Media Compatibility:** Supports various disc formats (VCD, DVD, SVCD, etc.) and video/audio/image file formats (AVI, MPG, MP3, JPEG) via USB/SD card. Note: Does not support Blu-Ray discs.

Product Overview



Figure 1: YOTON Portable DVD Player and included remote control.



Figure 2: Side view of the player highlighting USB, SD Card, 3.5mm Audio Port, AV Out, AV In, Off/On switch, DC In 12V, and Game USB ports.

Components

- Portable DVD Player (Model YD105)
- Remote Control
- AC Charger
- Car Charger
- 3-in-1 AV Cable
- User Manual

Setup

Initial Battery Charge

Before initial use, fully recharge the built-in battery for at least 12 hours. The red LED indicator on the front of the unit will be on during charging and will turn off when fully charged. The player can be used immediately when connected to AC power.

Your browser does not support the video tag.

Video: Demonstrates how to charge the YOTON Portable DVD Player using the included AC adapter. The red LED indicates charging status.

Screen Protection & Disc Tray Preparation

Remove the screen protector from the display (peel from the green label). Before inserting a disc, remove the white cardboard piece inside the player's disc tray. Avoid touching the laser head or other internal parts with your hands.

Your browser does not support the video tag.

Video: Shows the physical features of the YOTON Portable DVD Player, including the disc tray and screen swivel.

Operating Instructions

Basic Playback

Insert a compatible DVD or CD into the disc tray and close the lid. The player will automatically load and begin playback. Use the control buttons on the unit or the remote control for playback functions (play, pause, stop, fast forward, rewind, track changes, volume adjustment).

Your browser does not support the video tag.

Video: Demonstrates basic playback of a DVD on the YOTON Portable DVD Player, including disc insertion and button functions.

Swivel Screen Adjustment

The screen can be rotated 270° and flipped 180° to achieve optimal viewing angles. This is particularly useful for in-car use or shared viewing.



Figure 3: The flexible rotating screen allows for 270° rotation and 180° flip for versatile viewing.

Last Memory Function

The player features a last memory function, allowing it to resume playback from where it was last stopped, even after being powered off.




Figure 4: The player remembers the last playback position even after being turned off and on.

Media Playback

The YOTON Portable DVD Player supports a wide range of media formats:

- **Disc Formats:** VCD1.1, VCD2.0, VCD3.0, SVCD, DVCD, CVD, MINI DVD, DVD-5, DVD-9, DVD-10, DVD-18, DVD+R, DVD-R, DVD-RW, DVD+RW.
- **Video File Formats:** AVI, MPG, MPEG, DAT, VOB, OGG, ASF (resolution up to 720x480).
- **Audio File Formats:** MP3, WMA.
- **Image File Formats:** JPEG (resolution up to 2650x1440).
- **USB/SD Card Support:** Up to 32GB.

Note: This unit does not support Blu-Ray discs.



Figure 5: The player supports region-free playback for various DVD formats.

Connectivity

The player can be connected to external displays for a larger viewing experience:

- **Sync to TV/Projector:** Use the included 3-in-1 AV cable to connect the player's AV Out port to your TV or projector's AV In ports.
- **Sync to Similar Player:** Connect two YOTON portable DVD players using the AV In/Out ports for synchronized playback.



Figure 6: Connectivity options for syncing the player's screen to a TV, projector, or another compatible player.

Power Options

Your YOTON Portable DVD Player offers multiple power options:

- **Built-in Battery:** Provides 4-6 hours of playback on a full charge.
- **AC Adapter:** For home use and charging.
- **Car Charger:** For use and charging in vehicles.




Figure 7: The player can be powered by AC adapters, a car charger, or its built-in battery.

Maintenance

- Keep the player clean by wiping with a soft, dry cloth.
- Avoid exposing the player to extreme temperatures or direct sunlight.
- Handle discs carefully to prevent scratches, which can affect playback quality.

Troubleshooting

Problem	Possible Cause / Solution
DVD player does not turn on.	Ensure the machine is fully charged. When not in use, turn the power switch to the OFF position to save power.

Problem	Possible Cause / Solution
Video does not play.	Verify the disc, USB/SD card, and file format meet the requirements (e.g., video files 720x480). Mechanical parts may be damaged during transportation.
No HDMI port to connect to TV.	Use the included 3-in-1 AV cable. If your TV only has HDMI ports, purchase an HDMI to 3-in-1 AV Cable Adapter.
Low volume.	Consider purchasing an external portable mini speaker and plug it into the speaker port for enhanced audio.
No backlight on screen.	Ensure brightness settings are adjusted. If the issue persists, contact customer service.

Specifications

- **Model Number:** YD105
- **Screen Size:** 14.1 Inches (Visible diagonal: 11" / 27 cm)
- **Display Type:** LCD
- **Resolution:** 1280x800
- **Product Dimensions:** 10.24 x 7.48 x 1.57 inches
- **Item Weight:** 3.01 pounds
- **Battery:** 1 Lithium Ion battery (included)
- **Color:** Ivory white

Warranty & Support

All YOTON products are covered by a 1-year warranty. For any concerns or assistance, please contact our professional team. We offer 24-hour friendly customer support and provide free new parts for any broken or missing components. You can find more detailed operation instructions on the Amazon product page or by contacting YOTON directly.

© 2025 YOTON. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

My YOTON YD105 portable DVD player says 'loading' when I insert a disc, and after about 30 seconds, it stops spinning and still says 'loading', preventing playback. I have tried multiple DVDs with the same result. What could be the issue?

It sounds like your YOTON YD105 portable DVD player may be having trouble reading the discs. Here are a few troubleshooting steps based on the manual:Clean the laser: Dust or smudges on the laser...

Read full answer