

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Uthfy](#) /
- › [Uthfy Evaporative Air Cooler User Manual](#)

**Uthfy HY-ATF-015L-W**

# Uthfy Evaporative Air Cooler Instruction Manual

Model: HY-ATF-015L-W

Brand: Uthfy

## INTRODUCTION

Thank you for choosing the Uthfy Evaporative Air Cooler. This 3-in-1 portable tower fan is designed to provide a comfortable environment by blowing air, humidifying, and cooling. It is an energy-efficient solution for dry, hot rooms, offering a refreshing breeze with added humidity.

This evaporative cooler features an air speed of up to 180 CFM. Hot, dry air passes through a wet cooling pad, absorbing heat and recirculating cooler, humidified air into the room. For enhanced cooling, two ice boxes are included.

# Three Effect Unite

The 3 in 1 air cooler with integrated effects of blowing



*Image: The 3-in-1 functionality of the Uthfy Evaporative Air Cooler, illustrating its use as a fan (without water), humidifier (with water), and air cooler (cooling mode).*

The unit offers three distinct modes (Normal, Natural Wind, Sleep) and three fan speeds, along with a 1-12 hour timer and convenient remote control functionality. Its compact 30-inch tall design with a stable base allows it to fit into various spaces, including living rooms, bedrooms, kitchens, and offices.

## SETUP GUIDE

Before first use, ensure all packaging materials are removed. Place the air cooler on a flat, stable surface.

### Adding Water and Ice Packs

1. Locate the removable water tank at the bottom rear of the unit. Gently pull it out.
2. Fill the water tank with clean, cool water. Do not exceed the 'MAX' fill line indicated on the tank. The 0.8-gallon tank can run continuously for 6-10 hours depending on ambient humidity.
3. For enhanced cooling, fill the provided ice boxes with water and freeze them. Once frozen, place the ice boxes into the water tank.

4. Carefully slide the water tank back into the unit until it clicks securely into place.

## How Cooling Best \*



\*Tip: Great with a dry climate, and leave windows open for long-time use to reduce the high humid

*Image: Visual guide showing the process of freezing ice boxes, adding water to the tank, and initiating the cooling function.*

# Removable and Washable Water Tank

The water tank can be easily removed for convenient water filling and cleaning



*Image: The removable water tank with clear MAX/MIN indicators and the placement of ice boxes for cooling.*

## Official Product Video: How Air Cooler Works

*Video: A detailed demonstration by the vendor on how the evaporative air cooler functions, including water filling and cooling mechanisms.*

## OPERATING INSTRUCTIONS

The Uthfy Evaporative Air Cooler can be operated using the touch control panel on top of the unit or the included remote control.

# Multifunctional Remote Control

Delicate and compact, comfortable to hold



Low/medium/  
High Speeds



Normal/ Nature/  
Sleep Mode



1-12h Auto-off  
Timer



Automatic/Manual  
Swing



*Image: The remote control highlighting its various functions for operating the air cooler.*

## Control Panel / Remote Functions

- **Power Button:** Turns the unit On/Off.
- **Speed Button:** Cycles through 3 fan speeds: Low, Medium, High.
- **Mode Button:** Selects operating mode: Normal (steady airflow), Natural Wind (variable airflow simulating natural breeze), Sleep (soft, quiet wind for undisturbed sleep).
- **Timer Button:** Sets the auto-off timer from 1 to 12 hours.
- **Oscillation Button:** Activates automatic side-to-side oscillation (110°) for wider air distribution. Vertical airflow can be adjusted manually.
- **Cooling Button:** Activates the evaporative cooling function, circulating water from the tank through the cooling pad.

## Official Product Video: Air Cooler Operation

*Video: A comprehensive video demonstrating the various operational modes and features of the air cooler, including speed, mode, timer, and oscillation settings.*

## MAINTENANCE AND CLEANING

Regular cleaning and maintenance are essential to ensure optimal performance and longevity of your air cooler.

### Water Tank Cleaning

The water tank is removable for easy cleaning. Periodically remove the tank, empty any remaining water, and clean it with a mild detergent and water. Rinse thoroughly before refilling.

### Cooling Pad and Rear Grille

The cooling pad and rear grille are also removable for cleaning. Refer to the full User Manual (PDF) for detailed instructions on how to safely remove and clean these components.

## TROUBLESHOOTING

If you encounter any issues with your Uthfy Evaporative Air Cooler, please refer to the comprehensive User Manual (PDF) provided with your product for detailed troubleshooting steps. Common issues may include insufficient cooling, unusual noises, or power problems.

## SPECIFICATIONS

Feature	Detail
Brand	Uthfy
Model Name	HY-ATF-015L-W
Mounting Type	Freestanding
Special Feature	Manual
Color	White
Air Flow Capacity	1800 Cubic Feet Per Minute
Controls Type	Touch and Remote Control
Reservoir Capacity	0.8 Gallons
Recommended Uses For Product	Residential, Cooling, Air Circulation
Included Components	User Manual, Air Cooler, Remote Control, 4 Ice Packs
Noise Level	45 dB

Number of Speeds	3
Product Dimensions	8.6"D x 11"W x 30"H
Voltage	120
Manufacturer	Uthfy
UPC	798623653108
Item Weight	9 pounds
ASIN	B09W9987D7
Item model number	HY-ATF-015L-W

## WARRANTY AND SUPPORT

The Uthfy Evaporative Air Cooler comes with a **1-year manufacturer warranty**.

For any support inquiries, troubleshooting assistance, or warranty claims, please refer to the contact information provided in your User Manual (PDF).

## IMPORTANT SAFETY INFORMATION


Please read all safety information carefully before operating the appliance. A dedicated Safety Information (PDF) document is available for your reference:

[Download Safety Information \(PDF\)](#)

For complete operational details, maintenance guidelines, and troubleshooting, please refer to the full User Manual (PDF):

[Download User Manual \(PDF\)](#)

## Related Documents - HY-ATF-015L-W

	<p><a href="#">Uthfy Evaporative Air Cooler User Guide</a></p> <p>User guide for the Uthfy Evaporative Air Cooler, model HY-43Y. Includes important safety instructions, operating instructions, parts list, and troubleshooting.</p>
	<p><a href="#">Uthfy Electronic Control Tower Fan Owner's Manual - Model JTF-14-R</a></p> <p>This owner's manual provides detailed instructions for the Uthfy Electronic Control Tower Fan, Model JTF-14-R. It covers assembly, operation, technical specifications, maintenance, and safety guidelines for optimal use.</p>

	<p><a href="#">JH-MTF01R Evaporative Air Cooler Operation User Manual</a></p> <p>This user manual provides instructions for operating and maintaining the JH-MTF01R Evaporative Air Cooler. It includes important safety instructions, product details, assembly guidance, operating instructions for the control panel and remote control, and maintenance tips.</p>
	<p><a href="#">Uthfy Air Cooler User Guide</a></p> <p>User guide for the Uthfy Air Cooler, model HY-66R. Learn about important safety instructions, how to use and clean your air cooler, and customer care information.</p>
	<p><a href="#">Uthfy JDAC75 JDAC75R Air Cooler Instruction Manual</a></p> <p>Comprehensive instruction manual for the Uthfy JDAC75 and JDAC75R evaporative air coolers. Includes details on operation, installation, technical specifications, safety precautions, and maintenance.</p>
	<p><a href="#">JH-60AI-H Mobile Evaporative Air Cooler Operation User Manual</a></p> <p>User manual for the JH-60AI-H Mobile Evaporative Air Cooler, detailing operation, safety instructions, cleaning, maintenance, and troubleshooting.</p>