

- Manuals.plus /
- › Lamshaw /
 - › LIGE Smart Watch Band Instruction Manual

Lamshaw Smart Watch Band

LIGE Smart Watch Band Instruction Manual

Silicone Replacement Soft Band Wristbands Straps

1. PRODUCT OVERVIEW

This manual provides instructions for the Lamshaw Silicone Replacement Smart Watch Bands, designed for compatibility with LIGE I9M 1.3 Smart Watch and LIGE NK091.32" Smart Watch models. These bands are crafted from high-quality elastomer, offering a soft, lightweight, and durable solution for daily wear. They feature a unique slim design for breathability and comfort.



Figure 1.1: Various color options for the Lamshaw Smart Watch Bands.



Compatible models: BW220A, BW0264E-LD, BW0264F

Figure 1.2: Smartwatch with an installed Lamshaw band, demonstrating compatibility.



Figure 1.3: Close-up view of the watch bands, highlighting the quick-release pins for easy installation.

2. SETUP

Attaching the Band to Your Smart Watch

The Lamshaw Smart Watch Bands are designed for easy installation and removal, featuring watch lugs on both ends that securely lock onto your watch interface.

1. **Identify Band Orientation:** Each band consists of two pieces. Identify the longer piece (with more holes) and the shorter piece (with the buckle).
2. **Locate Quick-Release Pins:** On the underside of each band piece, you will find a small metal pin with a spring-

loaded lever.

- 3. **Insert One End:** Gently push the quick-release pin inwards using the lever. Align one end of the pin with the corresponding lug hole on your smartwatch.
- 4. **Secure the Band:** While holding the pin inwards, guide the other end of the pin into the opposite lug hole. Release the lever, ensuring both ends of the pin are securely seated within the watch lugs. You should hear a slight click or feel it lock into place.
- 5. **Verify Connection:** Gently tug on the band to ensure it is firmly attached to the watch and does not come loose.
- 6. **Repeat for Second Piece:** Follow the same steps to attach the second piece of the band to the other side of your smartwatch.

3. OPERATING

Once installed, the Lamshaw Smart Watch Band operates as a standard watch strap. Adjust the band to a comfortable fit on your wrist using the stainless steel tang buckle. Ensure the fit is snug enough for accurate sensor readings from your smartwatch, but not so tight as to restrict circulation or cause discomfort. The multiple holes in the band allow for a wide range of wrist sizes and precise adjustment for optimal comfort and sensor performance.

4. MAINTENANCE

Proper care will extend the life and appearance of your silicone watch bands.

- **Cleaning:** Regularly clean your band with a soft, damp cloth. For deeper cleaning, use mild soap and water. Rinse thoroughly and dry completely before reattaching to your watch.
- **Avoid Harsh Chemicals:** Do not expose the band to strong chemicals, solvents, or abrasive cleaners, as these can damage the silicone material.
- **Storage:** When not in use, store the band in a cool, dry place away from direct sunlight to prevent discoloration or degradation of the material.
- **Avoid Extreme Temperatures:** Prolonged exposure to extremely high or low temperatures can affect the material's integrity.

5. TROUBLESHOOTING

Below are common issues and their potential solutions:

Issue	Possible Cause	Solution
Band does not attach securely.	Quick-release pin not fully engaged; incorrect band size for watch lugs.	Ensure the quick-release pin is fully retracted and then released into both lug holes. Verify the band is the correct size for your watch model.
Skin irritation.	Band is too tight; accumulation of sweat/dirt; allergic reaction.	Loosen the band for better air circulation. Clean the band regularly. If irritation persists, discontinue use and consult a dermatologist.

Issue	Possible Cause	Solution
Band appears discolored or worn.	Exposure to harsh chemicals, prolonged sunlight, or heavy use.	Clean as per maintenance instructions. Avoid exposure to harsh conditions. Consider replacement if wear is significant.

6. SPECIFICATIONS

Feature	Detail
Material	High-quality Elastomer (Silicone)
Buckle Material	Stainless Steel
Clasp Type	Tang Buckle
Compatibility	LIGE I9M 1.3 Smart Watch, LIGE NK091.32" Smart Watch
Design	Slim, breathable, quick-release pins

7. WARRANTY AND SUPPORT

Lamshaw stands behind the quality of its products. If you receive defective items, please contact us immediately. For 30 days after the date of purchase, we address all quality-related issues with a replacement or refund. For further assistance or inquiries, please refer to the contact information provided by your retailer or the official Lamshaw support channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09W9F3YY1>

More documents and user manuals: <https://manuals.plus/>