Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Oraimo UltraCleaner S Corded

Oraimo Stick Vacuum User Manual

Model: UltraCleaner S Corded

Brand: Oraimo

1. Introduction

Thank you for choosing the Oraimo Stick Vacuum. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new vacuum cleaner. Please read this manual thoroughly before first use and retain it for future reference.



Figure 1: Oraimo Stick Vacuum and its packaging. The image shows the vacuum in its full stick configuration and as a handheld unit, alongside its green product box.

Important Safety Instructions

- Always unplug the vacuum cleaner from the electrical outlet before cleaning or servicing.
- Do not use the vacuum cleaner on wet surfaces or to pick up liquids.
- Do not pick up burning or smoking materials, such as cigarettes, matches, or hot ashes.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with a damaged cord or plug. If the appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.

2. Product Components

Your Oraimo Stick Vacuum comes with several components designed for versatile cleaning. Familiarize yourself with each part:

1. **Main Unit:** Contains the 600W motor, dust cup, and handle.
2. **Extension Wand:** Connects the main unit to the floor brush for stick vacuum mode.
3. **Motorized LED Floor Brush:** Equipped with LED lights and a rotating brush for effective cleaning on various floor types.
4. **2-in-1 Long Crevice and Brush Tool:** A versatile attachment for cleaning tight spaces, corners, and delicate surfaces.
5. **Power Cord:** A 29.5 FT long cord for extended reach without frequent outlet changes.



Figure 2: Illustration of the vacuum's versatility with different attachments. This image shows the main unit, extension wand, floor brush, and the 2-in-1 crevice tool being used in various cleaning scenarios, highlighting its adaptability.

3. Setup and Assembly

Assembling your Oraimo Stick Vacuum is quick and easy. Follow these steps:

1. **Attach the Extension Wand:** Insert the extension wand into the main unit until it clicks securely into place.
2. **Attach the Floor Brush:** Connect the motorized LED floor brush to the other end of the extension wand, ensuring

it clicks firmly.

3. **For Handheld Use:** To use as a handheld vacuum, detach the extension wand and floor brush. Attach the 2-in-1 crevice and brush tool directly to the main unit.
4. **Cord Management:** The 29.5 FT power cord can be managed using the integrated cord storage hooks on the main unit for neatness during storage and use.



Figure 3: The Oraimo Stick Vacuum stored neatly on a wall mount. This image demonstrates the compact storage solution for the vacuum, showing it upright against a wall with its cord wrapped around a dedicated hook.

4. Operating Instructions

Your Oraimo Stick Vacuum is designed for powerful and efficient cleaning across various surfaces.

General Operation

1. **Power On:** Plug the power cord into a suitable electrical outlet. Press the power button located on the main unit to turn the vacuum on.
2. **Cleaning Surfaces:**

- **Hard Floors & Low-Pile Carpets:** Use the motorized LED floor brush for effective cleaning of dust, crumbs, pet hair, and food residue. The LED lights illuminate dark areas for thorough cleaning.
- **Tight Spaces & Upholstery:** Detach the extension wand and use the main unit with the 2-in-1 crevice and brush tool for cleaning corners, crevices, stairs, and furniture.

3. **Maneuverability:** The motorized LED floor brush head can be rotated by 120° horizontally and 90° vertically, allowing for flexible cleaning around furniture and in tight spots.
4. **Cord Management During Use:** Utilize the cord clip to keep the 29.5 FT cord out of your way while cleaning, preventing tangles and ensuring smooth operation.



Figure 4: A woman demonstrating the use of the Oraimo Stick Vacuum on a hard floor. The image highlights the vacuum's ability to pick up various debris types like dust, crumbs, pet hair, and food residue, showcasing its powerful suction.




Figure 5: Detailed view of the flexible LED motorized brush head. This image illustrates the brush head's ability to rotate 120 degrees horizontally and 90 degrees vertically, along with its integrated LED lights for improved visibility under furniture.



Figure 6: An overhead diagram illustrating the extensive reach of the 29.5 FT power cord. The image shows a large room layout with the vacuum's cord covering a significant area, indicating less need for frequent outlet changes.

5. Maintenance and Care

Regular maintenance ensures optimal performance and extends the lifespan of your Oraimo Stick Vacuum.

Dust Cup Emptying

- Empty the dust cup regularly, especially when debris reaches the "MAX" fill line.
- To empty, detach the dust cup from the main unit and open the bottom flap over a trash bin.

Filter Cleaning

The Oraimo Stick Vacuum features washable filters to maintain strong suction and prevent secondary air pollution.

1. **Remove Filters:** Twist and pull to remove the filter assembly from the dust cup.
2. **Wash Filters:** Rinse the filters under cold running water until the water runs clear. Do not use detergent.

3. **Dry Filters:** Allow filters to air dry completely for at least 24 hours before reinserting them. Ensure they are completely dry to prevent mold or damage to the motor.
4. **Reassemble:** Once dry, reinsert the filters into the dust cup and reattach the dust cup to the main unit.

Brush Roll Cleaning

- Periodically check the motorized floor brush for tangled hair or debris.
- Carefully remove any obstructions using scissors or a brush.

6. Troubleshooting

If you encounter issues with your Oraimo Stick Vacuum, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum does not turn on.	Not plugged in; power outlet issue; damaged cord.	Ensure cord is securely plugged in. Test outlet with another appliance. Inspect cord for damage; if damaged, contact support.
Loss of suction.	Dust cup full; clogged filter; blockage in hose/brush.	Empty dust cup. Clean or replace filters. Check for and remove any blockages in the extension wand, floor brush, or main unit intake.
Motorized brush not spinning.	Brush roll tangled with hair/debris; connection issue.	Clean brush roll, removing any obstructions. Ensure floor brush is securely attached to the extension wand or main unit.
Unusual noise.	Blockage; worn-out part.	Check for and remove any blockages. If noise persists, discontinue use and contact customer support.

7. Product Specifications

Feature	Specification
Brand	Oraimo
Model	UltraCleaner S Corded
Motor Power	600W (Upgraded Motor)
Cord Length	29.5 FT
Special Features	6-in-1 Multifunctional, LED Motorized Floor Brush, Cord Storage, Lightweight
Filter Type	Washable Filters (Multi-cone filtration system)
Included Components	Main Unit, Extension Wand, Motorized LED Floor Brush, 2-in-1 Long Crevice and Brush Tool
Is Cordless?	No (Corded)



Figure 7: An illustrative diagram showcasing the internal components of the 600W upgraded motor. This image emphasizes the powerful engineering behind the vacuum's suction capabilities.

8. Warranty and Support

Oraimo products are manufactured to the highest quality standards. For warranty information, technical support, or service inquiries, please contact Oraimo customer support through their official website or the retailer where the product was purchased.

For the most up-to-date support information, please visit the official Oraimo website:www.oraimo.com

© 2023 Oraimo. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the

question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09W9XGLGB

More documents and user manuals: **https://manuals.plus/**