



Manuals.plus /

› Coleman /

› Coleman Canopy Sun Shelter Instruction Manual

Coleman Canopy Sun Shelter B09WDKQ32J

Coleman Canopy Sun Shelter Instruction Manual

Model: Canopy Sun Shelter (B09WDKQ32J)

Introduction	Safety Information	Package Contents	Setup	Operating	Maintenance
	Troubleshooting	Specifications	Warranty & Support		

1. INTRODUCTION

Thank you for choosing the Coleman Canopy Sun Shelter. This manual provides essential information for the safe and efficient setup, operation, and maintenance of your sun shelter. Designed for quick assembly, this canopy offers reliable UPF 50+ sun protection for various outdoor activities such as camping, tailgating, and sporting events. Please read these instructions thoroughly before initial use and retain them for future reference.

This sun shelter is available in various sizes, including 7x5ft, 10x10ft, and 12x12ft, providing up to 144 square feet of coverage depending on the model purchased.

2. SAFETY INFORMATION

WARNING: Failure to follow these safety instructions could result in injury or damage to the product.

- Always secure the shelter with the included ground stakes and guy lines when using in windy conditions to prevent uplift and collapse.
- Keep a safe distance from heat sources and never use near open flames, barbecues, or heaters to prevent fire hazards. The fabric is not fireproof.
- Avoid prolonged exposure to direct sunlight to minimize UV degradation of the fabric over time. While the UVGuard™ material provides UPF 50+ sun protection, continuous exposure to harsh UV rays can affect material longevity.
- Do not use the canopy as a permanent structure. It is designed for temporary outdoor use.
- Ensure all poles are fully extended and locked into place before use to maintain structural integrity.
- Do not hang heavy objects from the frame.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- Coleman Canopy Sun Shelter (one-piece frame with canopy fabric attached)
- Wheeled Carry Bag
- Ground Stakes
- Guy Lines

4. SETUP INSTRUCTIONS

The Coleman Canopy Sun Shelter features an instant setup design, allowing for assembly in approximately 3 minutes. Follow these steps for quick and easy setup:

1. **Unpack the Shelter:** Remove the sun shelter from its wheeled carry bag and place it in the desired setup location. Ensure the area is clear of obstructions and level.
2. **Extend the Frame:** With two people, grasp opposite corners of the frame. Slowly pull the frame outwards, allowing the legs to extend partially. The one-piece frame is designed for simple, intuitive assembly.
3. **Lock the Legs:** Continue to extend the frame until the legs are fully extended. Use the Comfort Grip™ technology to lock each leg into place. This feature ensures a secure, pinch-free pole extension.
4. **Adjust Height (if applicable):** Some models may feature adjustable height settings. If your model allows, adjust the leg height to your preferred level, ensuring all legs are set to the same height for stability.
5. **Secure the Canopy:** Once the frame is fully extended and locked, ensure the canopy fabric is taut and properly seated over the frame.
6. **Stake Down the Shelter:** For optimal stability and safety, especially in windy conditions, use the provided ground stakes and guy lines. Securely stake down each leg of the canopy and attach guy lines to the corners, anchoring them firmly into the ground at an appropriate angle.



This image shows the Coleman Canopy Sun Shelter fully set up, demonstrating its primary function as a sun protection solution for outdoor activities.

5. OPERATING THE SUN SHELTER

The Coleman Canopy Sun Shelter is designed to provide temporary shade and protection from the sun. It is ideal for:

- **Sun Protection:** The UVGuard™ material offers UPF 50+ sun protection, making it suitable for sunny days.
- **Outdoor Gatherings:** Use it as a covered dining tent at campsites, tailgates, picnics, or other outdoor events.
- **Temporary Shelter:** Provides a quick and easy shelter solution for various recreational activities.

Important: This shelter is water resistant, but not fully waterproof. In heavy rain, water may seep through or collect on the canopy, potentially causing damage. It is recommended to take down the shelter during severe weather conditions, including strong winds, heavy rain, or thunderstorms.

6. MAINTENANCE

Proper care and maintenance will extend the life of your Coleman Canopy Sun Shelter:

- **Cleaning:** Clean the canopy fabric with mild soap and water. Do not use harsh detergents, bleach, or abrasive cleaners, as these can damage the UVGuard™ coating and fabric. Rinse thoroughly and allow to air dry completely before storage.
- **Drying:** Always ensure the canopy fabric and frame are completely dry before packing away. Storing a damp shelter can lead to mildew, mold, and fabric degradation.
- **Storage:** Fold the one-piece frame carefully and place it back into the wheeled carry bag. Store the shelter in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the frame, fabric, stakes, and guy lines for any signs of wear, damage, or corrosion. Replace any damaged components as needed.

7. TROUBLESHOOTING

Canopy is difficult to set up or take down:

Ensure all locking mechanisms are disengaged when taking down. During setup, ensure the frame is fully extended and the Comfort Grip™ mechanisms are properly engaged. Lubricate moving parts of the frame with a silicone-based spray if they become stiff.

Canopy is unstable or sways in light wind:

Verify that all legs are fully extended and locked. Ensure ground stakes are firmly inserted into the ground and guy lines are properly tensioned and anchored. Always use all provided stakes and guy lines.

Water pooling on the canopy:

While the canopy is water resistant, prolonged or heavy rain can cause pooling. Ensure the canopy is taut and properly stretched over the frame. If pooling occurs, gently push up from underneath to release the water. Consider taking down the shelter during heavy rainfall.

Canopy height is not adjustable:

Some models of the Coleman Canopy Sun Shelter are designed with a fixed height for simplicity and stability. Please refer to your product packaging or specifications to confirm if your specific model features adjustable legs. If not, the height is fixed as designed.

8. SPECIFICATIONS

Brand	Coleman
Model	Canopy Sun Shelter (B09WDKQ32J)
Material	Polyguard 2X™ (Polyester) fabric, Metal frame (Aluminum, Alloy Steel poles)
UV Protection	UVGuard™ UPF 50+
Water Resistance Level	Water Resistant
Frame Type	Pop-up/Instant
Setup Time	Approximately 3 minutes
Coverage (Max)	144 square feet (for 12x12ft model)
Dimensions (12x12ft model)	12'L x 12'D x 9'H
Special Features	Comfort Grip™ technology, Wheeled Carry Bag
Required Assembly	Yes

9. WARRANTY & SUPPORT

This Coleman Canopy Sun Shelter comes with a **1-year limited manufacturer warranty**. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, accidents, unauthorized modifications, or failure to follow the instructions in this manual. For warranty claims, technical support, or to purchase replacement parts, please contact Coleman Customer Service:

- **Website:** Visit the official Coleman website for support resources and contact information.
- **Phone:** Refer to the contact details provided on the Coleman website or product packaging.

Please have your product model number (B09WDKQ32J) and date of purchase available when contacting support.