

[Manuals.plus](#) /

› [Coleman](#) /

› Coleman Chiller 48qt Insulated Portable Cooler with Ice Retention & Heavy-Duty Handles, Made in USA Blue Portable Cooler User Manual

Coleman 3000000152NP

Coleman Chiller 48qt Insulated Portable Cooler User Manual

Model: 3000000152NP

INTRODUCTION

This manual provides essential information for the proper use, maintenance, and care of your Coleman Chiller 48qt Insulated Portable Cooler. Designed for durability and ice retention, this cooler is ideal for various outdoor activities, including camping, tailgating, picnics, boating, and grocery transport.



Image: The Coleman Chiller 48qt Insulated Portable Cooler in blue with a white lid, showcasing its rectangular design and side handles.

KEY FEATURES

- **Tall Design:** Accommodates 2-liter bottles upright, minimizing spills during transport.
- **ThermOZONE Insulation:** Environmentally friendly insulation that does not contain CFCs, HFCs, or HCFCs, which are harmful to the ozone layer.
- **Hinged Lid:** Provides easy access to contents.
- **2-Way Handles:** Designed for easier lifting and carrying, enhancing portability.
- **Integrated Drain:** Allows for easy draining of melted ice and cleaning.

SETUP

Your Coleman Chiller Cooler comes ready for immediate use. Before first use, it is recommended to:

1. **Inspect:** Check the cooler for any signs of damage from shipping.
2. **Clean:** Wipe the interior and exterior surfaces with a damp cloth and mild soap. Rinse thoroughly and allow to air dry completely before use.
3. **Pre-chill (Optional but Recommended):** For optimal ice retention, pre-chill the cooler by placing a bag of ice or ice packs inside for a few hours before loading it with food and beverages.

OPERATING INSTRUCTIONS

Using your Coleman Chiller Cooler is straightforward:

- **Loading:** Place desired food and beverages inside. For best results, use a combination of ice and ice packs. Fill the cooler as much as possible to minimize air space, which helps with ice retention.
- **Closing the Lid:** Ensure the hinged lid is securely closed to maintain internal temperature.
- **Transport:** Utilize the 2-way handles for comfortable lifting and carrying. The handles slide up for carrying and down for compact storage.




Image: A side view of the Coleman Chiller 48qt Insulated Portable Cooler, illustrating its dimensions (approximately 15 inches in height).

MAINTENANCE

Proper maintenance ensures the longevity and performance of your cooler:

- **Cleaning:** After each use, especially when ice has melted, drain any remaining water using the integrated drain spout.
- **Draining:** To drain, locate the drain spout on the side of the cooler, twist the cap to open, and allow water to flow out. Once drained, close the cap securely.
- **Washing:** Wash the interior and exterior with mild soap and warm water. For stubborn stains, a baking soda paste can be used. Avoid abrasive cleaners or harsh chemicals.
- **Drying:** Thoroughly dry the cooler, leaving the lid slightly ajar to prevent odors and mildew formation.
- **Storage:** Store the cooler in a cool, dry place away from direct sunlight when not in use.

TROUBLESHOOTING

Here are solutions to common issues you might encounter:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Ice melts quickly	Lid not fully sealed. Cooler not pre-chilled. Too much empty space inside. Frequent opening of the lid.	Ensure lid is securely closed. Pre-chill the cooler before use. Fill the cooler as much as possible with contents or additional ice. Minimize opening the lid.
Unpleasant odor inside	Improper cleaning or drying. Food residue.	Clean thoroughly with mild soap and water. Use a baking soda paste to absorb odors. Ensure cooler is completely dry before storing with lid ajar.
Hinges or handles appear damaged	Wear and tear over time. Excessive force during use.	Contact Coleman customer support for replacement parts or repair options. Avoid overloading the cooler or applying excessive force to handles/lid.

SPECIFICATIONS

Brand	Coleman
Model Name	R3S62390466
Capacity	45.4 Liters (approx. 48 Quarts)
Color	Blue
Material	Plastic (Polyurethane Foam Insulation)
Product Dimensions (D x W x H)	14.13"D x 25.63"W x 14.13"H
Item Weight	7.35 Pounds
Special Feature	Drain
Recommended Uses	Camping, Tailgating, Picnic, Boating, Groceries
UPC	076501303810

WARRANTY AND SUPPORT

Warranty Description: R3S62390466

For detailed warranty information, product support, or to inquire about replacement parts, please visit the official Coleman website or contact their customer service department. Keep your purchase receipt for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question