

[Manuals.plus](#) /

› [UTEX](#) /

› UTEX Toy Storage Organizer Instruction Manual

UTEX SS21-UTX-K020G

UTEX Toy Storage Organizer Instruction Manual

Model: SS21-UTX-K020G

PRODUCT OVERVIEW

This manual provides essential information for the assembly, operation, and maintenance of your UTEX Toy Storage Organizer. Designed for children's playrooms, bedrooms, and nurseries, this organizer offers a practical solution for tidying up toys, books, and other items.



Image: The UTEX Toy Storage Organizer, shown in a gray finish, filled with various children's items such as books, stuffed animals, and a woven basket. The top shelf displays decorative items, while the lower cubbies and bottom bin hold larger toys.

SETUP AND ASSEMBLY

The UTEX Toy Storage Organizer is designed for straightforward assembly. Please ensure all components are present before beginning. A screwdriver is the only tool required for assembly.

Required Tools:

- Phillips head screwdriver (not included)

Estimated Assembly Time:

Approximately 30 minutes.

Assembly Steps:

1. Unpack all components and verify against the parts list provided in the separate assembly instructions.
2. Follow the step-by-step diagrams in the assembly instructions to connect the panels using the provided hardware.
3. Ensure all screws are tightened securely, but do not overtighten to avoid damaging the engineered wood.
4. Place the assembled organizer on a flat, stable surface.




Image: A detailed diagram illustrating the dimensions of the UTEX Toy Storage Organizer. Key measurements include a width of 23.62 inches, a depth of 13.38 inches, and a height of 30.98 inches. Internal shelf and cubby dimensions are also provided, which are crucial for assembly and understanding the storage capacity.

OPERATING INSTRUCTIONS

The UTEX Toy Storage Organizer is designed for versatile use in various children's spaces. Its multiple compartments allow for organized storage of different item types.

Storage Capacity:

- **Top Surface:** Ideal for displaying books, small decorative items, or frequently accessed toys.
- **Upper Cubbies:** Two compartments suitable for organizing smaller books, art supplies, or small toys.
- **Lower Cubbies:** Two larger compartments for medium-sized toys, board games, or additional books.
- **Bottom Bin:** A spacious open bin designed for larger toys, stuffed animals, or bulkier items, allowing easy access for children.

Placement Recommendations:

This organizer is suitable for placement in bedrooms, playrooms, nurseries, classrooms, or study rooms. Ensure it is placed on a level surface to maintain stability.



Image: A collage demonstrating the UTEX Toy Storage Organizer's versatility in different environments. It shows the organizer in a playroom, living room, study room, and classroom, highlighting its adaptability for various storage needs and room types.

MAINTENANCE

Proper care will ensure the longevity and appearance of your UTEX Toy Storage Organizer.

Cleaning:

- Wipe the surface with a dry cloth to remove dust and light dirt.
- For more stubborn marks, use a slightly damp cloth with mild soap, then immediately wipe dry with a clean, dry cloth.
- Avoid using abrasive cleaners or harsh chemicals, as these can damage the painted finish.

General Care:

- Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- Avoid exposing the organizer to excessive moisture or direct sunlight for prolonged periods to prevent warping or fading.
- The product is made of engineered wood with a painted finish, offering durability and a water-resistant surface.

TROUBLESHOOTING

This section addresses common issues you might encounter with your toy storage organizer.

Stability Issues:

- **Problem:** The organizer wobbles or feels unstable.
- **Solution:** Ensure the organizer is placed on a flat, level surface. Check all assembly screws and tighten any that are loose. If the floor is uneven, consider using furniture pads or shims under the base.

Missing or Damaged Parts:

- **Problem:** Components are missing from the package or arrived damaged.
- **Solution:** Do not proceed with assembly. Contact UTEX customer support immediately with your purchase details and a description of the missing or damaged parts.

Difficulty During Assembly:

- **Problem:** Parts do not fit together easily or alignment is difficult.
- **Solution:** Double-check the assembly instructions and diagrams to ensure you are using the correct parts and orientation for each step. Avoid forcing components together, as this can cause damage. If issues persist, contact customer support.

SPECIFICATIONS

Detailed specifications for the UTEX Toy Storage Organizer.

Brand	UTEX
Model Number	SS21-UTX-K020G
Product Dimensions (W x D x H)	23.62" x 13.38" x 30.98" (Overall)
Item Weight	29.6 pounds

Material	Engineered Wood
Finish Type	Painted
Special Feature	Water Resistant
Assembly Required	Yes
Recommended Uses	Bedroom, Nursery, Playroom
Product Care Instructions	Wipe with Dry Cloth

WARRANTY INFORMATION

Specific warranty details for the UTEX Toy Storage Organizer are not provided in the product information. For inquiries regarding warranty coverage, terms, and conditions, please contact UTEX customer support directly.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact UTEX customer support through their official website or the retailer where the product was purchased.
For more information about UTEX products, visit the [UTEX Store on Amazon](#).