

Manuals.plus /

- › Playmobil /
- › Playmobil Adventure Zoo (Model 71190) Instruction Manual

Playmobil 71190

Playmobil Adventure Zoo (Model 71190) Instruction Manual

Brand: Playmobil | Model: 71190

[Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Playmobil Adventure Zoo (Model 71190). Please read all instructions carefully before beginning assembly to ensure correct setup and safe play.

Warning: Choking Hazard. Small parts. Not for children under 3 years.

SETUP AND ASSEMBLY

The Playmobil Adventure Zoo set includes 127 pieces. Assembly may take approximately 40 minutes. Follow the included instruction manual for detailed, step-by-step guidance. Ensure all stickers are applied correctly as indicated in the manual.



Image: The complete Playmobil Adventure Zoo set, showcasing the zoo entrance, observation path, giraffe feeding area, and penguin slide with various figures and animals.

Key Assembly Steps:

1. **Unpack Components:** Carefully remove all 127 pieces from the packaging. Verify all parts are present against the parts list in the included instruction manual.
2. **Assemble Main Structures:** Begin with the zoo entrance arch and the elevated observation path. These form the central structure of the zoo.
3. **Construct Animal Habitats:** Assemble the giraffe feeding station with its hanging basket and trough. Construct the penguin slide and water area.
4. **Place Accessories:** Position smaller elements such as trees, plants, signs, and the telescope.
5. **Apply Stickers:** Adhere all decorative stickers to their designated locations as shown in the manual for a complete appearance.



Image: A visual representation of various assembled sections of the Playmobil Adventure Zoo, including the observation deck and animal areas, indicating modular construction.

Figures and Animals:

- The set includes two adult figures and two children figures.
- Animal figures include a giraffe with a baby, two adult penguins, four baby penguins, two mice, a lizard, and a bird.
- These figures are designed for interactive play within the zoo environment.

OPERATION AND PLAY

The Playmobil Adventure Zoo is designed for imaginative play, allowing users to create various zoo scenarios.

Interactive Features:

- **Observation Path:** Guide figures along the elevated observation path to view the animals from above.

- **Giraffe Feeding:** Use the hanging basket and trough to simulate feeding the adult and baby giraffes.
- **Penguin Slide:** Place the penguin figures on the ice slide for interactive movement.
- **Zoo Entrance:** Utilize the colorful ZOO arch as the main entry point for figures.
- **Map and Information:** Use the included map and information signs to navigate the zoo and check feeding times.
- **Telescope:** Position figures at the viewing platform to use the telescope for observing wildlife.



Image: A detailed view of the giraffe feeding area within the Playmobil Adventure Zoo, showing an adult and baby giraffe, a zookeeper figure, and a hanging feed basket.



Image: The main entrance of the Playmobil Adventure Zoo, featuring two child figures examining a zoo map and information signs, with the zoo arch in the background.



Image: The elevated observation deck of the Playmobil Adventure Zoo, with two child figures and an adult figure using a telescope to view the animals.

MAINTENANCE

To ensure the longevity of your Playmobil Adventure Zoo set, follow these simple maintenance guidelines:

- **Cleaning:** Wipe down all plastic components with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these may damage the plastic or painted details.
- **Storage:** Store the set in a clean, dry place away from direct sunlight and extreme temperatures to prevent warping or fading.
- **Small Parts:** Keep all small parts, especially animal figures and accessories, in a designated container to prevent loss.

TROUBLESHOOTING

If you encounter any issues with your Playmobil Adventure Zoo, consider the following common solutions:

- **Missing Pieces:** Double-check all packaging materials. If a piece is genuinely missing, contact Playmobil customer support (see Warranty & Support section).
- **Assembly Difficulties:** Refer to the detailed instruction manual provided with the set. Ensure all pieces are oriented correctly and snapped firmly into place. Do not force pieces together.
- **Loose Connections:** If parts become loose during play, gently re-attach them. Playmobil components are designed for secure, yet detachable, connections.

SPECIFICATIONS

Feature	Detail
Brand	Playmobil
Model Number	71190
Item Type Name	Building Set
Number of Pieces	127
Material Type	Plastic
Color	Multicolor
Theme	Animal
Age Range Description	Kid (Recommended for ages four to ten)
Item Dimensions (LxWxH)	18.11 x 4.69 x 11.18 inches
Item Weight	992.12 Grams
Is Assembly Required	No (Refers to the product being sold as a kit, not pre-assembled)

WARRANTY & SUPPORT

Specific warranty information for the Playmobil Adventure Zoo (Model 71190) is not available in the provided product data. For detailed warranty terms, product support, or to inquire about replacement parts, please visit the official Playmobil website or contact their customer service directly.

You can often find support information on the manufacturer's official website: www.playmobil.com

PRODUCT VIDEOS

No official product videos from the seller were available for embedding based on the provided criteria. The available video is user-generated content and does not meet the embedding requirements.

