

Severin TKB 2925

SEVERIN TKB 2925 Electric Cooler (25 L)

User Manual

1. IMPORTANT SAFETY INSTRUCTIONS

Please read these instructions carefully before using the appliance and keep them for future reference. This appliance is intended for domestic use only.

- Do not immerse the appliance or its power cords in water or any other liquids.
- Ensure the voltage indicated on the rating label matches your mains voltage.
- This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Always unplug the appliance from the power source when not in use, before cleaning, or in case of malfunction.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use abrasive cleaning agents or sharp objects for cleaning.
- Ensure adequate ventilation around the cooler, especially the fan vents, to prevent overheating.
- Do not block the ventilation openings.
- Avoid placing hot items directly into the cooler when in cooling mode, or cold items when in warming mode, without allowing them to reach ambient temperature first.
- The cooler is designed for portable use. Secure it properly in a vehicle to prevent movement during transit.

2. PRODUCT OVERVIEW

The SEVERIN TKB 2925 is a versatile electric cooler designed for both cooling and warming food and beverages. With a 25-liter capacity, it is an ideal companion for picnics, road trips, camping, or as a portable storage solution.

Key Features:

- **Cooling Function:** Cools contents up to 20°C below ambient temperature.
- **Warming Function:** Keeps contents warm at approximately 50-60°C.
- **Multiple Power Options:** Includes innovative USB connection, standard AC power, and 12V car cigarette lighter cable.
- **ECO Function:** Energy-saving mode (16W) for efficient operation.
- **Large Capacity:** 25-liter usable volume, suitable for 1.5-2 liter bottles standing upright.
- **Thoughtful Design:** Removable lid with carrying handle, lid lock, cable storage compartment, silicone pad for power bank storage, and car battery discharge protection.



Figure 2.1: Front view of the SEVERIN TKB 2925 Electric Cooler. The cooler is grey with a white lid and lime green accents on the handle and fan covers.





Figure 2.2: The cooler shown with its lid open, revealing the spacious interior and the cooling/warming unit on the underside of the lid. The lime green handle is visible in its upright position.

3. SETUP

3.1 Unpacking and Initial Inspection

1. Carefully remove the cooler from its packaging.
2. Check for any visible damage to the appliance or its accessories. If damaged, do not use and contact customer support.
3. Remove all packing materials and dispose of them responsibly.

3.2 Power Connections

The SEVERIN TKB 2925 offers flexible power options:

- **AC Power (Mains):** Use the provided AC power cable to connect the cooler to a standard wall outlet (220-240V).
- **12V Car Power:** Use the provided 12V car adapter cable to connect the cooler to your vehicle's cigarette lighter socket. This mode includes car battery discharge protection.
- **USB Power:** For portable use, connect a power bank (10,000 mAh recommended, not included) to the cooler's USB port. The cooler can operate for up to 4.5 hours on a suitable power bank.

Ensure the correct cable is used for the intended power source. The cable storage compartment is located on the lid for convenience.



Figure 3.1: The cooler connected to a 12V power outlet in a car's trunk, demonstrating its portability and car-friendly design.

4. OPERATING INSTRUCTIONS

4.1 Cooling and Warming Modes

The cooler features a switch to select between cooling and warming functions. The selected function is indicated by a light:

- **Cooling Mode:** Ideal for keeping drinks and perishable foods cool. The cooler can reach temperatures up to 20°C below the ambient temperature.
- **Warming Mode:** Suitable for keeping cooked food warm. The cooler maintains an internal temperature of approximately 50-60°C.

To switch modes, locate the control panel on the lid and select the desired setting. Allow some time for the cooler to reach the desired temperature.

4.2 ECO Function

The ECO function (16W) provides an energy-efficient operating mode, particularly useful when powered by a car battery or power bank to conserve energy. This mode is suitable for maintaining temperature rather than rapid cooling or warming.

4.3 Using with a Power Bank

For extended portability, the cooler can be powered by a power bank via its USB port. A silicone pad is integrated into the lid design to securely hold a power bank during operation.



Figure 4.1: The cooler's lid with a power bank connected via USB, demonstrating how it can be powered for portable use. The power bank rests securely on a dedicated silicone pad.



Figure 4.2: The interior of the cooler filled with various food items, including fruits and containers, showcasing its practical storage capacity.



Figure 4.3: The cooler's interior accommodating multiple bottles, illustrating its suitability for beverages and its efficient use of space.

5. MAINTENANCE AND CLEANING

5.1 Cleaning the Cooler

- 1. Always unplug the cooler from all power sources before cleaning.
- 2. Wipe the interior and exterior surfaces with a soft, damp cloth and mild detergent.
- 3. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the surfaces.
- 4. Ensure the cooler is completely dry before storing or reconnecting to power.
- 5. Periodically check and clean the fan vents on the lid to ensure proper airflow and prevent dust buildup.

5.2 Storage

When not in use, store the cooler in a clean, dry place away from direct sunlight and extreme temperatures. Ensure the lid is slightly ajar to prevent odors and mildew buildup.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Cooler not operating (no cooling/warming, no indicator light)	No power supply. Incorrect power connection. Damaged cable or plug. Car battery discharge protection activated.	Check if the power cable is securely plugged into the cooler and the power source. Ensure the power source (outlet, car socket, power bank) is functional. If using 12V car power, check your car battery level. Inspect cables for damage. If damaged, do not use.
Insufficient cooling/warming performance	Blocked ventilation openings. Ambient temperature too high (for cooling). Contents were already warm/cold (for warming/cooling). ECO mode is active.	Ensure fan vents are clear of obstructions. Pre-cool or pre-warm items before placing them in the cooler for optimal performance. Switch off ECO mode if faster cooling/warming is desired (if applicable). Allow sufficient time for the cooler to reach the desired temperature.
Unusual noise from the fan	Dust or debris in the fan. Fan malfunction.	Clean the fan vents carefully. If the noise persists or is excessive, contact customer support.

7. SPECIFICATIONS

Attribute	Value
Brand	Severin
Model Number	2925

<div data-bbox="221 96 304 114" data-label="Section-Header"> SEVERIN </div> <div data-bbox="181 129 264 241" data-label="Image"> </div> <div data-bbox="126 239 304 344" data-label="Table-Of-Contents"> <table> <tr> <th colspan="2">SEVERIN WK 3472</th> </tr> <tr> <td>DE Gebrauchsanweisung</td> <td>Wasserkocher</td> </tr> <tr> <td>FR Instructions for use</td> <td>Électro bouilloire</td> </tr> <tr> <td>EN Instructions for use</td> <td>Electric kettle</td> </tr> <tr> <td>ES Instrucciones de uso</td> <td>Electrolava vasos</td> </tr> <tr> <td>IT Istruzioni d'uso</td> <td>Electrolava</td> </tr> <tr> <td>PT Manual de instruções</td> <td>Electrolava</td> </tr> <tr> <td>RU Инструкция по эксплуатации</td> <td>Электрочайник</td> </tr> <tr> <td>GR Οδηγίες χρήσης</td> <td>Ηλεκτρικός βραστήρας</td> </tr> </table> </div>	SEVERIN WK 3472		DE Gebrauchsanweisung	Wasserkocher	FR Instructions for use	Électro bouilloire	EN Instructions for use	Electric kettle	ES Instrucciones de uso	Electrolava vasos	IT Istruzioni d'uso	Electrolava	PT Manual de instruções	Electrolava	RU Инструкция по эксплуатации	Электрочайник	GR Οδηγίες χρήσης	Ηλεκτρικός βραστήρας	<div data-bbox="336 170 1287 201" data-label="Section-Header"> <h2>SEVERIN Wasserkocher WK 3472 - Bedienungsanleitung und Sicherheitshinweise</h2> </div> <div data-bbox="336 210 1455 282" data-label="Text"> <p>Finden Sie detaillierte Anleitungen und wichtige Sicherheitshinweise für den SEVERIN Wasserkocher WK 3472. Erfahren Sie mehr über Anschluss, Bedienung, Reinigung und Wartung.</p> </div>
SEVERIN WK 3472																			
DE Gebrauchsanweisung	Wasserkocher																		
FR Instructions for use	Électro bouilloire																		
EN Instructions for use	Electric kettle																		
ES Instrucciones de uso	Electrolava vasos																		
IT Istruzioni d'uso	Electrolava																		
PT Manual de instruções	Electrolava																		
RU Инструкция по эксплуатации	Электрочайник																		
GR Οδηγίες χρήσης	Ηλεκτρικός βραστήρας																		
<div data-bbox="228 400 304 418" data-label="Section-Header"> SEVERIN </div> <div data-bbox="189 434 240 546" data-label="Image"> </div> <div data-bbox="126 546 304 669" data-label="Table-Of-Contents"> <table> <tr> <th colspan="2">SEVERIN FKS 8841</th> </tr> <tr> <td>DE Gebrauchsanleitung</td> <td>Flaschenkühlschrank</td> </tr> <tr> <td>FR Instructions for use</td> <td>Refrigérateur pour bouteilles</td> </tr> <tr> <td>EN Instructions for use</td> <td>Bottle refrigerator</td> </tr> <tr> <td>ES Instrucciones de uso</td> <td>Refrigerador para botellas</td> </tr> <tr> <td>IT Istruzioni d'uso</td> <td>Refrigeratore per bottiglie</td> </tr> <tr> <td>PT Manual de instruções</td> <td>Refrigerador para garrafas</td> </tr> <tr> <td>RU Инструкция по эксплуатации</td> <td>Холодильник для бутылок</td> </tr> <tr> <td>GR Οδηγίες χρήσης</td> <td>Ψυγείο για μπουκάλια</td> </tr> </table> </div>	SEVERIN FKS 8841		DE Gebrauchsanleitung	Flaschenkühlschrank	FR Instructions for use	Refrigérateur pour bouteilles	EN Instructions for use	Bottle refrigerator	ES Instrucciones de uso	Refrigerador para botellas	IT Istruzioni d'uso	Refrigeratore per bottiglie	PT Manual de instruções	Refrigerador para garrafas	RU Инструкция по эксплуатации	Холодильник для бутылок	GR Οδηγίες χρήσης	Ψυγείο για μπουκάλια	<div data-bbox="336 465 1082 497" data-label="Section-Header"> <h2>SEVERIN FKS 8841 Bedienungsanleitung und Produktdatenblatt</h2> </div> <div data-bbox="336 506 1436 616" data-label="Text"> <p>Entdecken Sie die detaillierte Bedienungsanleitung und das Produktdatenblatt für den SEVERIN FKS 8841 Flaschenkühlschrank. Erfahren Sie mehr über Installation, Bedienung, Sicherheitshinweise und technische Spezifikationen dieses hochwertigen Geräts von SEVERIN.</p> </div>
SEVERIN FKS 8841																			
DE Gebrauchsanleitung	Flaschenkühlschrank																		
FR Instructions for use	Refrigérateur pour bouteilles																		
EN Instructions for use	Bottle refrigerator																		
ES Instrucciones de uso	Refrigerador para botellas																		
IT Istruzioni d'uso	Refrigeratore per bottiglie																		
PT Manual de instruções	Refrigerador para garrafas																		
RU Инструкция по эксплуатации	Холодильник для бутылок																		
GR Οδηγίες χρήσης	Ψυγείο για μπουκάλια																		
<div data-bbox="221 723 304 741" data-label="Section-Header"> SEVERIN </div> <div data-bbox="150 770 280 860" data-label="Image"> </div> <div data-bbox="126 860 304 972" data-label="Table-Of-Contents"> <table> <tr> <th colspan="2">SEVERIN JG 3521</th> </tr> <tr> <td>DE Gebrauchsanweisung</td> <td>Digitaler Joghurtbereiter</td> </tr> <tr> <td>FR Instructions for use</td> <td>Préparateur de yaourt digital</td> </tr> <tr> <td>EN Instructions for use</td> <td>Digital yogurt maker</td> </tr> <tr> <td>ES Instrucciones de uso</td> <td>Preparador de yogur digital</td> </tr> <tr> <td>IT Istruzioni d'uso</td> <td>Preparatore di yogurt digitale</td> </tr> <tr> <td>PT Manual de instruções</td> <td>Preparador de iogurte digital</td> </tr> <tr> <td>RU Инструкция по эксплуатации</td> <td>Цифровой йогуртница</td> </tr> <tr> <td>GR Οδηγίες χρήσης</td> <td>Ψηφιακός γιαγιούρτοποιητής</td> </tr> </table> </div>	SEVERIN JG 3521		DE Gebrauchsanweisung	Digitaler Joghurtbereiter	FR Instructions for use	Préparateur de yaourt digital	EN Instructions for use	Digital yogurt maker	ES Instrucciones de uso	Preparador de yogur digital	IT Istruzioni d'uso	Preparatore di yogurt digitale	PT Manual de instruções	Preparador de iogurte digital	RU Инструкция по эксплуатации	Цифровой йогуртница	GR Οδηγίες χρήσης	Ψηφιακός γιαγιούρτοποιητής	<div data-bbox="336 779 1086 810" data-label="Section-Header"> <h2>SEVERIN JG 3521 Digitaler Joghurtbereiter Bedienungsanleitung</h2> </div> <div data-bbox="336 819 1460 929" data-label="Text"> <p>Entdecken Sie den SEVERIN JG 3521 Digitalen Joghurtbereiter. Diese Anleitung bietet detaillierte Informationen zur Verwendung, Sicherheit und Rezepten für die Zubereitung von hausgemachtem Joghurt.</p> </div>
SEVERIN JG 3521																			
DE Gebrauchsanweisung	Digitaler Joghurtbereiter																		
FR Instructions for use	Préparateur de yaourt digital																		
EN Instructions for use	Digital yogurt maker																		
ES Instrucciones de uso	Preparador de yogur digital																		
IT Istruzioni d'uso	Preparatore di yogurt digitale																		
PT Manual de instruções	Preparador de iogurte digital																		
RU Инструкция по эксплуатации	Цифровой йогуртница																		
GR Οδηγίες χρήσης	Ψηφιακός γιαγιούρτοποιητής																		
<div data-bbox="126 1028 304 1055" data-label="Section-Header"> SEVERIN Friends for Life </div> <div data-bbox="173 1061 256 1196" data-label="Image"> </div> <div data-bbox="126 1196 304 1296" data-label="Table-Of-Contents"> <table> <tr> <th colspan="2">SEVERIN WK 3454 / WK 3459</th> </tr> <tr> <td>DE Gebrauchsanweisung</td> <td>Wasserkocher</td> </tr> <tr> <td>FR Instructions for use</td> <td>Électro bouilloire</td> </tr> <tr> <td>EN Instructions for use</td> <td>Electric kettle</td> </tr> <tr> <td>ES Instrucciones de uso</td> <td>Electrolava vasos</td> </tr> <tr> <td>IT Istruzioni d'uso</td> <td>Electrolava</td> </tr> <tr> <td>PT Manual de instruções</td> <td>Electrolava</td> </tr> <tr> <td>RU Инструкция по эксплуатации</td> <td>Электрочайник</td> </tr> <tr> <td>GR Οδηγίες χρήσης</td> <td>Ηλεκτρικός βραστήρας</td> </tr> </table> </div>	SEVERIN WK 3454 / WK 3459		DE Gebrauchsanweisung	Wasserkocher	FR Instructions for use	Électro bouilloire	EN Instructions for use	Electric kettle	ES Instrucciones de uso	Electrolava vasos	IT Istruzioni d'uso	Electrolava	PT Manual de instruções	Electrolava	RU Инструкция по эксплуатации	Электрочайник	GR Οδηγίες χρήσης	Ηλεκτρικός βραστήρας	<div data-bbox="336 1093 1423 1124" data-label="Section-Header"> <h2>SEVERIN WK 3454 / WK 3459 Wasserkocher – Bedienungsanleitung und Sicherheitshinweise</h2> </div> <div data-bbox="336 1133 1466 1243" data-label="Text"> <p>Finden Sie die vollständige Bedienungsanleitung für den SEVERIN Wasserkocher WK 3454 und WK 3459. Enthält wichtige Sicherheitshinweise, Gebrauchsanweisungen und Wartungstipps für Ihr Gerät.</p> </div>
SEVERIN WK 3454 / WK 3459																			
DE Gebrauchsanweisung	Wasserkocher																		
FR Instructions for use	Électro bouilloire																		
EN Instructions for use	Electric kettle																		
ES Instrucciones de uso	Electrolava vasos																		
IT Istruzioni d'uso	Electrolava																		
PT Manual de instruções	Electrolava																		
RU Инструкция по эксплуатации	Электрочайник																		
GR Οδηγίες χρήσης	Ηλεκτρικός βραστήρας																		
<div data-bbox="126 1350 304 1377" data-label="Section-Header"> SEVERIN Friends for Life </div> <div data-bbox="150 1384 280 1496" data-label="Image"> </div> <div data-bbox="126 1496 304 1597" data-label="Table-Of-Contents"> <table> <tr> <th colspan="2">SEVERIN BA 3261</th> </tr> <tr> <td>DE Gebrauchsanweisung</td> <td>Dampfbügeleisen</td> </tr> <tr> <td>FR Instructions for use</td> <td>Sèche-à-fer à vapeur</td> </tr> <tr> <td>EN Instructions for use</td> <td>Steam iron</td> </tr> <tr> <td>ES Instrucciones de uso</td> <td>Plancha de vapor</td> </tr> <tr> <td>IT Istruzioni d'uso</td> <td>Stendirovestiti a vapore</td> </tr> <tr> <td>PT Manual de instruções</td> <td>Plancha de vapor</td> </tr> <tr> <td>RU Инструкция по эксплуатации</td> <td>Паровой утюг</td> </tr> <tr> <td>GR Οδηγίες χρήσης</td> <td>Σιδερένιος σιδερένιος</td> </tr> </table> </div>	SEVERIN BA 3261		DE Gebrauchsanweisung	Dampfbügeleisen	FR Instructions for use	Sèche-à-fer à vapeur	EN Instructions for use	Steam iron	ES Instrucciones de uso	Plancha de vapor	IT Istruzioni d'uso	Stendirovestiti a vapore	PT Manual de instruções	Plancha de vapor	RU Инструкция по эксплуатации	Паровой утюг	GR Οδηγίες χρήσης	Σιδερένιος σιδερένιος	<div data-bbox="336 1429 1015 1460" data-label="Section-Header"> <h2>SEVERIN BA 3261 Dampfbügeleisen Bedienungsanleitung</h2> </div> <div data-bbox="336 1469 1433 1541" data-label="Text"> <p>Umfassende Bedienungsanleitung für das SEVERIN Dampfbügeleisen Modell BA 3261. Enthält Informationen zur sicheren Nutzung, Funktionen, Wartung und Pflege des Geräts.</p> </div>
SEVERIN BA 3261																			
DE Gebrauchsanweisung	Dampfbügeleisen																		
FR Instructions for use	Sèche-à-fer à vapeur																		
EN Instructions for use	Steam iron																		
ES Instrucciones de uso	Plancha de vapor																		
IT Istruzioni d'uso	Stendirovestiti a vapore																		
PT Manual de instruções	Plancha de vapor																		
RU Инструкция по эксплуатации	Паровой утюг																		
GR Οδηγίες χρήσης	Σιδερένιος σιδερένιος																		