

[Manuals.plus](#) /

› [Funsicle](#) /

› Funsicle 14ft x 48in Round Oasis Above Ground Pool User Manual

Funsicle P4001448B

Funsicle 14ft x 48in Round Oasis Above Ground Pool Instruction Manual

Model: P4001448B

1. INTRODUCTION

The Funsicle 14ft x 48in Round Oasis Above Ground Pool offers a premium backyard swimming experience. Designed for easy setup and lasting durability, this pool features a sleek cool gray liner with a stylish interior honeycomb print. It comes equipped with a powerful 2-in-1 SkimmerPlus Filter Pump, a pool cover, a SureStep ladder, and a deluxe maintenance kit, ensuring clean water and convenient access. This manual will guide you through all necessary steps for assembly, operation, and care.



Image 1.1: The Funsicle 14ft x 48in Round Oasis Above Ground Pool, showcasing its round shape and 48-inch height.

2. IMPORTANT SAFETY INFORMATION

WARNING: PREVENT DROWNING! Closely watch children who are in or near this pool. Children under 5 are at highest risk for drowning. Empty pool or prevent access when not in use. **NO DIVING!** You can break your neck.

Always ensure adult supervision when the pool is in use. Keep children away from the pool when not supervised. Secure the

ladder or remove it when the pool is not in use to prevent unauthorized access.

3. PRODUCT FEATURES

- **Luxury Pool Experience:** Ideal for up to 6 to 7 people, perfect for families, socializing & swimming.
- **Simple Setup:** Features SmartConnect poles with a convenient snap-in design for quick assembly.
- **Durable Construction:** Ultra-strong oval metal frame with anti-corrosive matte finish and a durable non-phthalates liner.
- **Integrated Filtration:** Includes SFX1000 SkimmerPlus Filter Pump (with GFCI) and a Type C filter cartridge.
- **Complete Accessory Kit:** Comes with a deluxe maintenance kit, pool cover, ground cloth, and repair patch.
- **Safe Access:** SureStep Ladder included for easy and secure pool entry and exit.

Oasis Pool Set Features:




Image 3.1: Diagram illustrating key features of the Funsicle Oasis Pool Set, including SmartConnect poles, pool cover, SureStep ladder, ground cloth, and durable liner.

4. SETUP GUIDE

Before beginning assembly, ensure you have a level surface free of debris. Refer to the detailed User Manual (PDF) provided with your product for complete step-by-step instructions and safety warnings.

4.1 Site Preparation

- Choose a flat, level area for your pool. Uneven ground can cause structural stress and potential failure.
- Clear the area of any sharp objects, rocks, or debris.
- Lay down the included ground cloth for extra puncture protection.

4.2 Frame Assembly (SmartConnect™ Technology)

The Funsicle Oasis Pool utilizes SmartConnect™ technology for simplified assembly. Simply connect the oval-shaped poles together until you hear a distinct 'click'. This ensures a sturdy and secure frame structure.



Image 4.1: Close-up of SmartConnect poles, designed for easy snap-in assembly.

4.3 Liner Installation

Carefully unfold the durable non-phthalates 3-ply liner onto the ground cloth, ensuring the drain plug is positioned correctly for future drainage. The liner is constructed with heavy gauge PVC and a polyester mesh for enhanced durability.




Image 4.2: Cross-section view of the 3-layered durable puncture-resistant liner, showing heavy gauge PVC and polyester mesh.

4.4 Ladder Assembly

Assemble the SureStep™ ladder according to the instructions in the main user manual. This ladder provides convenient and safe access to and from the pool. Ensure it is securely assembled before use.



Image 4.3: The removable SureStep ladder, designed for safe and easy pool access.

5. OPERATING YOUR POOL

5.1 SkimmerPlus Filter Pump Operation

The included SFX1000 SkimmerPlus Filter Pump is a 2-in-1 unit that combines skimming and filtration functions. It attaches to the pool sidewall for easy maintenance and efficient space utilization. Ensure the pump is connected to a GFCI-protected outlet.

- The skimmer basket picks up debris, leaves, and insects from the water surface.
- The filter cartridge captures small particles, ensuring clean water circulation.
- Operate the pump daily for optimal water clarity. Consult the pump's specific manual for recommended run times based on pool usage and water conditions.

Includes our exclusive 2 in 1 side-mounted SkimmerPlus® filter pump



1. Skimmer basket picks up debris, leaves & insects



2. Filter cartridge captures small particles



Look for
Funsicle filters
Type

C

Combines the functions of a skimmer & filter pump in one unit
Filter pump attaches to pool sidewall for easy maintenance
and efficient space

Image 5.1: The SFX1000 SkimmerPlus Filter Pump alongside a Type C filter cartridge.



Image 5.2: Filtered water being returned to the pool, illustrating the pump's circulation function.

5.2 Pool Cover Usage

Use the included pool cover when the pool is not in use. This helps to keep out debris, leaves, and insects, and reduces water evaporation, minimizing the need for frequent refilling and chemical adjustments.



Image 5.3: The FunSicle pool with its cover in place, demonstrating how it protects the water from external elements.

6. MAINTENANCE

Regular maintenance is crucial for keeping your pool water clean and extending the life of your FunSicle pool.

6.1 Filter Cartridge Replacement

The SkimmerPlus Filter Pump uses a Type C filter cartridge. Check and clean the filter cartridge regularly (e.g., every few days, depending on usage). Replace the cartridge every 2-4 weeks or when it becomes visibly dirty and cannot be cleaned effectively.

6.2 Deluxe Maintenance Kit

Your pool comes with a deluxe maintenance kit to assist with cleaning. This kit typically includes a vacuum attachment for the bottom, a hand-held skimmer net for surface debris, and a brush for scrubbing the liner.



Image 6.1: Components of the deluxe maintenance kit, including a vacuum head, skimmer net, and telescopic pole.

6.3 Water Chemistry

Maintain proper water chemistry by regularly testing pH and chlorine levels. Follow guidelines for safe chemical usage to prevent algae growth and ensure water sanitation.

6.4 Draining and Storage

For convenient draining, the pool features a 2-in-1 drainage plug. Simply unlock and open the plug; no tools are required. Ensure the pool is completely dry before folding and storing it in a cool, dry place for the off-season.



Image 6.2: Close-up of the 2-in-1 drainage plug, designed for easy and tool-free water removal.

7. TROUBLESHOOTING

If you encounter issues with your Funsicle pool, consider the following common troubleshooting tips:

- **Water Leaks:** Inspect the liner for any punctures or tears. Use the included repair patch for minor damages. For leaks around connections, ensure all hoses and clamps are tightened securely.
- **Cloudy Water:** Check and clean or replace the filter cartridge. Ensure the filter pump is running for sufficient periods daily. Test and adjust water chemistry (chlorine, pH) as needed.
- **Pump Not Working:** Verify the pump is plugged into a working GFCI outlet. Check for any blockages in the intake or return lines. Ensure the filter cartridge is not excessively clogged.
- **Unstable Frame:** Re-check all SmartConnect pole connections to ensure they are fully clicked into place. Confirm the pool is on a completely level surface.

For more complex issues or if troubleshooting steps do not resolve the problem, please contact Funsicle Customer Support.

8. SPECIFICATIONS

Attribute	Detail
Brand	Funsicle
Model Number	P4001448B
Product Dimensions	168"L x 168"W x 48"H (14ft Diameter x 48in Height)
Shape	Round
Color	Gray
Material	Polyvinyl Chloride (PVC)
Item Weight	167 Pounds
Included Components	Cover, Ground Cloth, SFX1000 SkimmerPlus Filter Pump 110~120V w/GFCI, SureStep Ladder, Deluxe Maintenance Kit
Assembly Required	Yes

9. SUPPORT & WARRANTY

9.1 Customer Support

For any questions, assistance, or technical support regarding your Funsicle pool, please contact our customer service team:

Phone: (888) 670-4388

Website: funsicle.com/support

9.2 Warranty Information

Please refer to the warranty documentation included with your product packaging for specific details regarding coverage, terms, and conditions. Keep your proof of purchase for any warranty claims.

This product is eligible for 30-day easy returns when purchased from Amazon.com.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question