

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [vapeonly](#) /

› [Bocoice Blade Speaker User Manual](#)

vapeonly Bocoice Blade

Bocoice Blade Speaker User Manual

Model: Bocoice Blade

Brand: vapeonly

INTRODUCTION

The Bocoice Blade Speaker is an innovative bone conduction Bluetooth speaker designed for portability and versatile sound experiences. Its card-thin profile allows it to be easily carried, while its unique bone conduction technology transforms various surfaces into sound amplifiers, delivering stereo sound. This manual provides comprehensive instructions for setting up, operating, and maintaining your Blade Speaker.



Image: The Bocoice Blade Speaker, a sleek, thin black rectangular device.

KEY FEATURES

- **Bone Conduction Technology:** Transforms various surfaces into speakers, offering unique sound experiences.
- **True Wireless Stereo (TWS):** Pair two Blade Speakers for immersive stereo sound.
- **Bluetooth 5.0 Connectivity:** Ensures stable and efficient wireless connection with your devices.
- **Ultra-Portable Design:** Card-thin and lightweight, designed for easy carrying in a wallet or pocket.
- **Long Battery Life:** Provides extended playtime for continuous audio enjoyment.
- **Built-in FM Radio:** Access your favorite radio stations on the go.
- **HD Voice & Clear Voice:** Enhanced audio quality for calls and music.

- **Waterproof Design:** Durable for various environments.



BLADE SPEAKER

Slim but Powerful!



Bone Conduction

TWS



Bluetooth 5.0



Multiple Colors



Long Battery Life

FM

Build-in FM



HD Voice



Clear Voice



Ultra-Lightweight

Image: An overview of the Bocoice Blade Speaker's key features, including its various color options and technological capabilities.

SETUP GUIDE

1. Charging the Speaker

Before first use, fully charge your Bocoice Blade Speaker. The device features a high-speed Type-C port for quick charging.

- Connect the provided Type-C charging cable to the speaker's charging port.
- Connect the other end of the cable to a compatible USB power adapter (not included) or a computer's USB port.

- The indicator LED will show charging status. A full charge takes less than 30 minutes.
- Once fully charged, the speaker provides approximately 5 hours of continuous music playback.



Image: The speaker's battery life and music playback duration.

2. Bluetooth Pairing

The Bocoice Blade Speaker is compatible with any Bluetooth-enabled device.

1. Turn on the Blade Speaker by pressing and holding the power key/function key.
2. On your device (smartphone, tablet, laptop), navigate to the Bluetooth settings.
3. Search for available Bluetooth devices. The Blade Speaker should appear in the list (e.g., "Bocoice Blade").
4. Select the Blade Speaker to initiate pairing. Once connected, you will hear an audible confirmation.



Image: The Bluetooth 5.0 chip ensures stable connection and high-quality audio.

OPERATING INSTRUCTIONS

1. Experiencing Bone Conduction Sound


The unique feature of the Blade Speaker is its ability to use bone conduction technology to turn various hollow surfaces into speakers. Experiment with different materials and objects to discover unique sound profiles.

- **Wood:** Provides rich bass resonance.
- **Glass:** Delivers medium to high frequencies.
- **Drum/Hollow Objects:** Produces ultra mega bass.
- **Mirror:** Offers clean and melodious sound.
- **Cardboard/Kraft Box:** Can provide varying sound effects.

Simply attach the speaker to the desired surface using its adhesive backing or suction cup (if included in your set). The sound will then be projected through the entire chosen surface, offering an omni-directional and unlimited sound experience.

Create your own music

Blade Speaker uses bone conduction technology to offer you a DIY customize experience of sound. You can enjoy different sounds—almost as if different instruments are used. Place It on top of different surfaces such as a guitar, a Kraft box, a plastic storage box, photo frames, mirror, bike helmet or even dashboards can provide you varying sound effects.



Different Surfaces, Different Sounds

Image: Different surfaces produce different sound characteristics when the speaker is attached.

Your browser does not support the video tag.

Video: Demonstrates the versatility of the Blade Speaker by attaching it to various objects like a guitar, a box, and a helmet to produce sound. It also highlights its portability and private call feature.

2. True Wireless Stereo (TWS) Pairing

For a more immersive audio experience, you can pair two Bocoice Blade Speakers together to create a true wireless stereo sound system.

1. Ensure both Blade Speakers are charged and powered on.
2. Do not connect either speaker to your device via Bluetooth yet.
3. Double-press the power key/function key on one of the speakers. It will enter TWS pairing mode and automatically search for

another Blade Speaker.

- Once paired, you will hear an audible confirmation. The indicator LEDs on both speakers will change to indicate a successful TWS connection.
- Now, connect your device to one of the paired speakers via Bluetooth as described in the "Bluetooth Pairing" section. The sound will now play in stereo through both speakers.




Image: Combining two Blade Speakers for a surrounding stereo sound experience.

3. Making and Receiving Calls

The Blade Speaker includes an embedded high-sensitive microphone for clear voice calls.

- When a call comes in, the speaker will ring. Press the power key/function key once to answer the call.
- To end a call, press the power key/function key once again.
- To reject an incoming call, press and hold the power key/function key.
- For private calls in open spaces, you can turn down the volume on your connected device. The bone conduction technology allows for crystal clear sound that primarily only you can hear when the speaker is held close to your ear or a suitable surface.

Image: The speaker supports voice calls with clear audio.

4. FM Radio Function

The Blade Speaker features a built-in FM chipset with storage for 20 FM stations.

- To switch to FM radio mode, press the function key (refer to product diagram for exact button).
- Use the volume buttons to adjust the radio frequency.

- The speaker will automatically scan and store available FM stations.

MAINTENANCE

To ensure the longevity and optimal performance of your Bocoice Blade Speaker, follow these maintenance guidelines:

- **Cleaning:** Wipe the speaker with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the charging port or other openings.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Charging:** Always use the provided Type-C cable for charging. Avoid using damaged cables or chargers.
- **Water Exposure:** While the speaker is waterproof, avoid prolonged submersion or exposure to high-pressure water jets. Ensure the charging port is dry before charging after water exposure.
- **Handling:** Handle the speaker with care. Avoid dropping it or subjecting it to strong impacts, as this may damage internal components.

TROUBLESHOOTING

If you encounter any issues with your Bocoice Blade Speaker, please refer to the following common problems and solutions:

No Sound or Low Volume

- **Check Volume:** Ensure the volume on both the speaker and your connected device is turned up.
- **Surface Contact:** Verify that the speaker is firmly attached to a suitable hollow surface. Different surfaces yield different sound qualities and volumes.
- **Battery Level:** A low battery can affect sound output. Charge the speaker fully.
- **Bluetooth Connection:** Re-establish the Bluetooth connection with your device.

Cannot Pair with Device

- **Speaker in Pairing Mode:** Ensure the speaker is in Bluetooth pairing mode (indicator light blinking).
- **Device Bluetooth On:** Make sure Bluetooth is enabled on your device.
- **Distance:** Keep the speaker and device within the effective Bluetooth range (typically 10 meters).
- **Interference:** Move away from other Bluetooth devices or Wi-Fi routers that might cause interference.
- **Forget Device:** On your device, "forget" or "unpair" the Blade Speaker from your Bluetooth list, then try pairing again.
- **Restart Devices:** Turn off both the speaker and your device, then turn them back on and attempt pairing.

TWS Pairing Issues

- **Both Speakers On:** Ensure both Blade Speakers are powered on and not connected to any other device.
- **Initiate TWS Correctly:** Double-press the power key/function key on one speaker to initiate TWS pairing.
- **Proximity:** Keep the two speakers close to each other during TWS pairing.

SPECIFICATIONS

Model Name	Bocoice Blade
Brand	vapeonly
Speaker Type	Surround Sound
Special Feature	Portable

Controller Type	Battery Powered
Battery Life	5 Hours
Is Waterproof	TRUE
Power Source	Battery Powered
Connectivity Protocol	Bluetooth
Connectivity Technology	Bluetooth
Audio Output Mode	Surround, Stereo
Mounting Type	Freestanding
Item Weight	10.8 ounces (approx. 306 grams)
Package Dimensions	8.03 x 7.91 x 1.06 inches
Manufacturer	Bocoice
Date First Available	April 3, 2022
Charging Port	Type C
Battery Capacity	400mAh Polymer Battery
Frequency Range	20 Hz - 20 KHz
Output Power	3 Watt
FM Radio	Built-in FM chipset, 20 stations stored



Image: Dimensions of the Bocoice Blade Speaker compared to a credit card.

WARRANTY AND SUPPORT

The Bocoice Blade Speaker comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage details.

For technical support, troubleshooting assistance, or warranty claims, please contact vapeonly customer service through the contact information provided on the product packaging or their official website. Please have your product model and purchase details ready when contacting support.