Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

pamu S29

pamu S29 Active Noise Cancelling Bluetooth 5.2 Wireless Earbuds User Manual

Model: S29 (T6CP)

1. Introduction

Thank you for choosing the pamu S29 Active Noise Cancelling Bluetooth 5.2 Wireless Earbuds. These earbuds are designed to provide a superior audio experience with advanced noise cancellation, comfortable fit, and reliable wireless connectivity. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

2. What's in the Box

- pamu S29 Wireless Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- Eartips (S/M/L sizes)
- User Manual

3. Product Overview

Familiarize yourself with the components and features of your pamu S29 earbuds.




Image: pamu S29 Wireless Earbuds and Charging Case. The image displays the white earbuds and their charging case, highlighting their sleek design.



Image: pamu S29 Active Noise Cancellation Feature. This image illustrates the Active Noise Cancellation (ANC) capability of the earbuds, showing sound waves being reduced.



Image: pamu S29 Earbud with Microphone Locations. This image illustrates the placement of the four microphones (MIC1, MIC2, MIC3, MIC4) on each earbud, which are crucial for Active Noise Cancellation (ANC) and Environmental Noise Cancellation (ENC).



Image: pamu S29 Earbuds with 10mm Dynamic Drivers. This image highlights the 10mm dynamic drivers responsible for delivering premium sound and deep bass.



Image: pamu S29 Charging Case with USB-C Port. The image shows the charging case with its USB-C charging port and battery level indicator.



Image: pamu S29 Earbuds with Water Splashes. This image highlights the IPX4 waterproof rating of the earbuds, showing them resistant to splashes.

Key Features:

- **Active Noise Cancellation (ANC) & Environmental Noise Cancellation (ENC):** Reduces ambient noise for clear audio and calls.
- **Bluetooth 5.2:** Ensures stable and fast wireless connection.
- **Mono/Dual Modes:** Use either earbud independently or both for stereo sound.
- **10mm Dynamic Drivers:** Delivers powerful deep bass and clear audio.
- **IPX4 Waterproof:** Resistant to sweat and splashes, suitable for workouts.
- **Long Battery Life:** Up to 6 hours listening time per charge, 30 hours total with charging case.
- **Comfortable Fit:** Ergonomic design with multiple eartip sizes.

4. Setup

Initial Pairing:

1. **Charge the Earbuds:** Before first use, place both earbuds into the charging case and connect the case to a power source using the provided USB-C cable. Ensure the earbuds and case are fully charged.
2. **Power On:** Open the charging case. The earbuds will automatically power on and enter TWS (True Wireless Stereo) pairing mode.
3. **Activate Bluetooth:** On your device (smartphone, tablet, laptop), go to Bluetooth settings and enable Bluetooth.
4. **Select "Pamu S29":** In the list of available Bluetooth devices, select "Pamu S29".
5. **Confirm Connection:** Once connected, you will hear an audio prompt, and the earbuds will be ready for use.

Note: After the initial pairing, the earbuds will automatically connect to the last paired device when taken out of the case, provided Bluetooth is enabled on the device.



Image: pamu S29 Instant Pairing Process. This image demonstrates the simple pairing process, showing a smartphone's Bluetooth settings with "Pamu S29" successfully connected.

5. Operating Instructions

The pamu S29 earbuds feature intuitive touch controls on each earbud. The following table outlines the functions:




Image: pamu S29 Earbuds Touch Control Diagram. This diagram illustrates the touch-sensitive areas on the left and right earbuds and provides a table of

operating instructions for various functions like calls, music playback, and voice assistant activation.

Touch Control Functions

Touch Key	Left Ear	Right Ear
Click	Play & Pause / Receive call	Play & Pause / Receive call
Double click	Previous track / Hang up (Call Status)	Next track / Hang up (Call Status)
Triple click	Turn on game mode / Turn off game mode	Activate voice assistant
Press and hold for 2 seconds	Cancel voice assistant / Reject call	Cancel voice assistant / Reject call
Press and hold for 2 seconds	Turn on noise reduction / Transparent mode	Turn on noise reduction / Transparent mode
Press and hold for 3 seconds	Turn off noise reduction	Turn off noise reduction

ANC and Transparent Mode:

The pamu S29 earbuds offer Active Noise Cancellation (ANC) and Transparent Mode. ANC reduces external noise, while Transparent Mode allows you to hear your surroundings without removing the earbuds. Switch between these modes by pressing and holding the touch key for 2 seconds (as per the table above).




Image: pamu S29 ANC and Transparent Mode Switching. This image visually represents the ability to switch between ANC and Transparent modes, indicating sound wave manipulation.

Mono/Dual Mode:

Each earbud can be used independently (Mono Mode) or together (Dual Mode) for a seamless audio experience. Simply take one earbud out of the case to use it in mono mode, or both for stereo.




Image: pamu S29 Single Ear and Binaural Mode. This image illustrates the flexibility of using either a single earbud or both, along with battery life information.

6. Charging

To charge your pamu S29 earbuds, place them into the charging case. The case itself can be charged via the USB-C port located at the bottom.

- **Earbud Battery Life:** Up to 6 hours of listening time on a single charge.
- **Total Battery Life (with case):** Up to 30 hours.
- **Charging Time:** Approximately 1.5 hours for a full charge via USB-C.

Battery Indicator Light:

The charging case features an LED indicator to show the battery level:

- **Green LED:** 70% - 100% battery
- **White LED:** 30% - 70% battery
- **Orange LED:** 0% - 30% battery



Image: pamu S29 Charging Case Battery Indicator. This image shows the charging case with its battery level indicator, displaying different LED colors for various charge levels (Green, White, Orange).

7. Maintenance

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Eartips:** Remove eartips and clean them with mild soap and water if necessary. Ensure they are completely dry before reattaching.
- **Water Resistance:** The earbuds are IPX4 waterproof, meaning they are resistant to sweat and splashes. Do not submerge them in water or expose them to heavy rain. The charging case is not waterproof.
- **Storage:** Store the earbuds in their charging case when not in use to protect them and keep them charged. Avoid extreme temperatures.

8. Troubleshooting

Earbuds not pairing or connecting:

- Ensure both earbuds are charged and taken out of the case.
- Turn off and on your device's Bluetooth.
- Forget "Pamu S29" from your device's Bluetooth list and try pairing again.
- Ensure the earbuds are within the Bluetooth range of your device.

Only one earbud working:

- Place both earbuds back into the charging case, close the lid, wait a few seconds, then open the lid and take them out again.
- Ensure both earbuds are charged.

Poor sound quality:

- Ensure the eartips fit snugly in your ears to create a good seal. Try different sized eartips.
- Clean any debris from the earbud speakers.
- Check the audio source and volume settings on your device.

Charging case not charging:

- Ensure the USB-C cable is properly connected to both the case and the power source.
- Try a different USB-C cable or power adapter.

9. Specifications

Feature	Detail
Model Name	S29 (T6CP)
Connectivity Technology	Wireless (Bluetooth 5.2)
Audio Driver Size	10 mm
Noise Control Features	Active Noise Cancellation (ANC), Environmental Noise Cancellation (ENC)
Water Resistance Level	IPX4 (Earbuds only)
Battery Life (Earbuds)	Up to 6 hours
Total Battery Life (with case)	Up to 30 hours
Charging Time	1.5 Hours (via USB-C)
Earbud Weight	3.9 Grams (per earbud)
Material	Silicone (eartips)
Compatible Devices	Smartphones, Tablets, Laptops, Desktops
UPC	768461287025

10. Safety Information

- Do not disassemble or modify the product.
- Keep away from extreme temperatures, direct sunlight, and open flames.
- Avoid exposing the charging case to water or moisture.
- Use only the provided charging cable or a certified USB-C cable.
- Do not use the earbuds at excessively high volumes for prolonged periods to prevent hearing damage.
- Keep out of reach of children and pets.

11. Warranty and Support

For warranty information, technical support, or customer service inquiries, please refer to the warranty card included in your product packaging or visit the official pamu website. Please retain your proof of purchase for any warranty claims.

12. Product Videos

Watch these official product videos for visual guides and demonstrations.

Your browser does not support the video tag.

Video: Pamu S29 Wireless Bluetooth Earbuds with Charging Case. This video provides an overview and unboxing of the Pamu S29 earbuds and charging case.

Your browser does not support the video tag.

Video: Pamu S29 Noise Cancelling Wireless Bluetooth Headphones with Charging Case. This video demonstrates the noise-cancelling features and overall functionality of the Pamu S29 earbuds.

© 2023 pamu. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09WJ1RJNX

More documents and user manuals: **https://manuals.plus/**