

[Manuals.plus](#) /

› [Kikkerland](#) /

› Kikkerland Solar-Powered Double Rainbow Maker Instruction Manual

Kikkerland RM1588-D-EU

Kikkerland Solar-Powered Double Rainbow Maker Instruction Manual

Model: RM1588-D-EU

INTRODUCTION

Thank you for purchasing the Kikkerland Solar-Powered Double Rainbow Maker. This device utilizes solar energy to rotate genuine crystals, creating beautiful rainbow patterns when exposed to direct sunlight. Please read this manual carefully to ensure proper setup and operation.

PRODUCT FEATURES

- Solar-powered operation.
- Features two genuine crystals for enhanced rainbow projection.
- Designed to attach easily to windows.
- Creates dynamic rainbow patterns in your living space.

PACKAGE CONTENTS

The package should contain the following items:

- 1 x Kikkerland Solar-Powered Double Rainbow Maker unit
- Instruction Manual (this document)






Image: The Kikkerland Solar-Powered Double Rainbow Maker shown in its retail packaging. The packaging displays the product name, brand logo, and a visual of the device with its two crystals.

SETUP INSTRUCTIONS

1. **Unpack the Device:** Carefully remove the Rainbow Maker from its packaging.
2. **Choose a Location:** Select a window that receives direct sunlight for several hours a day. The solar panel needs direct sun exposure to power the rotation mechanism.
3. **Attach to Window:** The Rainbow Maker features a suction cup for easy attachment. Ensure the window surface is clean and dry before pressing the suction cup firmly against the glass. Position the device so the solar panel faces outwards, towards the sun.
4. **Adjust Solar Panel:** The solar panel can be tilted to optimize its angle towards the sun. Adjust it to maximize sunlight absorption.



Image: The Kikkerland Solar-Powered Double Rainbow Maker attached to a window, showcasing its clear casing, internal gears, solar panel, and two hanging crystals. The device is positioned to receive sunlight.

OPERATING INSTRUCTIONS

The Kikkerland Solar-Powered Double Rainbow Maker operates automatically when exposed to sufficient direct sunlight.

- Once the solar panel absorbs enough sunlight, it will power a small motor.
- This motor drives a series of gears, which in turn rotate the two hanging crystals.
- As the crystals rotate and sunlight passes through them, they will refract the light, creating moving rainbow patterns on nearby surfaces.
- The intensity and movement of the rainbows will vary depending on the angle and strength of the sunlight.

MAINTENANCE

- **Cleaning:** To maintain optimal performance and clarity of the crystals, periodically wipe the solar panel and crystals with a soft, damp cloth. Avoid abrasive cleaners.
- **Position Adjustment:** As seasons change, the angle of the sun will shift. Adjust the position of the Rainbow Maker on your window or the tilt of the solar panel to ensure it continues to receive direct sunlight.
- **Storage:** If storing the device for an extended period, remove it from the window and store it in a cool, dry place away from direct sunlight.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Rainbow Maker is not rotating.	Insufficient direct sunlight.	Relocate the device to a window that receives more direct sunlight. Ensure the solar panel is clean and optimally angled.
Rainbows are faint or absent.	Crystals are dirty or scratched; insufficient sunlight.	Clean the crystals with a soft, damp cloth. Verify the device is in direct sunlight.
Device makes a clicking sound but does not spin.	Internal mechanism obstruction or malfunction.	Ensure no external objects are obstructing the gears or crystals. If the issue persists, contact customer support.

SPECIFICATIONS

- **Model Number:** RM1588-D-EU
- **Power Source:** Solar-powered
- **Material:** Crystal
- **Item Weight:** 2.4 ounces
- **Assembly Required:** No
- **Designed by:** David Dear

WARRANTY AND SUPPORT

For warranty information or technical support, please contact Kikkerland customer service through their official website or the retailer where the product was purchased. Keep your purchase receipt as proof of purchase.

Kikkerland Website: www.kikkerland.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09WJ43WF6>

More documents and user manuals: <https://manuals.plus/>