Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

saschedross 15V AC/DC Adapter

saschedross 15V AC/DC Adapter User Manual

Model: 15V AC/DC Adapter (Compatible with High-Power TM18C, AWANFI C101, C104 Jump Starters)

1. Introduction

This manual provides essential instructions for the safe and effective use of your saschedross 15V AC/DC Adapter. This adapter is designed to provide a stable 15V DC power supply for charging compatible devices, such as High-Power TM18C, AWANFI C101, and AWANFI C104 jump starters, and other devices requiring a 15VDC 1A input.

Please read this manual thoroughly before using the adapter and retain it for future reference.

2. Safety Information

- **Indoor Use Only:** This adapter is intended for indoor use in dry locations. Do not expose it to rain, moisture, or extreme temperatures.
- **Proper Voltage:** Ensure the wall outlet voltage matches the adapter's input requirements (100-240V AC).
- **Avoid Overloading:** Do not connect devices that exceed the adapter's output specifications (15V DC, 1A).
- **Inspect Before Use:** Before each use, check the adapter and its cable for any signs of damage. Do not use if damaged.
- **Disconnect When Not in Use:** Unplug the adapter from the wall outlet and the device when not charging or when unattended for extended periods.
- **Keep Away from Children:** Store the adapter out of reach of children.
- **Ventilation:** Ensure adequate ventilation around the adapter during operation to prevent overheating.

3. Product Overview

The saschedross 15V AC/DC Adapter is a compact and efficient power supply designed for charging various electronic devices, particularly jump starters. It features a standard AC input plug and a DC barrel connector for output.



Figure 1: Various views of the 15V AC/DC adapter, illustrating its compact dimensions (approximately 2.7 inches in height, 1.2 inches in width, and 1.6 inches in depth). The adapter features a standard two-prong AC plug for power input and a barrel connector for DC output. The label indicates an input of 100-240VAC, 0.3A, 50/60Hz.



Figure 2: The 15V AC/DC adapter shown with its integrated power cable, which measures approximately 6.5 feet (2 meters) in length. The cable terminates in a barrel connector for connecting to compatible devices.



Figure 3: An illustration of the adapter's portability, with a hand demonstrating how easily it fits into a pocket or bag, highlighting its suitability for travel.

4. Setup

1. **Identify Charging Port:** Locate the 15V DC input charging port on your compatible jump starter or device. This port typically accepts a barrel connector.
2. **Connect to Device:** Insert the barrel connector of the saschedross 15V AC/DC Adapter into the 15V DC input port of your device. Ensure a firm connection.
3. **Plug into Outlet:** Insert the AC plug of the adapter into a standard 100-240V AC wall outlet.

Once connected, your device should begin charging. Refer to your device's manual for specific charging indicators or instructions.

5. Operating Instructions

The saschedross 15V AC/DC Adapter operates automatically once connected to a power source and a compatible device.

- **Charging:** When properly connected, the adapter will supply 15V DC power to your device. The charging status (e.g., indicator lights, battery level) will typically be displayed on the device itself.
- **Charging Time:** Charging time will vary depending on the battery capacity of your device and its current charge level.
- **Disconnection:** Once your device is fully charged, or if you need to stop charging, first unplug the adapter from the wall outlet, then disconnect the barrel connector from your device.

6. Maintenance

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Wipe the exterior with a soft, dry cloth. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and moisture when not in use.
- **Cable Care:** Avoid sharp bends, twists, or kinks in the power cable. Do not place heavy objects on the cable.

7. Troubleshooting

Problem	Possible Cause	Solution
Device not charging	1. Adapter not plugged into wall outlet. 2. Adapter not properly connected to device. 3. Wall outlet is not active. 4. Adapter or cable is damaged. 5. Device is not compatible or has an internal issue.	1. Ensure the adapter's AC plug is fully inserted into a live wall outlet. 2. Verify the barrel connector is securely inserted into the device's charging port. 3. Test the wall outlet with another appliance. 4. Inspect the adapter and cable for visible damage. If damaged, discontinue use and replace. 5. Confirm device compatibility and consult the device's manual.
Adapter feels warm during use	Normal operation. Overheating due to poor ventilation or overload.	A slight warmth is normal. Ensure the adapter is in a well-ventilated area. If it becomes excessively hot, disconnect immediately and check for obstructions or overload.

8. Specifications

- **Model:** 15V AC/DC Adapter
- **Input:** 100-240V AC, 0.3A, 50/60Hz
- **Output:** 15V DC, 1A
- **Output Connector:** Barrel Plug
- **Cable Length:** Approximately 6.5 ft (2 meters)
- **Dimensions (Adapter Body):** Approximately 2.7 in (H) x 1.2 in (W) x 1.6 in (D)
- **Manufacturer:** Shenzhen Waweis Technology Co., Ltd
- **ASIN:** B09WJGCH24

© 2024 saschedross. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09WJGCH24

More documents and user manuals: **https://manuals.plus/**