

Coverage Tecno KG5k /Spark 8C

User Manual: Coverage Transparent Rubber Back Cover

Model: Tecno KG5k / Spark 8C

1. INTRODUCTION

Thank you for choosing the Coverage Transparent Rubber Back Cover. This manual provides essential information for the proper installation, use, and maintenance of your new phone cover. Designed specifically for the Tecno KG5k / Spark 8C, this transparent cover offers protection against dust, dirt, bumps, and scratches while maintaining full access to all phone controls and buttons.



Image 1.1: The Coverage Transparent Rubber Back Cover fitted on a Tecno Spark 8C smartphone, showcasing its clear design and precise fit around the camera and buttons.

2. SETUP AND INSTALLATION

Follow these steps to correctly install the back cover on your Tecno KG5k / Spark 8C mobile phone.

- 1. Verify Compatibility:** Ensure your mobile phone is the Tecno KG5k or Tecno Spark 8C model. This cover is specifically designed for these models and will not fit other versions, such as the Tecno Spark 8.

FITS ONLY - Tecno Spark 8C



Image 2.1: Visual guide illustrating the precise fit of the cover on the Tecno Spark 8C (left) and demonstrating that it does not fit the Tecno Spark 8 (right).

2. **Clean Your Device:** Before installation, gently wipe your phone's back and sides with a soft, dry cloth to remove any dust or fingerprints. This ensures a clean fit and prevents particles from being trapped under the cover.
3. **Align the Cover:** Hold the transparent back cover and align it with your phone, ensuring the camera cutouts and button placements match perfectly.



Image 2.2: The transparent back cover positioned alongside a Tecno Spark 8C phone, highlighting its clear material and readiness for installation.

4. **Snap into Place:** Gently press your phone into the cover, starting from one corner and working your way around. The flexible silicone material will allow for easy fitting. Ensure all edges are securely seated.
5. **Check Fit:** Once installed, verify that all buttons (power, volume) are accessible and functional, and that the charging port and speaker cutouts are unobstructed.

3. OPERATING AND USAGE

The Coverage Transparent Rubber Back Cover is designed for everyday use, providing reliable protection without hindering your phone's functionality.

- **Enhanced Grip:** The rubber material provides a comfortable and secure grip, reducing the chance of accidental drops.
- **Button Accessibility:** The cover features precise cutouts and responsive button covers, ensuring easy access and tactile feedback for all physical buttons.
- **Port Access:** All ports (charging, audio) and speaker grilles remain fully accessible for normal use.

- **Camera Protection:** The raised edges around the camera module help protect the lenses from scratches when the phone is placed on flat surfaces.

Ankirant



Image 3.1: A hand demonstrating the flexibility of the transparent rubber back cover, highlighting its durable and pliable material.

4. MAINTENANCE AND CARE

To ensure the longevity and clarity of your transparent back cover, follow these simple maintenance guidelines:

- **Regular Cleaning:** Wipe the cover periodically with a soft, damp cloth to remove dust, dirt, and smudges. For stubborn marks, a small amount of mild soap can be used, followed by rinsing and drying thoroughly.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, alcohol, or strong chemical solvents, as these can damage the material and affect its transparency.
- **Prevent Discoloration:** While designed to resist yellowing, prolonged exposure to direct sunlight or extreme temperatures may accelerate discoloration. Store your phone in a cool, shaded place when not in use.
- **Inspect for Damage:** Periodically check the cover for any signs of wear, tears, or damage. A damaged cover may not

provide optimal protection.

5. TROUBLESHOOTING

Most issues with the back cover are minor and can be resolved easily.

Problem	Possible Cause	Solution
Cover does not fit properly.	Incorrect phone model.	Ensure your phone is a Tecno KG5k / Spark 8C. This cover is not compatible with other models.
Buttons are stiff or unresponsive.	Cover not fully seated.	Remove the cover and re-install, ensuring all edges snap into place correctly.
Dust or debris trapped under cover.	Phone not cleaned before installation.	Remove the cover, clean both the phone and the inside of the cover with a soft cloth, then re-install.
Cover appears discolored or yellowed.	Natural aging of material or prolonged UV exposure.	This is normal over time. Minimize direct sunlight exposure to slow the process.

6. SPECIFICATIONS

Feature	Detail
Product Name	Coverage Transparent Rubber Back Cover
Brand	Coverage
Model Compatibility	Tecno KG5k / Spark 8C
Material	Silicone
Color	Transparent
Form Factor	Basic Case
Item Weight	100 g
Package Dimensions	19 x 11 x 9 cm
Special Features	Shock-Absorbent

7. WARRANTY AND SUPPORT

7.1. Warranty Information

This Coverage Transparent Rubber Back Cover comes with a **7-day warranty** from the date of purchase. This warranty covers manufacturing defects. It does not cover damage caused by misuse, accident, unauthorized modification, or normal wear and tear. Please retain your proof of purchase for warranty claims.

7.2. Customer Support

For any questions, concerns, or support regarding your Coverage product, please contact the seller or refer to the platform where you made your purchase.

- **Returns Policy:** Please refer to the retailer's return policy for information on product returns.
- **Secure Transaction:** Your purchase is backed by a secure transaction process.

© 2024 Coverage. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.