

[Manuals.plus](#) /

› [ENWShop](#) /

› ENWShop MECOOL KD3 4K Streaming Stick User Manual

ENWShop KD3

ENWShop MECOOL KD3 4K Streaming Stick User Manual

Model: KD3

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your ENWShop MECOOL KD3 4K Streaming Stick. Please read this guide thoroughly to ensure proper use and to maximize your device's capabilities. The MECOOL KD3 is a Google TV 11 certified streaming device designed to deliver a high-quality 4K entertainment experience with integrated Google Assistant and Chromecast functionality.

WHAT'S IN THE BOX

Carefully unpack your MECOOL KD3 and verify that all items are present:

- MECOOL KD3 4K Streaming Stick
- Bluetooth Voice Remote Control
- Power Adapter
- USB Cable
- HDMI Extension Cable
- User Guide (this document)



Image: The MECOOL KD3 4K Streaming Stick, its remote control, power adapter, USB cable, and HDMI extension cable, as packaged in the retail box.

PRODUCT OVERVIEW

The MECOOL KD3 is a compact streaming device that connects directly to your TV's HDMI port. It features a minimalist design and comes with a voice-enabled Bluetooth remote control for easy navigation and interaction.



Image: The MECOOL KD3 streaming stick and its accompanying remote control, showcasing their design.

SETUP INSTRUCTIONS

1. Connect the MECOOL KD3 to your TV

1. Plug the MECOOL KD3 Streaming Stick directly into an available HDMI port on your television. If space is limited, use the provided HDMI extension cable.
2. Connect the USB cable to the MECOOL KD3 and then to the power adapter.
3. Plug the power adapter into a wall outlet.

2. Power On and Initial Setup

1. Turn on your TV and select the correct HDMI input source to which the MECOOL KD3 is connected.
2. The device will boot up and display the Google TV setup screen.
3. **Pair the Remote Control:** Follow the on-screen instructions to pair your Bluetooth voice remote control. This usually involves pressing and holding specific buttons on the remote until an indicator light flashes.

4. **Network Connection:** Connect the device to your Wi-Fi network by selecting your network and entering the password.
5. **Google Account Login:** Sign in with your Google account. This is required to access Google TV features, download apps, and use Google Assistant.
6. **Complete Setup:** Follow any remaining on-screen prompts to complete the initial setup, including accepting terms of service and customizing settings.



Image: The Google TV 11 home screen, illustrating the user interface and available applications.

OPERATING INSTRUCTIONS

Navigating Google TV

Use the directional pad and select button on your remote to navigate through the Google TV interface. The home button will always return you to the main screen. Dedicated buttons for YouTube, Netflix, Prime Video, and Disney+ provide quick access to these popular streaming services.

Using Google Assistant

Press the Google Assistant button on your remote and speak into the microphone to control your device, search for content, get information, and manage smart home devices. For example, say "Hey Google, open Netflix" or "What's the weather today?"

Image: Demonstrating the use of Google Assistant via the remote control to display weather information on the TV.

Streaming Content

The MECOOL KD3 supports 4K streaming from various applications, including Netflix, YouTube, Prime Video, and Disney+. Ensure your internet connection is stable and fast enough for 4K content (typically 25 Mbps or higher).

4k Netflix Google TV Steaming Dongle

Built-in the Netflix for TVs version with Android operating system.
Supports TV 4k streaming.




Image: A TV screen showing Netflix content, highlighting the 4K streaming feature of the MECOOL KD3.

Chromecast Built-in

The device includes Chromecast built-in, allowing you to cast content from your compatible phone, tablet, or computer directly to your TV. Look for the Cast icon within supported apps on your mobile device.

**If you want to increase the storage on your MECOOL KD3,
then follow the steps below.**

***Sold Separately**




Image: A visual representation of Chromecast built-in, showing content mirrored from a smartphone to the television.

AV1 Video Codec Support

The MECOOL KD3 supports the AV1 video codec, which offers improved compression efficiency. This means you can stream high-quality video with less data consumption compared to older codecs like H.265 or VP9.



Image: A comparison graphic illustrating the efficiency of the AV1 codec over VP9/H.265, resulting in more video for less data.

MAINTENANCE

Cleaning

To clean your MECOOL KD3, gently wipe the device and remote with a soft, dry, lint-free cloth. Do not use liquid cleaners or abrasive materials.

Software Updates

The MECOOL KD3 will periodically receive software updates to improve performance and add new features. Ensure your device is connected to the internet to receive these updates automatically. You can also manually check for updates in the device settings.

Storage Expansion

The MECOOL KD3 has 8GB of internal storage. If you require additional storage for apps or media, you can expand it using a USB hub (sold separately) connected to the device's micro USB port, allowing you to connect a USB disk.




Image: Instructions for expanding storage on the MECOOL KD3 using a USB hub to connect a USB disk and power adapter.

TROUBLESHOOTING

- **No Power/Device Not Turning On:**

Ensure the power adapter is securely connected to the device and a working power outlet. Try a different outlet.

- **No Picture on TV:**

Verify the HDMI cable is properly connected to both the MECOOL KD3 and the TV. Ensure your TV is set to the correct HDMI input source. Try a different HDMI port or cable.

- **Remote Control Not Responding:**

Check the batteries in the remote control and replace them if necessary. Re-pair the remote by following the initial setup instructions or consulting the device settings for remote pairing options.

- **Wi-Fi Connection Issues:**

Ensure your Wi-Fi router is on and functioning. Re-enter your Wi-Fi password in the device settings. Move the device closer to the router or reduce interference from other electronic devices.

- **Buffering or Poor Streaming Quality:**

Check your internet speed. For 4K streaming, a minimum of 25 Mbps is recommended. Reduce the number of devices using your network simultaneously. Restart your router and the MECOOL KD3.

- **Apps Not Working/Crashing:**

Try clearing the cache for the problematic app in the device settings (Settings > Apps > [App Name] > Clear Cache). If the issue persists, try uninstalling and reinstalling the app.

SPECIFICATIONS

Brand	ENWShop
Model Name	KD3

Operating System	Google TV 11
Resolution	4K Ultra HD
Processor	Amlogic S905Y4 (4-core)
RAM	2 GB DDR
Internal Storage	8 GB eMMC
Connectivity	HDMI, Wi-Fi (2.4G/5G 2T2R)
Special Features	Netflix 4K, Google Assistant, Chromecast Built-in, AV1 Video Codec, HDR10
Controller Type	Bluetooth Voice Remote Control



Image: Detailed view of the Amlogic S905Y4 CPU, emphasizing its power-saving features and codec compatibility.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided at the time of purchase or contact ENWSop customer service through their official channels. Keep your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09WKV9FCV>

More documents and user manuals: <https://manuals.plus/>