

[Manuals.plus](#) /

> [Q&Q](#) /

> Q&Q M206J003Y Digital Resin Watch User Manual

## Q&Q M206J003Y

# Q&Q M206J003Y Digital Resin Watch User Manual

Model: M206J003Y

## INTRODUCTION

Thank you for purchasing the Q&Q M206J003Y Digital Resin Watch. This manual provides essential information for the proper use, setup, and maintenance of your watch. Please read it carefully to ensure optimal performance and longevity of your timepiece.

The Q&Q M206J003Y is a durable digital watch featuring a quartz movement, 50-meter water resistance, and a comfortable resin strap. Its digital display and sporty design make it suitable for various activities.



Image: Front view of the Q&Q M206J003Y Digital Resin Watch. The watch features a square black case, a clear digital display, and a black

resin strap. Control buttons are visible on the sides.

## SETUP

### Setting Time and Date

Your Q&Q M206J003Y watch typically has multiple buttons for operation. While specific button functions may vary slightly, the general procedure for setting time and date is as follows:

1. **Enter Time Setting Mode:** Press the **MODE** button repeatedly until the time setting mode is displayed. Digits (usually hours or seconds) will start flashing.
2. **Select Item to Adjust:** Use the **ADJUST** or **LIGHT** button to cycle through the items you wish to set (seconds, hours, minutes, year, month, day).
3. **Adjust Value:** Use the **START/STOP** or **RESET** button to increase or decrease the flashing value.
4. **Exit Setting Mode:** Once all settings are correct, press the **MODE** button again to return to the normal time display.

Refer to the button labels on your specific watch for precise identification.

## OPERATING INSTRUCTIONS

### Mode Functions

Your digital watch includes several modes accessible via the **MODE** button:

- **Timekeeping Mode:** Displays current time (hour, minute, second), day of the week, and date.
- **Alarm Mode:** Allows you to set a daily alarm. Use the **ADJUST** and **START/STOP** buttons to set the alarm time.
- **Stopwatch Mode:** Measures elapsed time. Press **START/STOP** to begin/pause, and **RESET** to clear.
- **Backlight:** Press the **LIGHT** button to illuminate the display for a few seconds in low-light conditions.



Image: The Q&Q M206J003Y watch displayed on a wrist, illustrating its practical size and fit. The digital screen clearly shows the time and date.

## MAINTENANCE

### Water Resistance

This watch is water resistant up to 50 meters (5 ATM). This means it is suitable for showering, swimming in shallow water,

and general daily use. It is **not** suitable for diving, snorkeling, or high-pressure water activities.

- Do not operate buttons while the watch is submerged in water.
- Avoid exposing the watch to hot water or steam, as this can compromise the seals.

## Cleaning

To clean your watch, wipe it with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and mild soap, then wipe dry immediately. Avoid harsh chemicals or abrasive cleaners.

## Battery Replacement

The watch is powered by a Lithium Ion battery (included). When the display dims or functions become erratic, it may be time to replace the battery. Battery replacement should ideally be performed by a qualified watch technician to ensure water resistance is maintained.



Image: Back view of the Q&Q M206J003Y Digital Resin Watch. The stainless steel case back is visible, along with the attachment points for the black resin strap.

## TROUBLESHOOTING

| Problem                        | Possible Cause  | Solution  |
|--------------------------------|---|---|
| Display is blank or dim.       | Low battery.  | Replace the battery.  |
| Time is incorrect.             | Time not set correctly or accidental button press.    | Re-set the time and date as per the "Setup" section.  |
| Buttons are unresponsive.      | Watch may be in a locked mode or battery is very low. | Try pressing all buttons to see if it unlocks. If not, replace battery.                           |
| Condensation inside the watch. | Water resistance compromised.                         | Stop using the watch immediately and take it to a qualified technician for inspection and repair. |

## SPECIFICATIONS

| Feature      | Detail    |
|--------------|-----------|
| Brand        | Q&Q       |
| Model Number | M206J003Y |

| Feature                   | Detail   |
|---------------------------|--|
| Display Type              | Digital  |
| Movement                  | Quartz   |
| Water Resistance Depth    | 50 Meters (5 ATM)                                |
| Case Material             | Resin  |
| Case Shape                | Square   |
| Case Diameter             | 38 mm  |
| Case Thickness            | 9 mm   |
| Dial Window Material Type | Mineral Glass                                    |
| Band Material Type        | Resin  |
| Band Color                | Black  |
| Band Width                | 18 mm  |
| Clasp Type                | Buckle   |
| Power Source              | Battery Powered (1 Lithium Ion battery included) |
| Item Weight               | 30 grams   |
| Country of Origin         | China  |

## WARRANTY INFORMATION

This Q&Q M206J003Y Digital Resin Watch comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.

The warranty does not cover:

- Damage resulting from improper handling, lack of care, accidents, or normal wear and tear.
- Water damage if the watch was used beyond its specified water resistance limits or if buttons were operated underwater.
- Battery replacement.
- Unauthorized repairs or modifications.

For warranty claims or service, please contact the manufacturer or its authorized service agent. You may also contact Amazon for further assistance regarding your purchase.



Image: The white Q&Q product box, featuring the brand logo. This represents the original packaging for the watch.

## SUPPORT

If you require further assistance or have questions not covered in this manual, please refer to the following resources:

- **Manufacturer's Website:** Visit the official Q&Q website for product information and support.
- **Customer Service:** Contact the retailer (e.g., Amazon) where you purchased the watch for order-specific inquiries.
- **Authorized Service Centers:** For repairs or technical issues, locate an authorized Q&Q service center in your region.

Always provide your model number (M206J003Y) when seeking support.