



[Manuals.plus](#) /

› [Take Me Away](#) /

› Take Me Away 18" Trapeze Swing Bar Rings User Manual

Take Me Away DH-Green-120

Take Me Away 18" Trapeze Swing Bar Rings User Manual

Model: DH-Green-120

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your Take Me Away 18" Trapeze Swing Bar. Please read it thoroughly before installation and operation. Keep this manual for future reference.



Figure 1: Take Me Away Trapeze Swing Bar with Rings and Chains (Green color variant shown).

2. SAFETY INFORMATION

Always prioritize safety when installing and using this product. Failure to follow these instructions may result in injury or damage.

- **Maximum Weight Capacity:** Do not exceed the maximum weight recommendation of 250 pounds.
- **Adult Supervision:** Children should always be supervised by an adult when using the swing.
- **Secure Installation:** Ensure the trapeze bar is securely attached to a sturdy swing set, ceiling, or robust tree branch capable of supporting the weight.
- **Regular Inspection:** Periodically check all components, including chains, S-links, bar, and rings, for wear, damage, or loose connections. Replace worn parts immediately.
- **Clearance:** Ensure adequate clearance around the swing area to prevent collisions with other objects or structures.
- **Surface:** Install over a soft, impact-absorbing surface such as wood chips, sand, or rubber mulch.

3. SETUP AND INSTALLATION

3.1. Package Contents

Verify that all components are present before beginning installation:

- 1x Trapeze Bar with Rings
- 2x Heavy Duty Plastic Coated Chains (48 inches each)
- 2x Reliable S-Links (Carabiners)



Figure 2: All components included in the package.

3.2. Installation Steps

1. **Prepare Mounting Point:** Identify a sturdy and secure overhead structure (e.g., swing set beam, robust tree branch, or ceiling mount) capable of safely supporting the swing and user weight.
2. **Attach Chains:** The trapeze bar comes with chains already attached to the bar.
3. **Connect to Mounting Point:** Use the provided S-links (carabiners) to connect the top end of each chain to your chosen mounting points. Ensure the S-links are fully closed and secured.
4. **Adjust Height (Optional):** The chains are adjustable. You can easily change the height of the chain by re-positioning the S-links or by shortening the chain length if necessary.



Figure 3: Example of the trapeze bar installed on a wooden swing set, showing chain and ring details.



Figure 4: Close-up view of the trapeze bar and ring attachment point, highlighting the secure connection.

4. OPERATING INSTRUCTIONS

The Take Me Away Trapeze Swing Bar is designed for recreational use in outdoor play environments.

- **Usage:** Users can hold onto the trapeze bar with both hands or use the integrated rings for various swinging and gymnastic activities.
- **Grip:** The rings are designed for an easy grip, providing comfort and security during use.
- **Movement:** Swing forward and backward, or perform controlled spins. Avoid excessive or uncontrolled movements that could lead to instability.



Figure 5: A child demonstrating the use of the trapeze swing bar, highlighting its recreational purpose.




Figure 6: Detail of the upgraded easy grip rings, designed for comfort and durability.

5. MAINTENANCE

Regular maintenance ensures the longevity and safety of your trapeze swing bar.

- **Cleaning:** Wipe down the trapeze bar, rings, and chains with a damp cloth and mild soap as needed. Rinse thoroughly and allow to air dry. Avoid harsh chemicals.
- **Inspection:**
 - Check chains for rust, kinks, or excessive wear. The plastic coating helps protect against corrosion.
 - Inspect S-links (carabiners) for deformation, cracks, or signs of weakening. Ensure they close securely.
 - Examine the trapeze bar and rings for cracks, breaks, or sharp edges.
 - Verify that all connections are tight and secure.
- **Storage:** If not in use for extended periods, especially during harsh weather, consider detaching and storing the swing

indoors to prolong its life.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Swing feels unstable or wobbly.	Loose S-links or insecure mounting point.	Ensure S-links are fully closed and securely attached. Verify the mounting structure is stable and robust.
Chains show signs of wear or rust.	Exposure to elements; prolonged use.	The chains are plastic-coated for durability. If significant wear or rust appears, consider replacing the chains. Regular cleaning can help prevent rust.
Rings or bar are damaged.	Impact or excessive force.	Discontinue use immediately. Replace the entire trapeze bar assembly if damaged.

7. SPECIFICATIONS

Brand: Take Me Away

Model: DH-Green-120

Color: Green

Trapeze Bar Length: Approximately 18 inches

Chain Length: 48 inches (heavy duty 4/0 chains with 20 inches plastic coating)

Material: Iron (bar), PE (rings), Zinc-plated steel (chains)

Maximum Weight Recommendation: 250 Pounds

Item Weight: 4.2 pounds

Package Dimensions: 17.48 x 8.03 x 3.82 inches

UPC: 618202001147




Figure 7: Key dimensions of the trapeze swing bar, including bar length and chain length.

8. WARRANTY AND SUPPORT

For information regarding warranty coverage or product support, please contact the manufacturer directly. The seller "TakeMeAway" can be reached via the Amazon platform for inquiries related to your purchase.

Return Policy: This product typically comes with a 30-day return/replacement policy through Amazon.

Manufacturer: Take Me away

