

Manuals.plus /

› JAUYXIAN /

› JAUYXIAN Wireless Microphone Speaker Set Instruction Manual

JAUYXIAN Draagbare Bluetooth-luidspreker

JAUYXIAN Wireless Microphone Speaker Set

Model: Draagbare Bluetooth-luidspreker

1. INTRODUCTION

Thank you for purchasing the JAUYXIAN Wireless Microphone Speaker Set. This portable speaker system is designed for versatile audio playback and karaoke, featuring Bluetooth 5.0 connectivity, FM radio, USB/TF card support, and AUX input. It includes wireless microphones for an enhanced audio experience. Please read this manual carefully before use to ensure proper operation and to maximize the product's lifespan.

2. PRODUCT OVERVIEW

2.1 Speaker Components and Controls

The speaker features a robust design with various input options and controls for audio management.

RiCh Feature Extensions

Karaoke/Radio/Recording/Bluetooth/TWS/USB/Tfcard/
Aux in/Cycle charging



Karaoke



Radio



Recording



Aux in



Bluetooth



Wifi



USB



Cycle charging

Image: Top view of the JAUYXIAN speaker's control panel. This image displays the various ports and buttons, including power, USB, TF card slot, AUX in, microphone inputs (MIC 1, MIC 2), and control buttons for playback and recording.

- **Power Button:** Turns the speaker on/off.
- **USB Port:** For USB flash drive playback.
- **TF Card Slot:** For TF (Micro SD) card playback.
- **AUX In:** 3.5mm audio input for external devices.
- **MIC 1 / MIC 2:** Inputs for wired microphones (if used, wireless microphones connect automatically).
- **Priority MIC:** Activates microphone priority mode, lowering music volume when speaking.
- **Volume Knobs:** Adjust master volume, microphone volume, echo, bass, and treble.
- **Playback Controls:** Previous track, Play/Pause, Next track, Record, Mode selection.

2.2 Package Contents

- JAUYXIAN Wireless Microphone Speaker
- Wireless Microphones (x2)
- Remote Control
- Charging Cable
- User Manual

3. SETUP

3.1 Charging the Speaker

Before first use, fully charge the speaker. Connect the provided charging cable to the speaker's power input and a suitable power source. The charging indicator will show the charging status.



Image: Illustration of the speaker's battery charging process and expected battery life. A full charge takes approximately 6-8 hours, providing 9-12 hours of continuous playback.

- Charging Time: Approximately 6-8 hours.
- Operating Time: Approximately 9-12 hours on a full charge.

3.2 Powering On/Off

Press and hold the Power button on the control panel to turn the speaker on or off.

4. OPERATING INSTRUCTIONS

4.1 Bluetooth Connection

Connect your smartphone, tablet, or computer wirelessly to the speaker.



Image: Visual representation of the speaker's Bluetooth 5.0 capabilities, illustrating wireless connection to devices such as smartphones, iPads, and computers for audio streaming.

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode.
2. On your device, enable Bluetooth and search for available devices.
3. Select "JAUYXIAN Speaker" (or similar name) from the list to pair.
4. Once connected, the speaker will indicate a successful pairing, and you can play audio from your device.

4.2 Karaoke Function

Use the included wireless microphones for karaoke.

1. Ensure the speaker is powered on.
2. Turn on the wireless microphones. They should automatically connect to the speaker.
3. Adjust the microphone volume and echo effects using the dedicated knobs on the speaker.
4. Play your desired music via Bluetooth, USB, TF card, or AUX.
5. To prioritize microphone audio, activate the "Priority MIC" function.

4.3 FM Radio

Listen to FM radio stations.

1. Press the "Mode" button to switch to FM Radio mode.
2. Press the Play/Pause button to automatically scan and save available FM stations.
3. Use the Previous/Next track buttons to navigate between saved stations.

4.4 USB/TF Card Playback

Play audio files directly from a USB flash drive or TF (Micro SD) card.

1. Insert a USB flash drive or TF card (with audio files) into the corresponding port.
2. The speaker will automatically detect and begin playing audio from the storage device. If not, press the "Mode" button to select USB or TF card mode.
3. Use the playback control buttons (Previous, Play/Pause, Next) to manage your music.

4.5 AUX Input

Connect external audio devices using a 3.5mm AUX cable.

1. Connect one end of a 3.5mm audio cable to the AUX In port on the speaker.
2. Connect the other end to the audio output of your external device (e.g., MP3 player, laptop).
3. Press the "Mode" button to select AUX mode.
4. Control playback and volume from your external device.

4.6 True Wireless Stereo (TWS) Function

Connect two JAUYXIAN speakers wirelessly for a stereo sound experience.



Image: Depiction of two JAUYXIAN speakers connected via TWS technology, creating a surround sound experience. A remote control is shown, indicating remote operation capabilities.

1. Ensure both speakers are powered on and in Bluetooth mode, but not connected to any device.
2. On one speaker (this will be the primary speaker), press and hold the TWS button (if available, or a specific mode button combination as per product design) until you hear an indication sound.
3. The two speakers will pair automatically. Once paired, they will function as left and right channels.
4. Connect your Bluetooth device to the primary speaker. Audio will now play in stereo through both speakers.

4.7 Portability and Carrying

The speaker is designed for easy transport with an adjustable shoulder strap.



Adjustable

Adjustable shoulder strap

Inclined Span

Straddlable shoulder strap

Portable Design

Easy to carry out



Image: A person carrying the JAUYXIAN speaker using its adjustable shoulder strap, highlighting its portable design for outdoor use.

5. MAINTENANCE

- **Cleaning:** Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, charge the speaker regularly, even if not in frequent use. Avoid fully discharging the battery for extended periods.
- **Water Exposure:** This speaker is not waterproof. Avoid exposure to water or excessive moisture.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery; Power button not pressed correctly.	Charge the speaker; Press and hold the Power button firmly.
No sound.	Volume too low; Incorrect mode selected; Device not connected.	Increase speaker and source device volume; Select correct input mode (Bluetooth, AUX, USB/TF); Ensure device is paired.
Bluetooth connection fails.	Speaker not in pairing mode; Device too far; Interference.	Ensure speaker is in Bluetooth mode; Move device closer; Restart speaker and device.
Microphone not working.	Microphone off; Volume too low; Battery low in microphone.	Turn on microphone; Increase microphone volume; Check microphone batteries.

7. SPECIFICATIONS

- **Brand:** JAUYXIAN
- **Model Number:** Draagbare Bluetooth-luidspreker
- **Connectivity Technology:** Bluetooth 5.0, AUX
- **Power Source:** Battery Powered, Corded Electric
- **Continuous Use Time:** Up to 8 hours
- **Mounting Type:** Tabletop
- **Channel Count:** 2
- **Color:** Black
- **Product Dimensions:** 38.3 x 32.7 x 19.1 cm
- **Product Weight:** 4.01 kg
- **Compatible Devices:** Smartphones, PCs, Tablets
- **UPC:** 797439630761

8. SAFETY INFORMATION

- Do not expose the speaker to extreme temperatures, direct sunlight, or high humidity.
- Do not disassemble or attempt to repair the speaker yourself. This may void the warranty and cause damage.
- Keep the speaker away from children and pets.
- Use only the provided charging cable or a certified equivalent.
- Avoid placing heavy objects on the speaker.

9. WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For detailed warranty information or technical support, please refer to the warranty card included in your package or contact JAUYXIAN customer service through the retailer where you purchased the product.

